

HCD-H170/H170K/H700

SERVICE MANUAL

HCD-H170, HCD-H170K and HCD-H700 are the tuner, deck, CD and amplifier section in FH-B170/B177, FH-B170K and MHC-700 respectively.


Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "DOLBY" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.



PHOTO: HCD-H170K

AEP Model

HCD-H170/

UK Model

E Model

HCD-170/HCD-170K

Australian Model

HCD-H170

SPECIFICATIONS

Tuner section

FM stereo, FM/AM superheterodyne tuner

FM tuner section

Tuning range 87.5 — 108 MHz

Antenna FM lead antenna
(HCD-H700)
Telescopic antenna
(HCD-H170, H170K)

Antenna terminals 75 ohm unbalanced
Intermediate frequency 10.7 MHz

AM tuner section

Tuning range

AEP,UK model

MW: 531 — 1,602 kHz
LW: 153 — 279 kHz

E, Saudi Arabia, Australian models

MW: 531 — 1,602 kHz
SW: 5.95 — 17.9 MHz

Antenna AM loop antenna
External antenna terminals
Intermediate frequency 450 kHz

Amplifier section

Continuous RMS power output

25 + 25 watts (6 ohms at 1 kHz, DIN)

Peak music power output

(E, Saudi Arabia, Australian model)

240 watts (4 speakers driven)

CD Section	Model Name Using Similar Mechanism		NEW
	CD Mechanism Name		CDM13B-5BD4A
	Base Unit Name		BU-5BD4A
DECK Section	Model Name Using Similar Mechanism		NEW
	Tape Transport Mechanism	DECK A	TCM-190RA13A
	Type	DECK B	TCM-190RB22A

Inputs

For HCD-H170K

MIX MIC-1 and MIX MIC-2 (minijack):
Sensitivity 1 mV, impedance 600 ohms
PHONO (phono jack):
sensitivity 5 mV, impedance 47 kilohms

For HCD-H700

MIX MIC (minijack):
Sensitivity 1 mV, impedance 600 ohms
PHONO (phono jack):
sensitivity 5 mV, impedance 47 kilohms

For HCD-H170

MIX MIC (minijack):
Sensitivity 1 mV, impedance 600 ohms
VIDEO/AUX (phono jack): sensitivity 5 mV, impedance 47 kilohms
HEADPHONES (stereo minijack): accept headphones of 8 ohms or more.
SPEAKERS: accept impedance of 6 to 16 ohms.

Outputs

Compact disc player section

System Compact disc digital audio system

Laser Semiconductor laser ($\lambda = 780 \text{ nm}$)
Emission duration: Continuous

Laser output Max. 44.6 μW^*
* This output is the value measured at distance of about 200 mm from the objective lens surface on the Optical Pick-up Block.

Signal-to noise ratio More than 95 dB
Dynamic range More than 90 dB

Cassette deck section

Recording system

4-track 2-channel stereo

Frequency response

(DOLBY NR OFF)

60 — 13,000 Hz ($\pm 3 \text{ dB}$), using TYPE I cassette (Sony HF-S)

60 — 14,000 Hz ($\pm 3 \text{ dB}$), using TYPE II cassette

Wow and flutter

0.1% WRMS $\pm 0.3\%$ (DIN)

- continued on next page -

COMPACT DISC DECK RECEIVER
SONY®



TABLE OF CONTENTS

Speaker section

Speaker system 3 way system

Speaker units

Woofer: 13 cm dia., cone type

Tweeter: 5 cm dia., cone type

Super tweeter: 2 cm dia., dome type

Enclosure Bass reflex

Frequency range 60 Hz — 20 kHz

Sensitivity 88 dB/w/m

Rated impedance 6 ohms

Dimensions Approx. 195 x 285 x 230 mm
(7 5/8 x 11 1/4 x 9 inches)

Weight Approx. 3.0 kg (6 lb 10 oz)
net per speaker

General

Desti- nation	Power requirements	Power consumption
AEP model	220-230V AC, 50/60Hz	60 watts
UK model	240V AC, 50Hz	115 watts
E, Saudi Arabia Australian model	100V-120V or 220V- 240V AC adjustable, 50/60Hz	60 watts

Dimensions

Approx. 225 x 285 x 268 mm

(w/h/d)

(8 7/8 x 11 1/4 x 10 5/8 inches)

incl. projecting parts and controls

Weight

Approx. 6.2 kg (13 lb 11 oz)

Accessories supplied

AM loop antenna (1)

Remote commander (1)

Sony SUM-3 (NS) batteries (2)

FM lead antenna (1) (HCD-H700 only)

Speaker cords (2)

(HCD-H700, except for the UK
model)


Design and specifications subject to
change without notice.

Note

This appliance conforms with EEC

Directive 87/308/EEC regarding



interference suppression.



This appliance is classified as a
CLASS 1 LASER product.
The CLASS 1 LASER PRODUCT
label is located on the rear
exterior.

Section	Title	Page
1. SERVICING NOTES		3
2. GENERAL		5
3. DISASSEMBLY		
3-1. Case		25
3-2. Power Block		25
3-3. Main Board		26
3-4. CD Mechanism Block		26
3-5. TC Mechanism Block		27
3-6. Volume/MIC HP/Display/SW Board		27
4. MECHANICAL ADJUSTMENTS		28
5. ELECTRICAL ADJUSTMENTS		28
6. DIAGRAMS		
6-1. Semiconductor Lead Layouts		34
6-2. Circuit Boards Location		35
6-3. Printed Wiring Boards —Main Section—		37
6-4. Schematic Diagram —Main Section—		41
6-5. Schematic Diagram —Sub Section—		46
6-6. Printed Wiring Boards —Sub Section—		51
6-7. Printed Wiring Boards —Display Section—		56
6-8. Schematic Diagram —Display Section—		59
6-9. Schematic Diagram —BD Section—		62
6-10. IC Pin Description		67
7. EXPLODED VIEWS		
7-1. Case, Power Section		71
7-2. Front Panel, Main Board Section		72
7-3. MD Chassis Section		73
7-4. Mechanism Deck Section (1)		74
7-5. Mechanism Deck Section (2)		75
7-6. CD Section (1)		76
7-7. CD Section (2)		77
8. ELECTRICAL PARTS LIST		78

SAFETY-RELATED COMPONENT WARNING!!


COMPONENTS IDENTIFIED BY MARK  OR DOTTED
LINE WITH MARK  ON THE SCHEMATIC DIAGRAMS
AND IN THE PARTS LIST ARE CRITICAL TO SAFE
OPERATION. REPLACE THESE COMPONENTS WITH
SONY PARTS WHOSE PART NUMBERS APPEAR AS
SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

SECTION 1

SERVICING NOTES

MODEL IDENTIFICATION

— Specification Labels —



HCD-H170
HCD-H170K
HCD-H700

AEP model : AC : 220-230V~50/60Hz 60W


E, Saudi Arabia Australian model : AC : 100-120/220-240~50/60Hz 60W

UK model : AC : 240V~50Hz 115W

On operating voltage

Before operating the stereo system, check that the operating voltage of your system is identical with the voltage of your local power supply.

AEP model	220-230V AC, 50/60Hz
UK model	240V AC, 50Hz
Saudi Arabia Australian model	100V-120V/220V-240V AC, adjustable, 50/60Hz



Battery Installation

Install the two R6 (size AA) batteries in the supplied remote commander for remote control operation.



Battery life

About half a year of normal operation can be expected when using the Sony SUM-3 (NS) batteries.

When the batteries are exhausted, the commander cannot operate the stereo system. When this happens, replace both batteries with new ones.


To avoid battery leakage

If the commander is not to be used for a long time, remove the batteries to avoid damage caused by battery leakage and corrosion.



LASER DIODE AND FOCUS SEARCH OPERATION CHECK

1. Make POWER switch on with no disc inserted and disc table closed.
2. Confirm that the following operation is performed while observing the objecting lens.



- ① Confirm that laser beam is spread.
- ② Up and down motion of the objective lens. (3 times)

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic break-down because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body.


During repair, pay attention to electrostatic break-down and also use the procedure in the printed matter which is included in the repair parts.

The flexible board is easily damaged and should be handled with care.


NOTES ON LASER DIODE EMISSION CHECK

The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pick-up block. Therefore, when checking the laser diode emission, observe from more than 30 cm away from the objective lens.

HOW TO OPEN THE DISC TRAY WHEN POWER SWITCH TURNS OFF



- (1) Insert to ① for tapering driver, etc., and turn in the direction of arrow OFF. (Disc tray open)
- (2) Tray as come out little of front panel, pull out in the direction of arrow ② by hand.



SECTION 2 GENERAL

This section is extracted from instruction manual.

Parts Identification



Refer to the pages indicated in parenthesis for use of the buttons.

Tuner Section A

- 1 POWER ON/STANDBY switch
- 2 Remote sensor
- 3 TIMER button (100)
- 4 TIMER REC button (104)
- 5 Display window
- 6 PRESET/TIMER +/- buttons (52, 100, 104)
- 7 BAND button (48)
- 8 MEMORY/NEXT button (52, 100, 104)
- 9 STEREO/MONO button (50)
- 10 TUNING +/- buttons (48)

Amplifier Section B

- 1 MIC (microphone) 1 and 2 LEVEL controls (only for FH-B170K) (112)
- 2 MIX MIC 1 and 2 jacks (for FH-B170K) (112)
- MIX MIC jack (for other models) (112)
- 3 HEADPHONES jack (22)
- 4 ECHO LEVEL control (only for FH-B170K) (112)
- 5 MPX (multiplex) button and indicator (only for FH-B170K) (114)
- 6 VOLUME control (22)
- 7 PRESET button and indicators (62)
- 8 FUNCTION button
- 9 DBFB (Dynamic Bass Feed Back) button and indicator (22)
- 10 KARAOKE PON (vocal reduction) button and indicator (for FH-B170K) (114)
- S-SUR (simulated surround) button (for other models) (22)
- 11 EQ (equalizer ON/OFF) button (62)




134

Parts Identification


Cassette Deck Section C

- 1 Cassette holders
- 2 HIGH SPEED button (72)
- 3 CD SYNC button (86, 94, 98)
- 4 EJECT button (for deck A) (56)
- 5 DIRECTION MODE selector (56)
- 6 Tape operating buttons (for deck A and B)
 - ▶▶ (fast wind and AMS*) button (56)
 - ◀◀ (rewind and AMS*) button (56)
 - ▶: Forward play button and direction indicator (56)
 - ◀: Reverse play button and direction indicator (56)
 - : Stop button (56)
- 7 REC (recording) button
- 8 PAUSE button (56)
- 9 EJECT button (for deck B) (68)
- 10 DOLBY NR selector (56)



CD Player Section D

- 1 Disc tray (24)
- 2 CHECK button (42)
- 3 EDIT/TIME FADE button (78, 90)
- 4 PLAY MODE buttons
 - CONTINUE button (38)
 - SHUFFLE button (38)
 - PROGRAM button (40, 96)
- 5 OPEN/CLOSE button (24)
- 6 play/pause button (24)
- 7 (stop) button (24)
- 8 manual search/AMS* buttons (26, 96)
- 9 REPEAT button (32)




* AMS is the abbreviation of Automatic Music Sensor.

136

Parts Identification

E



Remote Commander **E**

- 1 CLOCK DISPLAY button (20)
- 2 TAPE function button
- 3 DECK A/B selector
- 4 CD function button
- 5 TUNER/EQ/CD selector
- 6 CHECK button (42)
- 7 TUNER function button
- 8 VIDEO function button
- 9 PHONO function button
- 10 MEMORY button (66)
- 11 DBFB button (22)
- 12 SLEEP button (110)
- 13 SYSTEM POWER button
- 14 Tape operating buttons
- 15 CD player operating buttons
- 16 CLEAR button (38)
- 17 TUNER/EQ/CD numeric buttons (28, 62)
- 18 CURSOR CONTROL buttons (64)
- 19 VOL +/- (volume control) buttons (22)
- 20 EQ button (62)

How to Use This Manual

This manual applies MHC-700 for Europe and the U.K., FH-B177 for Europe, FH-B170 for the U.S.A. and other countries and FH-B170K for other countries. The differences between them are indicated below:

Yes: Equipped		No: Not equipped	
Destination	USA	Europe and UK	Other countries
Receivable band	AM/FM	FM/LW/MW	FM/MW/SW
PHONO jack	No	Yes	No
VIDEO/AUX jack	Yes	No	Yes

Equipped antenna for FM reception
MHC-700: FM lead antenna
FH-B177, B170 and B170K: Telescopic antenna

In this manual, the illustrations of the unit are illustrated as FH-B177.

How this manual is composed

Please read the instructions in this manual referring to the illustrations.

- The letters in the illustrations correspond to those in the text: e.g. Speaker Cord Connection **A**
- The step numbers in the illustrations correspond to those in the text.
- Use the page numbers in "Parts Identification" at the end of this manual as an index to find out how to use the buttons and controls.

Overview

Tuner section

- The receivable band stations differ depending on the model where it is destined for. Please see the table in "How to Use this Manual".
- You can store up to 30 stations (for the USA model) or 40 stations (except for the USA model).

Amplifier section






- DBFB (Dynamic Bass Feedback) system reinforces bass sound.
- You can easily adjust the music to your taste by selecting from 5 factory-preset graphic equalizer settings.
- You can store up to 5 individual settings of graphic equalizer.
- You can select directly the desired program source just by pressing the operation button (BAND, PRESET/TIMER +/-, or TUNING +/-) to select the tuner, >II< to select the CD player, and <I> to select the cassette deck) on the program source equipment. (Automatic Source Selection)

CD player section

- You can enjoy listening in various playing modes.
- Edit functions allow you to program selections automatically to fit in a desired duration.

Cassette deck section

- Auto-reverse decks enable repeated playback of both sides of the cassette.
- CD synchro function enables easy recording of a CD.
- Double decks enable tape dubbing and continuous playback.



Connections

Notes on connection

- Connect the AC power cord last.
- Cord plugs and jacks are color coded. Red plugs and jacks are for the right channel (R) and white ones for the left channel (L).

Speaker Cord Connection **A**

- Strip 15 mm (5/8 inches) of the speaker cord coating from the end of the cord.
- Connect the right speaker to R, with the red cord to + and the black cord to -.
Connect the left speaker to L, with the red cord to + and the black cord to -.

To attach the speakers to the main unit – For FH-B177, B170 and B170K only **B**

- Unlock the stopper and slide the speaker so that it hooks to the system.
- Lock the stopper.

AM Loop Antenna Connection **C**

For the European and U.K. model **C-1**

For the models for other countries **C-2**


Connect the supplied loop antenna to the AM and μ terminals.

FM Lead Antenna Connection (MHC-700 only) **D**


Connect the supplied FM lead antenna to the FM 75 Ω terminal and extend horizontally.

Connections


E-1




E-2




F-1



F-2



G



For Better FM Reception E

For the European and U.K. model
E-1

Connect the outdoor FM antenna to the FM 75 Ω terminal, using 75-ohm coaxial cable and IEC standard socket connector.

For the models for other countries
E-2

Connect the outdoor FM antenna to the FM 75 Ω and h terminals, using 75-ohm coaxial cable.

For Better AM Reception F

For the European and U.K. model
F-1

For the models for other countries
F-2

Use the 6- to 15-meter (20- to 50-foot) insulated wire for connecting the terminal. Connect the h terminal to a good ground.


Important

When you use an external antenna, be sure to ground it against lightning. Never connect the ground wire to a gas pipe. Doing so is extremely dangerous.


Power Connection

Connect the supplied AC power cord to AC IN and the other end to a wall outlet.


To attach the AM loop antenna to the main unit in order to carry the unit
See the illustration. **G**



A-1



A-2



Connections

Adding Other Components to the System A

Turntable system A-1

(For the European and U.K. model)
You can connect a turntable system to the PHONO jacks. To listen to the turntable system, press FUNCTION on the front panel until "PHONO" appears on the display.

VTR A-2

(For the model for other countries)
You can connect a VTR, etc. to the VIDEO/AUX jacks. To listen to the connected equipment, press FUNCTION on the front panel until "VIDEO/AUX" appears on the display.

Changing the MW tuning interval (except for the European and U.K. model)

The MW tuning interval is preset at the factory to 10 kHz for the USA model, and 9 kHz for the models for other countries. If you use the system where the frequency allocation system is different from the preset interval, change the interval as follows:

- 1 Turn on the power.
- 2 Tune in any MW station.
- 3 Turn off the power.
- 4 Turn the power back on while pressing the TUNING + button.

To reset the interval, follow the same procedure.

Important
When the interval is changed, stored stations will be erased from the memory.

Clock Setting

Setting the Clock

Example: Set to 9:25 in the morning.

- 1 Press **TIMER** and **TIMER REC** at the same time.
- 2 Set the hour with **PRESET/TIMER -** or **+** button.
- 3 Press **MEMORY/NEXT**.
- 4 Set the minute with **PRESET/TIMER -** or **+** button.
- 5 Press **MEMORY/NEXT**.
The clock starts operating.

Information on the time







The European and U.K. model shows the time in 24-hour cycle.
The model for other countries shows the time in 12-hour cycle.
AM 12:00 = midnight
PM 12:00 = noon


When a power interruption occurs

The clock and timer settings are all erased, and "0:00" ("AM 12:00") will flash on the display.

To change the frequency display to the time display

Press **CLOCK DISPLAY** on the remote commander. The time is displayed for about 4 seconds, then the time display changes into the frequency display.





Audio Adjustment

Volume Adjustment **A**

Turn VOLUME clockwise to increase the sound level, or counterclockwise to decrease it.
(Or press VOL + or - on the remote commander.)

Sound Quality Adjustment




To reinforce bass **B**
Press DBFB*.

To activate surround effect for stereo sound **C**
(Except for FH-B170K)
Press S-SUR** during a stereo sound reproduction. This creates the atmosphere of a movie theater or concert hall. This function is not effective for a monaural sound.

(For FH-B170K)
The KARAOKE PON button is provided here. See page 114.

For personal listening **D**
Connect headphones to HEADPHONES.
No sound comes from the speakers.

*DBFB = Dynamic Bass Feedback
**S-SUR = Simulated surround



CD Playing

Playing the Entire Disc

- 1 Press **△** OPEN/CLOSE to open the tray.
Place a disc with the printed side up.
- 2 Press **▷||** (▶ on the remote commander)
The tray closes and play starts.

The display shows **a** the current track number, **b** the current INDEX number (of the track), **c** elapsed playing time of the track and **d** track numbers.



Caution on adjusting volume
Do not turn up the volume while listening to a portion with very low level inputs or no audio signals. If you do, the speakers may be damaged when a peak level portion is played.

To stop play
Press **■**.

To stop for a moment during play
Press **▷||** (|| on the remote commander).
To resume play, press it again.

To stop play and open the tray
Press **△** OPEN/CLOSE.

To play an 8 cm (3-inch) CD
Place it on the inner circle of the tray. If the disc is provided with an adaptor, first remove it. Do not put a normal CD (12 cm/5-inch) on top of an 8 cm CD.



CD Playing

Locating a Particular Selection — Automatic Music Sensor (AMS)

The AMS locates the beginning of a selection.

To locate the beginning of the current or preceding selection **A**
Press **◀◀◀** (or **▶▶▶** on the remote commander) as many times as required.

To locate the beginning of a succeeding selection **B**
Press **▶▶▶** (or **▶▶▶** on the remote commander) as many times as required.

Locating a Particular Point in a Selection

You can locate any particular point in the selection. This function works during play or pause. This operation is impossible with the remote commander.

To search while monitoring the sound

To move forward at high speed **B**
Keep **▶▶▶** depressed and release it at the desired point.

To move backward at high speed **A**
Keep **◀◀◀** depressed and release it at the desired point.

To search quickly

1 Press **▷||** to set the unit in pause mode.

2 Keep **◀◀◀** or **▶▶▶** depressed.
The search speed increases, but there is no sound. Find the desired point by observing the display.
Press **▷||** again at the desired point to play.








CD Playing

To locate a selection directly
Possible only with the remote commander

- 1 Set the TUNER/EQ/CD selector to CD.
- 2 Press the numeric button for the selection.

If the selection number is greater than 12
Use the >12 and 1 to 10 buttons. "10"
functions as the figure "0."
e.g. To play from selection number 22, press
>12, 2, 2.
To play from selection number 30, press >12,
3, 10.



CD Playing

Information display

Possible only with the remote commander.

To change the time display A

Press TIME during play.
The display changes to give you the following information.

- Elapsed playing time of the current selection
- Remaining time in a selection. If the current selection number is over 20, "--m--s" is displayed.
- Remaining time of the disc.

To display the total playing time of the disc B




Press TIME during stop.
The following appears for about 4 seconds.

- Total number of selections
- Total playing time of the disc
- Track numbers

This information appears also when you close the tray by pressing OPEN/CLOSE.

Notes on handling discs C

- To keep the disc clean, handle the disc by its edge. Do not touch the surface.
- Do not stick paper or tape onto the disc.
- Do not expose the disc to direct sunlight or heat sources such as a hot air duct, nor leave it in a car parked in direct sunlight as there can be a considerable rise in the temperature.
- After playing, store the disc in its case.



CD Playing

Playing Repeatedly -- Repeat Play

To repeat all the selections A

Press REPEAT once during play so that "REPEAT" appears in the display.

To repeat a single selection B

Press REPEAT twice while playing the desired selection so that "REPEAT 1" appears in the display.
(Operable only in normal play and delete play mode)





To cancel repeat play

Press REPEAT so that neither "REPEAT" nor "REPEAT 1" appears.

Note

Repeat play function works also during:

- shuffle play
 - delete play
 - delete shuffle play
 - program play.
- Multi-disc program play (see page 44) cannot be repeated.



CD Playing


Playing in a Random Order – Shuffle Play

This operation is impossible with the remote commander. Shuffle play function plays all selections in a random order.

- 1 Press SHUFFLE. "SHUFFLE" appears in the display.
- 2 Press DII. "CD" appears and then shuffle play starts.

To stop playing
Press ■.

To cancel shuffle play **A**
Press CONTINUE. "SHUFFLE" disappears (**A**), and play continues in normal play mode.



CD Playing

To play only the desired selections in a random order – Delete Shuffle Play

You can delete the undesired selections before or during shuffle play. This operation is possible only with the remote commander.






To delete a selection
Press the numeric buttons (**B**) for the selection you want to delete. The number of the selection and "OFF" appears in the display.

To restore a selection which you have deleted
Press the numeric buttons for that selection. The number of the selection and "ON" appears in the display.

To restore all selections which you have deleted
Press ■ during stop.

When you press REPEAT during shuffle play
After playing all the selections in a random order, shuffle play starts again in a different random order. During delete shuffle play, only the desired selections are played in a different random order.

To check the remaining time
Press TIME once to see the remaining time of the selection being played; twice to see the total remaining time of the selections to be played; once more to return to the initial display.



CD Playing

Playing Only the Desired Selections – Delete Play

You can delete the undesired selections before or during play.

To delete a selection before play

- 1 Press SHUFFLE. "SHUFFLE" appears in the display.
- 2 Press the numeric buttons for that selection. The number of the selection and "OFF" appears in the display.
- 3 Press CONTINUE. "SHUFFLE" disappears.
- 4 Press DII (or ► on the remote commander). Delete play starts.

To delete a selection during play **A**
Press CLEAR on the remote commander while that selection is being played. The number of the selection and "OFF" appears in the display and the next selection starts.

To restore all the selections which you have deleted
Press ■ during stop.

CD Playing

Playing in a Desired Order — Program Play

You can make a program for up to 24 selections in the order you want them to be played.

Programming selections directly
Possible only with the remote commander.



- 1 Press PROGRAM.
"PGM" appears in the display.
- 2 Press the numeric buttons for the desired selections in the desired order to be programmed.
To choose a number greater than 12, see page 28.
 - a Last programmed selection
 - b The order to be played
 - c Total playing time of selections
 - d Programmed selection numbers

3 Press ►.

To program selections while checking the total time
Use the [◀◀] and [▶▶] buttons (◀◀ and ▶▶ buttons on the remote commander) instead of the numeric buttons to choose the desired selections. Choose a selection with the [◀◀] and [▶▶] buttons, check the total time, and then press PROGRAM while the selection number is flashing.

To program a pause
Press II.
"P" appears and the total playing time is reset to 0.

To stop play
Press ■.
To restart the same program play, press ►.



CD Playing

To cancel the program play
Press CONTINUE.
The program is erased and the play continues in normal play mode.

To check the program
Press CHECK.
Each time you press CHECK, the number of the selection and the order to be played appear in the display. After the last selection is displayed, "CHECK END" appears on the display.

To add a selection to the end of the program
Press the numeric buttons.

To erase a selection







1 Press CHECK so that the number of the selection you wish to erase appears.

2 Press CLEAR.

To erase the entire program
Press ■ once during stop; twice during play.
The program is also erased when you turn off the system.

If "----s" is displayed
• You have programmed a selection the number of which is over 20.
• The total time has exceeded 100 minutes.

To check the remaining time
Press TIME once to see the remaining time of the selection being played; twice to see the total remaining time of the whole program; once more to return to the initial display.



CD Playing


Designating the Playing Order of Up to 6 Discs — Multi-disc Program

You can make a program by designating up to 24 selections from up to 6 discs in the order you want them to be played. At the same time, you can adjust the total playing time of the program. This function is convenient for editing tapes.

To program selections directly
Possible only with the remote commander.

- 1 Insert the first disc.
- 2 Press PROGRAM.
"PGM" appears in the display.
- 3 Press the numeric buttons for the desired selection in the desired order to be programmed.
- 4 Remove the disc and insert the second disc.
"PGM (MULTI)" and "DISC 2" appear in the display.
- 5 Repeat steps 3 and 4 to program additional selections.
Up to 24 selections from up to 6 discs can be programmed.
The total playing time for all selections appears on the time display.

To play the program
Insert the first disc and press ► (▶) on the remote commander).
When "DISC 2" appears in the display, replace the first disc with the second disc and press ►. Continue replacing the discs until the last disc. When playback of the last disc is completed, "DISC END" appears in the display. The unit returns to the initial standby condition of program play from the first disc.



CD Playing

To stop playing
Press ■.

To cancel the program play
Press CONTINUE.

To check the program
Press CHECK.
Each time you press CHECK, the number of the disc and the selection appear. After the last selection is displayed, "CHECK END" appears in the display.

To erase a selection from the end of the program
1 Insert the last disc.
2 Press CLEAR.

Each time you press CLEAR, the selections are erased from the end of the program.
If you insert a pause in your program, you cannot erase the selections programmed before the pause.




To erase the entire program
Press ■ once during stop; twice during play.

Notes on multi-disc program
• You cannot use the repeat play function.
• Do not insert a pause in your program when you want to use the CD SYNC button.

If "—m—s" is displayed
• You have programmed a selection number over 20.
• The total time has exceeded 100 minutes.

To check the remaining time
Press TIME once to see the remaining time of the selection being played; twice to see the total remaining time of the programmed selections of the disc being played; once more to return to the initial display.

To check the number of the disc inserted
Press TIME during stop.
The number of the disc appears.



Radio

The automatic tuning enables you to find a station when its signal is strong enough.
When the signal is too weak, use the manual tuning. This operation is impossible with the remote commander.

Tuning in Automatically

- 1 Press BAND repeatedly until the desired band appears.
As you press BAND, the band changes as follows:
USA model:
FM → AM
European and U.K. model:
FM → MW → LW
Model for other countries:
FM → MW → SW
- 2 Keep TUNING - or + depressed for more than 1 second.
"AUTO" appears in the display and the unit tunes in a station automatically.
- 3 Repeat step 2 until the desired station appears.



Indicator in the display

TUNED: Appears when a station of sufficient signal strength is tuned in.

STEREO: Appears when an FM stereo program of sufficient signal strength is received.

Antenna adjustment A

For FM reception, adjust the length and direction of the telescopic antenna (except for MHC-700).
For AM (MW, LW and SW) reception, find the best location for the supplied AM loop antenna.






Radio

Tuning in Manually

- 1 Press BAND repeatedly until the desired band appears.
- 2 Press TUNING - or + repeatedly until the desired station appears.

When an FM program is noisy or hard to receive
Press STEREO/MONO so that "MONO" appears in the display. There will be no stereo effect, but the reception will be improved.
Press the button again to restore the stereo effect.



Radio

Storing Stations

You can store up to 20 FM stations and 10 MW stations and 10 LW (SW) stations (for the USA model, 20 FM stations and 10 AM stations) in a desired sequence, so that you can tune in the stored station directly by entering the preset station number.




This operation is not possible with the remote commander.

- 1 Tune in the desired station.
- 2 Press MEMORY/NEXT. "MEMORY" and the preset station numbers appear in the display.
- 3 While "MEMORY" is on (for several seconds), press PRESET/TIMER - or + to select a desired preset number.
- 4 Press MEMORY/NEXT. "MEMORY" disappears, the preset number appears and the station is stored.
- 5 Repeat step 1 to 4 for each station to be stored.

If you cannot store a station successfully Press MEMORY/NEXT again so that "MEMORY" appears, and then proceed with steps 3 and 4 above. Be sure to operate while "MEMORY" is on. (about 4 seconds.)

When you have selected the wrong preset station number
Press MEMORY/NEXT again and then proceed with steps 3 and 4.

To change the preset station
Store a desired station at the desired preset number by proceeding with the above steps. The station previously preset will be erased. Erasing only is not possible.



Radio




To Tune in a Preset Station

- 1 Press BAND to select a desired band.
- 2 Press PRESET/TIMER - or + to select the desired preset number.

To tune in a preset station directly **A**

Possible only with the remote commander.

- 1 Set the TUNER/EQ/CD selector to TUNER.
- 2 Press BAND to select a desired band.
- 3 Press the numeric button to select a desired preset station number.



Tape Playback

Playback Operation

- 1 Insert a tape in deck A or B.
- 2 Press > (for front side playback) or < (for reverse side playback).

To stop playback
Press ■.

To stop for a moment during play
(Deck B only)
Press PAUSE ■.

How to select the DIRECTION MODE position

To playback one side: set it to .
To play back both sides: set it to .
To playback both decks in succession: set it to RELAY. See page 60.
The DIRECTION MODE setting is effective for both decks.

Playing back Automatically after Fast Winding - Auto Play

This function starts playback automatically from the beginning of the side after fast winding.



To start playback from the beginning of the front side
Press > while keeping << pressed.

To start playback from the beginning of the reverse side
Press < while keeping >> pressed.

When listening to the cassette recorded with the Dolby noise reduction system*
Set the DOLBY NR selector to ON. The setting is active for both decks. This system is provided with the DOLBY B NR system.

What is the Dolby NR system?
Dolby NR (noise reduction) system reduces tape hiss noise in low-level high-frequency signals. The system boosts these signals during recording and lowers them during playback.

*Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.
"DOLBY" and double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.




A



B



C



Tape Playback

Locating the Beginning of a Selection during Playback — Automatic Music Sensor (AMS)

The AMS locates the beginning of a selection by detecting the blank spaces between selections. To assure correct operation of the AMS, there must be a blank of 3 seconds or more between selections.

- 1 Press **<** or **>** to start playback.
- 2 Press **<<** or **>>** referring to the following table.



Side of the cassette being played (Indication on the display)	Next selection	Selection being played
Front side (>)	>>	<<
Reverse side (<)	<<	>>

Notes on Cassettes

To protect the recording **A**
Break off the tab on the left shoulder on the cassette side of which recording is to be protected.

To re-record the cassette **B**
Cover each slot with plastic tape.


When using a type II (CrO₂) cassette, be careful not to cover the detector slots (**B**) which are necessary for automatic tape type detection. **C**



Tape Playback



Playing Both Decks in Succession — Relay Play

Relay play always follows the sequence below regardless of where playback starts. When playback of the reverse side of the tape in deck B is completed, the following sequence continues 4 more times.



- 1 Insert recorded cassettes in both decks.
- 2 Set the DIRECTION MODE selector to RELAY.
- 3 Press **<** or **>** on either deck.

To stop relay play
Press **■**.



A



Using the Graphic Equalizer

Making Use of the Preset Equalizer Settings

When the system is shipped from the factory, 5 specially recommended settings of the graphic equalizer are stored. You can enjoy the effect of the equalizer by simply choosing from the preset settings according to the program source.

Press the desired preset equalizer setting button **A** on the remote commander by referring to the table below.

Display	Applications
1 DISCO	Gives a sound similar to a disco surrounded by hard walls.
2 POPS	Vocal sound is intensified.
3 CLASSIC	For orchestral music
4 JAZZ	For jazz
5 BGM	For background music

You can also select the preset equalizer setting by pressing PRESET on the front panel repeatedly.

When you do not want to apply the equalizer effect **A**
Press EQ so that "EQ OFF" appears on the display.

Using the Graphic Equalizer

Adjusting the Graphic Equalizer

This function allows you to adjust the sound by raising and lowering the level of specific frequency ranges. This operation is possible only with the remote commander.

- 1 Press EQ so that "EQ SET" appears in the display.
- 2 While the frequency range is flashing (for about 6 seconds), select the frequency range you wish to adjust using CURSOR CONTROL \blacktriangle or \blacktriangledown .
- 3 While the frequency range is flashing (for about 6 seconds), raise or lower the level of the frequency range with CURSOR CONTROL \blacktriangle or \blacktriangledown .






Confirming the effect of the adjustment

Press EQ.

You can compare the difference between the adjusted setting ("EQ ON" is displayed) and no equalizer effect ("EQ OFF" is displayed).

The sound you adjust

You can record the sound you have adjusted with the graphic equalizer and the S-SUR button (not supplied for FH-B170K).



Using the Graphic Equalizer








Storing Your Individual Graphic Equalizer Settings - Personal File

By storing your individual graphic equalizer setting in the Personal File, you can easily call up the setting at any time. You can store up to 5 settings. This operation is possible only with the remote commander.

- 1 Adjust the sound with the graphic equalizer and the S-SUR button (except for FH-B170K). (See pages 64 and 22.)
- 2 Press MEMORY. "FILE 1" appears and flashes.
- 3 While "FILE 1" is flashing (for about 4 seconds), press CURSOR CONTROL \blacktriangle or \blacktriangledown to select a desired Personal File.
- 4 While the selected Personal File is flashing (for about 4 seconds), press MEMORY. The selected Personal File stops flashing. The equalizer setting is stored in the selected Personal File. The setting previously stored in the file is erased and replaced by the new setting.

Calling up the setting from the Personal File

Press the desired Personal File (F-1 to F-5) button \square on the remote commander. You can also select the Personal File by pressing PRESET on the unit repeatedly.



Recording

Recording Operation (Deck B)

Use TYPE I (normal) or TYPE II (CrO₂) tapes for recording.

- 1 Insert a blank tape into deck B.
- 2 Select a program source and play it. To select the tuner, the CD player or the cassette deck, you do not have to press FUNCTION. You can select them directly by pressing the operation button (BAND, PRESET/TIMER +/- or TUNING +/-) to select the tuner, B/I to select the CD player, and \blacktriangleright or \blacktriangleleft to select the cassette deck.
- 3 Set the DIRECTION MODE selector. To record one side, set it to \blacktriangleright . To record both sides, set it to \blacktriangleleft .
- 4 Set to DOLBY NR switch to ON or OFF.
- 5 Press REC \bullet . The deck B enters the recording pause mode.
- 6 If the desired direction indicator is not illuminated, select the side to be recorded. Press \blacktriangleright (for front side recording) or \blacktriangleleft (for reverse side recording).
- 7 Press PAUSE II. The pause mode is released and recording starts.

To stop recording
Press \blacksquare .

Notes:

- Even if you set the DIRECTION MODE selector to \blacktriangleleft , recording stops at the end of the reverse side. To record on both sides, be sure to start with the front side.
- The recording level is fixed and cannot be adjusted manually.

Recording

Inserting a Blank Space during Recording



This operation is possible only with the remote commander.

- 1 Press **O** during recording at the position where the blank space is to be inserted. REC indicator flashes and the tape runs without recording. After 4 seconds, the unit enters recording pause mode.

- 2 Press **II** at the position where you want to start recording again. Recording restarts.

To make a blank of more than 4 seconds
Press **O** as long as needed. REC indicator flashes faster after 4 seconds have elapsed. The tape pauses when **O** is released.

To make a blank less than 4 seconds
Press **REC** while REC indicator is flashing.



Tape Dubbing (from deck A to B)

Dubbing the Whole Tape at High Speed

This operation is not possible with the remote commander.

- 1 Insert a recorded tape in deck A and a blank tape in deck B.


- 2 Set the DIRECTION MODE selector. To dub on one side: set it to **RELAY**. To dub on both sides: set it to **RELAY** or **RELAY**. (See "Note on DIRECTION MODE setting page 74.")

- 3 Press **HIGH SPEED**. The deck B enters recording pause mode.

- 4 Choose the same direction on both decks by pressing **<** or **>**. To dub on one side, choose **<** or **>**. To dub on both sides, choose **>**.

- 5 Press **PAUSE II**. Dubbing starts.

To stop dubbing
Press **■**.



Tape Dubbing (from deck A to B)

Note on DIRECTION MODE setting

Position	Operation
RELAY	Dubbing stops at the end of the tape.
RELAY	When the tape in one deck comes to its end of the front side, it reverses immediately regardless of the tape position in the other deck.
RELAY	When the tape in one deck reaches its end of the front side, it stops until the other tape comes to its end, and then both tape reverse together.

When dubbing starts from the reverse side in the RELAY mode

At the end of the reverse side, dubbing stops automatically.

Is it necessary to set DOLBY NR?






No. The tape in deck B is automatically recorded in the same state as the tape in deck A.

If the direction indicator on play button flashes 3 times and disappears

The tab(s) of the cassette inserted into deck B has (have) been removed. Dubbing is not possible on that cassette. Cover the slot with plastic tape. (See page 58.)


Tape Dubbing (from deck A to B)

Manual Dubbing

- 1 Press **FUNCTION** to select the cassette deck.
- 2 Insert a recorded tape  deck A and a blank tape in deck B.
- 3 Set the **DIRECTION MODE** selector.
To dub on only one side; set it to .
To dub on both sides; set it to .
- 4 Press **REC** .
The deck B enters recording pause mode.
- 5 If the desired direction indicator is not illuminated, select the side to be recorded on the deck B.
Press **>** (for front side recording) or **<** (for reverse side recording).
- 6 Press **>** or **<** on deck A.
Playback starts.
- 7 Press **PAUSE** .
Normal speed dubbing starts.

Is it necessary to set DOLBY NR?
No. The tape in deck B is automatically recording in the same state as the tape in deck A.

Is it possible to listen to program sources other than tape during dubbing?
During high speed dubbing, yes. Any program source can be selected with the FUNCTION button.
During manual dubbing, no. The source changes to the function selected with the FUNCTION button and the tape playback cannot be dubbed.



CD Recording

Fading Out at the Designated Time — Time Fade

You can have the disc play fade out at the end by designating the playing time so that the selection at the end of the tape fades out naturally without breaking abruptly in the middle. The player records the selections in the order they appear on the disc. 5 seconds before the designated time, the recording level falls gradually. At the designated time, the recording fades out and the CD player enters pause mode. This function works for both sides of the tape by designating the time once. This function works also during repeat, shuffle, and program play.

Time Fade operation

This operation is not possible with the remote commander.

- 1 Insert a blank tape into deck B.
- 2 Place a disc with the label side up, and close the tray.
- 3 Press EDIT/TIME FADE three times and display "TIME FADE".
- 4 Designate the tape length.


When you use a 46-, 54-, 60-, 74-, or 90-minute cassette tape
Press [◀◀] and [▶▶].
As you press these buttons, the minute display changes as shown in the illustration.

When you choose "HALF"
The player fades out after playing just the half of the total playing time of the disc.

When you want to specify the recording time (of one side of the tape) more accurately
Press the numeric buttons on the remote commander. (Make sure to set the TUNER/EQ/CD selector to CD.)





Example: To specify the time of 11 minutes 30 seconds, press "1", "1", "3", and "0". ("10" functions as the figure "0".)


(to be continued)



CD Recording

(continued)

- 5 Set the DIRECTION MODE selector.**
To record on one side, set it to .
To record on both sides, set it to .
- 6 Press REC ●.**
The cassette deck enters recording pause mode.
- 7 If the desired direction indicator on play button is not illuminated, select the side to be recorded.**
Press  (for front side recording) or  (for reverse side recording)
- 8 Press PAUSE II of the cassette deck and II of the CD player.**
The pause mode is released, CD playing starts, and recording starts.



CD Recording

To stop recording

Press ■ of the cassette deck and the CD player.

When playback ends

The CD player fades out and enters pause mode at the designated time. "TIME FADE B" appears in the display. The cassette deck reverses automatically if you set the DIRECTION MODE selector to □.

If you want also to record on the reverse side of the cassette, press ▶II after the tape reverses.

When playback of the reverse side ends and fades out, the player enters the pause mode and the Time Fade is canceled.




To cancel the TIME FADE function
During stop, press EDIT/TIME FADE so that "TIME FADE" disappears.

When the playback of the disc ends during Time Fade

The Time Fade function is still active. If you place another disc, the recording can be continued and will fade out when the total playing time of the discs reaches the designated time.

About the remaining time during Time Fade
When you press TIME twice, the remaining time until the designated time is displayed.

If you press [◀◀◀◀ or ▶▶▶▶] Time Fade will be canceled.



CD Recording

Recording the Entire Program on a Disc - Fade Edit

CD program playback and tape recording start simultaneously due to the Synchronized Start function. The selection at the end of the tape does not break abruptly in the middle, but fades out automatically (Fade Edit Function).

How the Fade Edit function works

The player records the selections in the order on the disc. If the tape ends in the middle of the selection, the player rewinds the tape to the beginning of that selection. Then the selection is re-recorded so that it fades out naturally at the end of the tape.

If the recording is to be continued to the reverse side, the selection that faded out on the front side is recorded again from the beginning on the reverse side.

Fade edit operation

This operation is not possible with the remote commander.

- 1 Insert a blank tape into deck B.
- 2 Place a disc with the label side up, and close the tray.
- 3 Set the DIRECTION MODE selector. To record on one side, set it to □. To record on both sides, set it to □.

(to be continued)

CD Recording

(continued)

4 Press CD SYNC.

The deck B enters recording pause mode.

5 If the desired direction indicator on play button is not illuminated, select the side to be recorded by pressing ◀ or ▶.

To record on the front side or on both sides, press ▶.
To record only on the reverse side, press ◀.

6 Press PAUSE II on deck B.

The recording starts. After about 10 seconds, the CD playback starts.

To stop recording

Press ■ of the cassette deck and/or the CD player.

Note:

When the tab on the cassette has been removed, the CD SYNC button does not operate.


Is it possible to listen to program sources other than CD during CD recording?

No. If you select another function, the CD play stops and the selected program source will be recorded.

CD Recording


A

Front side/Face avant/
Cara frontal/ 正面 /Voorkant



Reverse side / Face arrière /
Cara posterior / 反面 / Achterkant


Front side/Face avant/
Cara frontal/ 正面 /Voorkant



Reverse side / Face arrière /
Cara posterior / 反面 / Achterkant


B

Front side/Face avant/
Cara frontal/ 正面/Voorkant



Reverse side/Face arrière/
Cara posterior/ 反面/Achterkant

Front side/Face avant/
Cara frontal/ 正面/Voorkant



Reverse side / Face arrière /
Cara posterior / 反面 / Achterkant

Editing the CD for Recording

The CD player automatically edits the selections on a disc according to the tape length. There are two ways of editing: Time Edit and Just Edit.

How the Time Edit function works

The CD player selects the selections so that the total recording time of the selections is within the tape length and so that the order of the selections changes as little as possible. This function is convenient when you know the available recording length of the tape.

The player selects the selections from the first one in the disc, summing up each playing time. When the total playing time exceeds the specified tape length, the last selection is eliminated and replaced with another selection which is not longer than the remaining time. The eliminated selection is recorded on the reverse side. If you do not want to miss recording some specific selections, you can select them beforehand.





How the Just Edit function works

The CD player chooses the selections so that the total recording time of the selections is within the tape length and so that you can record as many selections as possible by changing the order of the selections. This function is convenient when you want to record as many selections as possible.

The player selects the selections so that the total playing time best fits length of side A. Then the player selects from the remaining selections to record on side B. If you do not want to miss recording specific selections, you can select them beforehand.

Note:

You can edit only the selections from track numbers 1 to 20 in the disc using the Time Edit and Just Edit.



Time Edit and Just Edit operations

This operation is not possible with the remote commander.

- 1** Insert a blank tape into deck B.
- 2** Place a disc with the label side up, and close the tray.
- 3** Press EDIT/TIME FADE and display "EDIT" (Time Edit) or "JUST EDIT".
To choose Time Edit, press EDIT/TIME FADE once.
To choose Just Edit, press EDIT/TIME FADE twice.
- 4** Designate the tape length.

When you use a 46-, 54-, 60-, 74-, or 90-minute cassette tape Press [◀◀◀] and [▶▶▶]. As you press these buttons, the minute display changes as shown in the illustration.


When you choose "HALF" during Time Edit
The player divides the selections in the disc between side A and side B without changing their order and records them so that no selection is left out.

When you choose "HALF" during Just Edit
The player programs the selections by changing their order so that the recording time of one side of the tape is half the total playing time of the disc. However, the program of side A may be a little longer than that of side B because the player distributes all the selections.

When you want to specify the recording time (of one side of the tape) more accurately
Press the numeric buttons on the remote commander. (Make sure to set the TUNER/EQ/CD selector to CD.)

Example: To specify the time of 11 minutes 30 seconds, press "1", "1", "3", and "10". ("10" functions as the figure "0".)

(to be continued)





(continued)

- 5 Press EDIT/TIME FADE.**
The selections to be recorded on one side are determined automatically. Then the display shows **5** the last selection to be recorded, **6** the programmed order, **7** total playing time, and **8** the selections to be recorded.

For recording on both sides
Press EDIT/TIME FADE again.
The selections to be recorded on the
other side are determined.

To add selections (Link function)
If there is remaining time even after programming all the selections on the disc, the LINK indication and the selection numbers that can be recorded within the remaining time flash in the display window. You can choose from these selections to add to the program. When you want to record the selections of another disc, replace the disc. The selection numbers that can be recorded flash in the same way.

- There are two ways of adding selections:
- Press the numeric buttons for the selection. (Make sure to set the TUNER/EQ/CD selector to CD). That selection is added and if there is more space, "LINK" and the selection numbers flash again.
 - Press EDIT/TIME FADE.
- All the selections that can be recorded are programmed.

- 6** Set the **DIRECTION MODE** selector.
To record on one side, set it to .
To record on both sides, set it to .


- 7 Press CD SYNC.**
The deck B enters recording pause mode.

(to be continued)

CD Recording

(continued)

8



9



8 If the desired direction indicator on play button is not illuminated, select the side to be recorded by pressing \triangleright or \triangleleft .

To record on the front side or on both sides, press \triangleright .

To record only on the reverse side, press \triangleleft .

9 Press PAUSE II button.

The recording starts. After about 10 seconds, the CD playback starts.

To stop recording

Press ■ on the cassette deck or the CD player.

Notes:

- Do not press any other buttons than those mentioned in the procedure during Time Edit or Just Edit.
- When the tab on the cassette has been removed, the CD SYNC button does not operate.

To select the desired selections preferentially

You can place priority on some selections to be recorded by pre-selecting them first using the program function of the CD player (see page 40.)

Note:

The Time Edit and Just Edit functions do not work when you program more than 20 selections on one disc.

To check the program

Press CHECK.


In the display window, "A" appears while checking the program for side A, and "B" appears while checking the program for side B.

If it takes time for programming during Just Edit

For some discs with many selections, it may take a while for programming. In that case, press ■ if you want to cancel the Just Edit operation.

To use the CD synchronized recording function with more than one disc

Use the multi-disc program function (page 44). Press the CD SYNC button each time you change the disc.



CD Recording

Programming the Selections while Checking the Total Playing Time - Program Edit

You can adjust the total playing time to the tape length.

1 Press PROGRAM.

"PGM" appears in the display.

2 Choose a desired selection to be programmed with \ll or \gg and check the time.

If satisfactory, go to the next step. If not, repeat step 2 and choose another selection.

3 Press PROGRAM.

The selected selection number is memorized.

4 Repeat steps 2 to 3 to program desired selections for side A. (Be sure that "A" is lit in the display.)

5 Press II (for the CD player) on the remote commander. "P" appears in the display and the total playing time is reset to 0. "B" lights up.

(to be continued)


7



8



9



10



(continued)

6 Repeat steps 2 to 3 to program the desired selections for side B.

7 Set the DIRECTION MODE selector. To record on one side, set it to \triangleright . To record on both sides, set it to \triangleleft .

8 Press CD SYNC.

The deck B enters recording pause mode.

9 Select the side to be recorded by pressing \triangleleft or \triangleright . To record on the front side or on both sides, press \triangleright . To record only on the reverse side, press \triangleleft .

10 Press PAUSE II of the cassette deck.

The recording starts. About 10 seconds, the CD playback starts.

To stop recording

Press ■ on the cassette deck or the CD player.

Note:

Be sure to program the selections so that the total playing time of each side does not exceed the tape length of one side.

Timer-Activated Operation

Setting the Wake Up Timer

The power can be turned on automatically so that you can wake up with music. One hour later, the power is turned off automatically. The preset timer-on time remain until you reset it or you disconnect the power cord.

Before setting the timer

Make sure the clock is set correctly. (See page 20)

- 1 Press **TIMER** for more than 2 seconds. "TIMER" and "ON" appear and the hour digits flash in the display.
- 2 Set the hour and minute of the timer-on time by pressing **PRESET/TIMER** + or -, and **MEMORY/NEXT**. The program source flashes.
- 3 Select the program source by pressing **PRESET/TIMER** + or -. As you press the button (+ or -), the source changes as follows:



To listen to the radio:


- 1 Press **MEMORY/NEXT**. The frequency display appears.
- 2 Press **BAND** to select the desired band.
- 3 Press **PRESET/TIMER** + or - to select the desired selection.

To listen to a tape: go to step 6.

To listen to a compact disc:

- 1 Press **MEMORY/NEXT**. The selection number display appears.
- 2 Press **PRESET/TIMER** + or - to select the desired selection. (only from track numbers 1 to 20)


(to be continued)



Timer-Activated Operation

(continued)

- 4 Press **MEMORY/NEXT**. The preset items appear sequentially.
- 5 Prepare the program source by inserting a disc or a tape.
 - For listening to the radio: You do not have to tune in the station.
 - For listening to a tape: Insert the tape in deck B.
- 6 Press **POWER** to turn off the system. At the timer-on time, the system turns on automatically.



Timer-Activated Operation

Setting the Recording Timer


The power can be turned on and off automatically so that you can record a radio program while you are out. The preset timer-on and -off times function only once.

Before setting the timer

- Make sure the clock is set correctly. (See page 20).
- Be sure to insert a cassette tape that is long enough.

- 1 Press **TIMER REC** for more than 2 seconds. "TIMER REC" and "ON" appear and the hour digits flash on the display window.
- 2 Set the hour and minute of the timer-on time by pressing **PRESET/TIMER** + or -, and **MEMORY/NEXT**. "OFF" appears and the hour digits flash again.
- 3 Set the hour and minute of the timer-off time by pressing **PRESET/TIMER** + or -, and **MEMORY/NEXT**. The frequency display flashes.


(to be continued)



Timer-Activated Operation

(continued)

- 4 Press BAND and PRESET/TIMER + or - to tune in the desired preset station.
- 5 Press MEMORY/NEXT. The preset items appear sequentially.
- 6 Insert a cassette in deck B.
- 7 Set the DIRECTION MODE selector. To record on one side, set it to . To record on both sides, set it to .
- 8 Set the DOLBY NR to ON or OFF.
- 9 Press POWER to turn off the system. Make sure that "TIMER REC" and "TUNER" are displayed. At the timer-on time, the system turns on automatically.



Timer-Activated Operation

To change the time and program

- 1 Press TIMER (or TIMER REC for timer recording) for more than 2 seconds.
- 2 Press MEMORY/NEXT until the item to be changed flashes.
- 3 Press PRESET/TIMER + or - to change that item.
- 4 Press MEMORY/NEXT until the preset items appear sequentially.

When you do not want to use the timer program
Press TIMER (or TIMER REC) so that "TIMER" (or "TIMER REC") disappears.

When the power is already on at the preset time
The program source automatically changes to the preset one, even if you are playing another program source. However, when you have preset the recording timer, recording will not start even though the station is tuned in. Be sure to turn off the power before the preset time for timer recording.

Important

On the recording side of a tape during timer recording
Playback or recording always starts from the front side. When you want to record on only one side, be sure that the side you want to record on is facing you when you insert it.

Sleep Timer Operation



By setting the sleep timer, the system power can be turned off after the preset duration (up to 90 minutes). This operation is possible only with the remote commander.


- 1 Play a desired program source.

- 2 Press SLEEP to select the desired duration in minute. As you press SLEEP, the indication changes as follows:
90 → 80 → ... → 10 → ...


To turn off the system before the system is turned off by the sleep timer
Press POWER.

To check the remaining time before the sleep timer turns off the system
Press SLEEP once, and the remaining time appears. The display returns to the previous indication automatically after several seconds.





FH-B170K



2



3




4



5



6



Microphone Mixing

Mixing Operation

1 Turn down the MIC 1 and 2 LEVEL controls completely and connect microphones to the MIX MIC 1 and MIC 2 jacks. (only for FH-B170K) Connect a microphone to the MIX MIC jack. (for other models)

2 Press FUNCTION to select program source and play it.

3 Sing or speak into the microphone(s).

4 (only for FH-B170K) Adjust the microphone volume level with the MIC 1 and/or 2 LEVEL control(s).

5 (only for FH-B170K) Adjust the ECHO LEVEL control.

6 Adjust the VOLUME control.

When the mixing is over Be sure to disconnect the microphone(s).

Recording the sound mixed with a source

- 1 Mix the sound as described above.
- 2 Insert a tape in deck B.
- 3 Start recording.


Recording from a microphone only

- 1 Press FUNCTION to select the CD player. If a CD is being played, press ■ to stop playing.
- 2 Start recording.

When only one microphone is used (for FH-B170K)

Connect it to the MIX MIC 1 jack and turn down the MIC 2 LEVEL completely.

To stop howling (acoustic feedback) Placing the microphone too close to the speakers may cause howling. Move the microphone away from the speakers or change the direction it faces.



FH-B170K



Singing along (FH-B170K only)

Reducing the Vocals of a disc/tape - Vocal Reduction

You can sing with any desired stereo source by pressing the KARAOKE PON button which minimizes the singer's voice.

To reduce the vocal

Press the KARAOKE PON button so that the indicator turns on.

To cancel the vocal reduction

Press the button again so that the indicator turns off.

Notes on the vocal reduction

- Utilize stereo recorded sources. Not only would the singer's voice be reduced, but instrumental sounds may also be reduced with monaural recorded sources.
- The singers' voice may not be reduced completely for the following.
 - Stereo recorded sources containing only few instruments
 - Duet
 - Sources with strong echoes and chorus
 - Sources with singer's voice deviating from the center
 - Sources with singer's voice with extreme soprano or tenor
- When vocal reduction is used, the play sound will be monaural.

Singing Along with Multiplex Tapes

This feature can be made use of when you enjoy singing-along with microphones connected to the unit, while playing back a multiplex tape.

- To enjoy singing along, press MPX (multiplex) so that the indicator is turned on. You can hear only instrumental music and your voice through the microphone without recorded voice.
- To hear both instrumental music and recorded voice, press MPX again so that the indicator is turned off.

What is a multiplex tape?

Instrumental music and vocals were recorded respectively on the left channel and on the right channel. Therefore, when playing back a tape instrumental music comes from the left speaker and vocals come from the right speaker separately.


Maintenance

Cleaning the Heads and the Tape Paths A

Clean after every 10 hours of operation and before recording for optimum record/playback quality.

- 1 Press EJECT ▲ to open the cassette holders.
- 2 Slightly moisten the tip of a cotton swab with cleaning fluid or alcohol.
- 3 Wipe the parts shown in the illustration:
 - a Capstan
 - b Erase head
 - c Record/playback head
 - d Pinch roller

Do not insert a cassette until cleaned areas are completely dry.



B



Demagnetizing the Heads

After 20 to 30 hours of use, it is necessary to remove residual magnetism built up on the head using any commercially available demagnetizer. For demagnetizing procedure, refer to the instruction manual of the demagnetizer.

Cleaning Discs B

When a disc becomes dirty, clean it with a cleaning cloth. Wipe the disc from the center out.

Do not use solvents such as benzene, thinner, commercially available cleaners, or anti-static spray intended for analog discs.


Cleaning the Cabinet

Use a soft cloth slightly moistened with mild detergent solution.


3-1. CASE




3-3. MAIN BOARD




3-4. CD MECHANISM BLOCK



3-5. TC MECHANISM BLOCK



3-6. VOLUME/MIC HP/DISPLAY/SW BOARD



SECTION 4 MECHANICAL ADJUSTMENTS

PRECAUTION

1. Clean the following parts with a denatured alcohol-moistened swab :

record/playback head	pinch roller
erase head	rubber belt
capstan	idler
2. Demagnetize the record/playback head with a head demagnetizer.
(Head demagnetizer do not approach for the erase head.)
3. Do not use a magnetized screwdriver for the adjustment.
4. After the adjustments, apply suitable locking compound to the parts adjusted.
5. The adjustment should be performed with the rated power supply voltage unless otherwise noted.

• Torque Measurement

Torque	Torque meter	Meter reading
Forward	CQ-102C	35 to 60g • cm (0.49 to 0.83oz • inch)
Forward back tension	CQ-102C	2 to 6g • cm (0.028 to 0.08oz • inch)
Reverse	CQ-102RB	35 to 60g • cm (0.49 to 0.83oz • inch)
Reverse back tension	CQ-102RB	2 to 6g • cm (0.028 to 0.08oz • inch)
FF/REW	CQ-201B	70 to 110g • cm (0.98 to 1.52oz • inch)

• Timer Test Mode

When BAND, SHIFT and PRESET/TIMER+ buttons are pressed at the same time the following time test operation is performed. After the operation, it becomes in the system reset mode. Take care that the frequency preset to the tuner is initialized.

- 1) POWER OFF
- 2) Timer set

Clock	AM10: 23
Timer ON	AM10: 24
Timer OFF	AM10: 31
Function	TUNER
- 3) FL tube display (FL1100)

All light

↓ for 2 seconds

"AM 10: 23"

↓ for 0.5 second

"AM 10: 24"

↓ for 0.5 second

"TUNER" ← POWER ON

↓ for 2 seconds

Last channel

↓ for 1 second

"AM 00: 00" flashing ← POWER ON
- 4) Finish

SECTION 5 ELECTRICAL ADJUSTMENTS

DECK SECTION

1. The adjustment should be performed in the publication.
(Be sure to make playback adjustment at first.)
2. The adjustment and measurement should be performed for both L-CH and R-CH.
 - Switch position
DOLBY NR switch : OFF

• Test Tape

Tape	Contents	Use
P-4-A100	10kHz, -10dB	Head Azimuth Adjustment
P-4-L300	315Hz, 0dB	Level Adjustment
WS-48B	3kHz, 0dB	Tape Speed Adjustment


Record/Playback Head Azimuth Adjustment

DECK A


DECK B

Procedure :

1. Forward Playback Mode
Reverse Playback Mode





- Turn the adjustment screw for the maximum output levels. If these levels do not match, turn the adjustment screw until both of output levels match together within 1dB.



3. Playback Mode


test tape
P-4-A100
(10kHz, -10dB)



- Change the review playback mode and repeat the steps 1 to 3.
- After the adjustment, lock the adjustment screw with suitable locking compound.

Adjustment Location :

—record/playback head (deck A and B)




Tape Speed Adjustment DECK A DECK B

Procedure :

- Perform high speed adjustment before normal speed adjustment.

Mode : playback

test tape
WS-48B
(3kHz, 0dB)



Speed	Deck	Adjustment	Frequency counter
※ High	A	RV72A	5,970 to 6.030Hz
	B	RV72B	
Normal	A	RV71A	2,985 to 3,015Hz
	B	RV71B	

※ Continue to press HIGH SPEED DUBBING switch (S1523) in playback mode : High speed playback.

Frequency difference between the beginning and the end of the tape should be within $\pm 1.5\%$.


Adjustment Location: MD-A and MD-B boards.

Playback Level Adjustment DECK A DECK B

Procedure :

Mode : playback

test tape
P-4-L300
(315Hz, 0dB)



Deck A is RV11A (L-CH) and RV21A (R-CH), Deck B is RV11B (L-CH) and RV21B (R-CH) so that adjustment within adjustment level as follows.

Adjustment Level :

LINE OUT level : -8.2dB to -7.2dB (0.301 to 0.338V)

Level Difference between Channels : within 1dB


Confirm the DOLBY OUT level does not change in playback mode while changing the mode from playback to stop several times.

Adjustment Location : MD-A and MD-B boards


Record Bias Adjustment **DECK B**

Procedure :

1. record mode



2. playback mode



Confirm playback the signal recorded in step 1 become adjustment level as follows.

If these levels do not adjustment level, adjustment the RV12 (L-CH) and RV22 (R-CH) to repeat step 1 and 2.


Adjustment level : Playback output of 315Hz to playback output of 10kHz : -0.5dB to 0.5dB.

Adjustment Location : MD-B board


Record Level Adjustment **DECK B**

Procedure :

1. record mode



2. playback mode



Confirm playback the signal recorded in step become adjustment level as follows.

If these levels do not adjustment level, adjustment the RV201 (L-CH) and RV301 (R-CH) to repeat step 1 and 2.


Adjustment Level :

LINE OUT level : -23.8dB \pm 0.5dB (29 to 33.4mV)


Adjustment Location : main board

Adjustment Location :

Mechanism deck - rear side -



sub board - component side -





Note : As a front-end (FE1) is difficult to repair if faulty, replace it with new one.

TUNER SECTION

FM SECTION ADJUSTMENTS

Setting :



FM Discriminator Alignment (NULL Check)

Band : FM

Procedure :

1. Supply a 1mV (60dBμ) 98MHz signal from the ANTENNA terminal.
2. Tune the set to 98MHz.
3. Adjust IFT82 for 0V reading on the VOM.

Note : FM tuned indication lighting level adjustment should be made after FM discriminator alignment.

Adjustment Location: main board

FM Tuned Indication Lighting Level Adjustment

Band : FM


Procedure:

1. Supply a 24μV (25dBμ) 98MHz signal from the ANTENNA terminal.
2. Tune the set to 98MHz.
3. Adjust RV81 so that the **TUNED** light up.

- Repeat the procedures in each adjustment several times, and the frequency coverage and tracking adjustments should be finally done by trimmer capacitors.

AM SECTION ADJUSTMENTS

Setting :



MW Tuned Indication Lighting Level Adjustment

Band : MW

Procedure:

1. Set loop antenna A so that the loop antenna, B input level becomes 0.45mV (55dBμ)
2. Tune the set to 999kHz.
3. Adjust the RV82 so that the **TUNED** light up.

SW OSC Voltage Adjustment

Band : SW

Procedure :

1. Connect the VOM to TP (OSC).
2. Tune the set to 5.95MHz.
3. Adjust T2 for 0.9 to 1.1V reading on the VOM.
4. Tune the set to 17.90MHz.
5. Adjust CT22 for 8.3 to 8.7V reading on the VOM.

SW Tracking Adjustment


Band : SW

Procedure :

1. Connect the VOM to speaker terminal.
2. Adjust for a maximum reading on VOM.

Signal generator and Set frequency	Adjustment part
7.0MHz	T1
17.0MHz	CT21

Adjustment Location : main board —component side—




CD SECTION

Note :

1. CD Block basically constructed to operate without adjustment. Therefore, check each item in order given.
2. Use YEDS-18 disc (3-702-101-01) unless otherwise indicated.
3. Use the oscilloscope with more than 10MΩ impedance.
4. Clean an object lens by an applicator with neutral detergent when the signal level is low than specified value with the following checks.


S Curve Check



Procedure :

1. Connect oscilloscope to test point TP (FEO) on BD board.
2. Connect between test point TP (FES) and TP (VC) by lead wire.
3. Turned Power switch on and actuate the focus search. (actuate the focus search when disc table is moving in and out.)
4. Check the oscilloscope waveform (S curve) is symmetrical between A and B. And confirm peak to peak level within 3±1Vp-p.

S curve waveform




5. After check, remove the lead wire connected in step 2.

Note : • Try to measure several times to make sure that the ratio of A : B or B : A is more than 10 : 7.

- Take sweep time as long as possible and light up the brightness to obtain best waveform.

ation : main board —component side—




CD SECTION

Note :


1. CD Block basically constructed to operate without adjustment. Therefore, check each item in order given.
2. Use YEDS-18 disc (3-702-101-01) unless otherwise indicated.
3. Use the oscilloscope with more than 10M Ω impedance.
4. Clean an object lens by an applicator with neutral detergent when the signal level is low than specified value with the following checks.

S Curve Check



Procedure :


1. Connect oscilloscope to test point TP (FEO) on BD board.
2. Connect between test point TP (FES) and TP (VC) by lead wire.
3. Turned Power switch on and actuate the focus serch. (actuate the focus serch when disc table is moving in and out.)
4. Check the oscilloscope waveform (S curve) is symmetrical between A and B. And confirm peak to peak level within $3 \pm 1V_{p-p}$.



5. After check, remove the lead wire connected in step 2.

Note : • Try to mesure several times to make sure that the ratio of A : B or B : A is more than 10 : 7.
• Take sweep time as long as possible and light up the brightness to obtain best waveform.

RF Level Check




Procedure :


1. Connect oscilloscope to test point TP (RF) on BD board.
2. Turn Power switch on.
3. Put disc (YEDS-18) in and playback.
4. Confirm that oscilloscope waveform is clear and check RF signal level is correct or not.

Note :

Clear RF signal waveform means that the shape "◇" can be clearly distinguished at the center of the waveform.




E-F Balance Check



Procedure:

1. Connect test point TP (ADJ) to ground and TP (TEO) to TP (VC) with lead wire.
2. Connect oscilloscope to test point TP (TEO) on BD board.
3. Turn Power switch on.
4. Put disc (YEDS-18) in and playback.
5. Confirm that the osilloscope waveform is symmetrical on the top and bottom in relation to 0V, and check this level.




6. Remove the lead wire connected in step 1.

RF PLL Free-run Frequency Check

Procedure :

1. Connect frequency counter to test point (PCLK) with lead wire.
2. Turn Power switch on.
3. Confirm that reading on frequency counter is 4.3218MHz.




Focus/Tracking Gain

This gain has a margin, so even if it is slightly off. There is no problem.



Therefore, do not perform, this adjustment.

Please note that it should be fixed to mechanical center position when you moved and do not know original position.


Adjustment Locations :
[BD board]




6-1. SEMICONDUCTOR LEAD LAYO




GP1U59XB




LA6525M



M5218AFP



PST572E




SECTION 6 DIAGRAMS

RF PLL Free-run Frequency Check

Procedure :

1. Connect frequency counter to test point (PCLK) with lead wire.



2. Turn Power switch on.
3. Confirm that reading on frequency counter is 4. 3218MHz.


Focus/Tracking Gain

This gain has a margin, so even if it is slightly off. There is no problem.


















Therefore, do not perform, this adjustment.

Please note that it should be fixed to mechanical center position when you moved and do not know original position.



Adjustment Locations : [BD board]




6-1. SEMICONDUCTOR LEAD LAYOUTS




6-2. CIRCUIT BOARDS LOCATION




• IC801 STK-4132MK2




• IC201, 251 M5229P



• IC231, 236 MC14066BCP



• IC406 LB1639




- Semiconductor Location

Ref. No.	Location	Ref. No.	Location
D21 (*2)	C-4	Q5 (*2)	B-3
D81	H-7	Q7 (*1)	D-9
D202	J-8	Q7 (*2)	D-4
D205 (*3)	F-12	Q8 (*1)	D-9
D206	F-11	Q8 (*2)	D-4
D207 (*3)	C-11	Q9 (*1)	B-8
D208	G-8	Q9 (*2)	B-3
D401	H-21	Q10 (*1)	B-9
D801	D-23	Q10 (*2)	B-4
D810	J-25	Q11 (*2)	E-4
D901	B-26	Q51 (*1)	D-2
D902	B-26	Q51 (*2)	D-7
D904	E-22	Q52 (*1)	D-2
D905	B-24	Q52 (*2)	D-7
D906	B-25	Q53 (*1)	D-6
D907	C-24	Q54 (*1)	D-6
D909	E-21	Q101	G-10
D910	C-23	Q102	F-9
D914	C-11	Q103	I-9
D915	B-22	Q201	F-16
D916	B-22	Q202	H-10
D921	F-12	Q231 (*3)	E-12
D923	B-27	Q232	E-11
D924	C-27	Q233	H-10
IC51	F-7	Q234	J-8
IC81	H-8	Q235 (*3)	B-12
IC201	G-17	Q236 (*3)	C-12
IC231	E-13	Q237	I-9
IC232	D-12	Q251	D-17
IC233	F-17	Q252	H-10
IC234	F-17	Q301	D-14
IC236 (*3)	C-12	Q302	D-13
IC251	E-18	Q901	E-27
IC301 (*1)	C-18	Q903	E-26
IC302	D-15	Q904	E-27
IC406	H-21	Q905	E-21
IC801	E-25	Q906	E-22
IC901	C-26	Q907	E-21
IC902	E-14	Q908	C-24
IC9001	B-10	Q911	E-14
		Q999	I-7
Q1 (*1)	D-8	Q8001	D-21
Q1 (*2)	D-3	Q9001	B-11
Q4 (*1)	E-9	Q9002	B-11
Q4 (*2)	E-4	Q9003	B-10
Q5 (*1)	B-8		

(*1): H170/AEP, H700 MODEL
(*2): H170/E, EA, AUS, H170K MODEL
(*3): H170K MODEL


- EA : Saudi Arabia
- AUS : Australian





• IC81 LA1851N



6-3. PRINTED WIRING BOARDS – MAIN SECTION –

- See page 34, 35 for Semiconductor Lead Layouts and Circuit Boards







1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	----











6-5. SCHEMATIC DIAGRAM – SUB SECTION – •See page 64 for Wave forms and Note. •See page 67 for IC Pin Descriptions




forms and Note. *See page 67 for IC Pin Description.

5 6 7 8 9 10 11 12 13 14 15 16







[MD-A BOARD]




[LEAF SW (A) BOARD] (A DECK) TCM-190 RAI3A




[MD-B BOARD]




[LEAF SW (B) BOARD] (B DECK) RB22A






• IC Block Diagrams

• IC601 M50197FP



• IC1004 CD4052BCM




• Semiconductor Location


Ref. No.	Location
D101	D-4
D201	D-3
D601 (*1)	D-7
D602 (*1)	E-8
D1001	F-21
D1002	D-21
D1004	F-13
D1005	F-21
D1007	C-20
D1030	D-19
D1031	D-18
D1051	F-20
D1052	E-19
D1053	E-19
D1054	E-19
D1055	D-18
D1057 (*1)	E-16
D1058	D-21
D1059	C-21
IC101	B-4
IC102	C-4
IC103	D-4
IC106	F-14
IC201	H-4
IC202	C-3
IC203	H-3
IC301	G-3
IC302	G-2
IC501	C-16
IC601 (*1)	E-8
IC602	D-10
IC1001	G-15
IC1002	G-21
IC1003	C-19
IC1004	D-20
IC1005	F-13
IC1006	G-18
IC1007	G-19
IC1008	D-21
Q101	B-3
Q201	E-4
Q601	D-16
Q602	F-9
Q603 (*1)	F-9
Q1001	D-21
Q1002	D-20
Q1003	D-20
Q1004	D-21
Q1051	E-13

(*1): H170K MODEL


6-7. PRINTED WIRING BOARDS - DISPLAY SECTION - • See page 34, 35 for Semiconductor Lead Layouts and Circuit Boards Location.




7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----





6-8. SCHEMATIC DIAGRAM - DISPLAY SECTION - •See page 64 for Wave forms and Note.






6-9. SCHEMATIC DIAGRAM - BD SECTION - •See page 67 for IC Pin Description.





• Wave forms



Note on Schematic Diagram :

- All capacitors are in μF unless otherwise noted. pF : μF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $\frac{1}{4}$ W or less unless otherwise specified.
- Δ : internal component.
- --- : fusible resistor.

Note :The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.


- --- : B + Line.
- --- : B - Line.
- --- : adjustment for repair.
- Voltage and waveforms are dc with respect to ground under no-signal conditions.
- no mark : PB
- Voltages are taken with a VOM (input impedance 10 M Ω). Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with an oscilloscope. Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path.
 - --- : FM
 - --- : REC
 - --- : AF
 - --- : MIC
 - --- : PB
 - --- : CD
 - --- : CD AF

Note on Mounting Diagram :


- --- : Parts extracted from the component side.
- \bullet : Through hole.
- --- : Pattern on the side which is seen.
- --- : Pattern of the rear side.

• IC Block Diagrams


• IC201 CXD2500AQ




• IC102 LA6525M




• IC203 CXD2554M



• IC101 CXA1372AQ



• IC103 M54641FP



6- 10. IC PIN DESCRIPTION

• IC401 Deck Controller (M50946- 251FP)

Pin No.	Pin Name	I/O	Symbol	Description																																				
1	P62		G	GND																																				
2	P61		G	GND																																				
3	P60		G	GND																																				
4	P47		G	GND																																				
5	P46		G	GND																																				
6	AN5	I	B HALF	Deck B record prevention claw A, B detection input (Analog) <table><tr><td>Volgate (V)</td><td>1V</td><td>1.9V</td><td>2.8V</td><td>3.9V</td><td>5V</td></tr><tr><td>Harf</td><td>ON</td><td>ON</td><td>ON</td><td>ON</td><td>OFF</td></tr><tr><td>E. PROOF A</td><td>OFF</td><td>ON</td><td>OFF</td><td>ON</td><td>OFF</td></tr><tr><td>E. PROOF B</td><td>ON</td><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	Volgate (V)	1V	1.9V	2.8V	3.9V	5V	Harf	ON	ON	ON	ON	OFF	E. PROOF A	OFF	ON	OFF	ON	OFF	E. PROOF B	ON	ON	OFF	OFF	OFF												
Volgate (V)	1V	1.9V	2.8V	3.9V	5V																																			
Harf	ON	ON	ON	ON	OFF																																			
E. PROOF A	OFF	ON	OFF	ON	OFF																																			
E. PROOF B	ON	ON	OFF	OFF	OFF																																			
7	AN4	I	KEY Y	KEY input <table><tr><td>Volgate (V)</td><td>0</td><td>0.3</td><td>0.7</td><td>1.2</td><td>1.7</td><td>2.3</td><td>2.8</td><td>3.4</td><td>4.0</td><td>4.5</td><td>5.0</td></tr><tr><td>KEY Y</td><td>B■</td><td>B■</td><td>B▶</td><td>B◀</td><td></td><td>A◀</td><td>A▶</td><td></td><td></td><td>RELAY</td><td>OFF</td></tr><tr><td>KEY X</td><td>A■</td><td>A▶</td><td>A◀</td><td>A◀</td><td>B◀</td><td>B●</td><td>B</td><td>CD</td><td></td><td></td><td></td></tr></table>	Volgate (V)	0	0.3	0.7	1.2	1.7	2.3	2.8	3.4	4.0	4.5	5.0	KEY Y	B■	B■	B▶	B◀		A◀	A▶			RELAY	OFF	KEY X	A■	A▶	A◀	A◀	B◀	B●	B	CD			
Volgate (V)	0	0.3	0.7	1.2	1.7	2.3	2.8	3.4	4.0	4.5	5.0																													
KEY Y	B■	B■	B▶	B◀		A◀	A▶			RELAY	OFF																													
KEY X	A■	A▶	A◀	A◀	B◀	B●	B	CD																																
8	AN3	I	KEY X																																					
9	AN2	I	AMS IN	AMS signal input																																				
10	P41	O	L MUTE	Line mute output																																				
11	P40	O	R MUTE	mute output																																				
12	P37	O	RELAY (B MD)	REC/PB change relay output																																				
13	P36	O	R/P	Dolby IC REC/PB select output																																				
14	P35	O	EQ70	Playback EQ output for playing deck																																				
15	P34	O	SEL A/B	Dolby IC PB input Deck A/B select output																																				
16	P33	O	AMS A/B	AMS AMP input Deck A/B select output																																				
17	P32	I	AU BUS	AUDIO BUS input																																				
18	P31	O	BIAS	Bias oscillation output																																				
19	P30	O	AUB OUT	AUDIO BUS output																																				
20	INT1	I	A UBUS	AUDIO BUS normal input																																				
21	NC	—	—	—																																				
22	NC	—	—	—																																				
23	NC	—	—	—																																				
24	CNVSS		CNVSS	GND																																				
25	RESET	I	RESET	Microcomputer reset input																																				
26	XIN	I	XIN	Clock input (4MHz)																																				
27	Xo	O	Xo	Clock output (4MHz)																																				
28	Φ	O	Φ	Not used (open)																																				
29, 65	Vss		Vss	GND																																				
30	P57	I	PW IN	POWER OFF detection input																																				
31	P56	I	A STOP	Deck A STOP switch input																																				
32	P55	I	A HALF	Deck A Half switch input																																				
33	P54	I	A SHUT	Deck A Reel table signal input																																				
34	P53	I	A70 U	Deck A TYPE II switch input																																				
35	P52	I	B STOP	Deck B STOP switch input																																				
36	P51	I	B SHUT	Deck B Reel table signal input																																				
37	P50	I	B70 U	Deck B TYPE II switch input																																				
38	NC	—	—	—																																				
39	P17	O	ARM 3	Deck A Reel Motor control out																																				
40	P16	O	ARM 2	Deck A Reel Motor control out																																				

Pin No.	Pin Name	I/O	Symbol	Description
41	P15	O	ARM 1	Deck A Reel Motor control out
42	P14	O	BRM 3	Deck B Reel Motor control out
43	P13	O	BRM 2	Deck B Reel Motor control out
44	P12	O	BRM 1	Deck B Reel Motor control out
45	P11	O	H/L	Capstan motor speed select
46	P10	O	A CM	A Capstan motor ON/OFF
47	P07	O	B CM	B Capstan motor ON/OFF
48	P06	I	BS/ASCH	Deck A Reel table/BS signal input
49	P05	I	A • P/BSCH	Deck B Reel table/A • P signal input
50	P04	O	A ◁	Deck A RVS LED output
51	P03	O	A ▷	Deck A FWD LED output
52	P02	O	A PLAY	Deck B RVS/FWD LED control output
53	P01	O	DUB H	High Speed Dubbing LED output
54	P00	O	DUB N	Normal Speed Dubbing LED output
55	NC	—	—	—
56	P27	O	CD SYNC	Auto CD Synchro LED output
57	P26	O	B ◁	Deck B RVS LED output
58	P25	O	B ▷	Deck B FWD LED output
59	O24	O	B PLAY	Deck B RVS/FWD LED control output
60	P23	O	B PAUSE	Deck B PAUSE LED output
61	P22	O	B ●	Auto CD Synchro LED output
62	P21	O	PASS	PASS amplifier switch output
63	P20	I	TEST	Electrical adjustment test mode setting
64	NC	—	—	—
66	NC	—	—	—
67	Vcc		Vcc	POWER 5 ± 0.5V
68	AVss		AVss	Analog system GND
69	VREF	I	VREF	Analog system reference voltage input
70	D • A		D • A	GND
71	PWM		—	GND
72	P63		—	GND

[TEST MODE]

When making pin ③ low (connect TP1 to ground with jumper wire), following function operates.

1. Sourec monitor

Release the line mute while recording.

● IC202 CD Controller (μ PD75116GF)

Pin No.	Pin Name	I/O	Description
1	Not Used	O	OPEN
2	Not Used	O	OPEN
3	DPCLK	O	Display data transmission clock output
4	LATCH	O	Serial data latch pulse output for digital filter CXD2554M
5	SHIPT	O	Serial clock output for digital filter CXD2554M
6	AFT	O	Serial clock output for digital filter CXD2554M
7	RESET	I	System reset input terminal (LOW ACTIVE)
8	X2	I	System clock input 4.0MHZ
9	X1	I	System clock input 4.0MHz
10	DFCTSW	O	For focus in till spindle kick is ON except then is OFF.
11	AMUTE	O	Muting ON/OFF output
12	BSOUT	O	Audio bus output
13	AFADJ	I	Teast mode input, and on time POWER "L" is test move ment of every kind
14	LDON	O	Laser diode ON/OFF output
15	XKT	O	Serial data latch pulse output for CXD2500AQ
16	CLK	O	Serial data output for CXD2500AQ
17	DATA	O	Serial data output for CXD2500AQ
18	Not Used	I	GND
19	ADJ	I	Test mode input, "L" is GFS no check.
20	GFS	I	GFS OK/NO Good input
21	FOK	I	Focus OK/NO Good input
22	Not Used	O	OPEN
23	Not Used	O	OPEN
24	LODOUT	O	Disc tray loading-out output
25	LODIN	O	Disc tray loading-out output
26	VSS	I	GND
27	INSW	I	Disk tray clamp-end input
28	OUTSW	I	Disk tray open-end input
29	(TIMER)	I	Timer start input
30	BSIN	I	Audio bus input
31	Not Used	I	GND
32	Not Used	I	GND
33	Not Used	I	GND
34	Not Used	I	GND
35	Not Used	I	GND
36	Not Used	I	GND
37	SENS	I	SENS input, and the state input of every kind from CXD2500Q
38	TIMER	I	(NOT-PLAY)
39	D/F 16BT	I	(NOT-PLAY)
40	Not Used	I	GND
41	SUBQ	I	Q data serial input from CXD2500AQ
42	Not Used	O	OPEN
43	SQCLK	O	Sub-code Q data read-in clock output for CXD2500AQ
44	SCOR	I	Sub-code synchro S0 and S1 detect input
45	Not Used	O	OPEN
46		O	
47	Not Used	O	OPEN
48	Not Used	O	OPEN
49	Not Used	I	OPEN
50	Not Used	I	OPEN

Pin No.	Pin Name	I/O	Description
51	Not Used	I	OPEN
52	Not Used	I	OPEN
53	Not Used	O	OPEN
54	Not Used	O	OPEN
55	Not Used	O	OPEN
56	Not Used	O	OPEN
57	Not Used	I	+ 5V
58	VDD	I	+ 5V
59	DPDAT3	O	OPEN
60	DPDAT2	O	OPEN
61	DPDAT1	O	OPEN
62	DPDAT0	O	OPEN

EXPLODED VIEWS



NOTE:

- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Color Indication of Appearance Parts
Example :
KNOB, BALANCE (WHITE)...(RED)

↑
Parts color

↑
Cabinet's color

- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list is given in the last of this parts list.

The components identified by mark  or dotted line with mark  are critical for safety.
Replace only with part number specified.


- EA : Saudi Arabia

AUS : Australian

7-1. CASE, POWER SECTION

▲ A : POWER board (See page 72)

● B : POWER TRANSFORMER board
(See page 73)




Note: The components identified by mark or dotted line with mark are critical for safety.
Replace only with part number specified.

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
1	X-4942-644-1	LID (B) ASSY, CASSETTE	
2	X-4942-643-1	LID (A) ASSY, CASSETTE	
3	3-319-288-01	FOOT	
4	X-4942-657-1	KNOB (VOLUME) ASSY	
5	3-701-947-14	LABEL (T2A), FUSE (H170:E, EA, H170K)	
6	1-533-213-31	HOLDER, FUSE	
8	3-704-366-01	SCREW (CASE) (M3X8)	
* 9	4-941-548-01	LABEL, CLASS 1 (H700:UK)	
10	4-951-989-01	CASE (H700)	
10	X-4942-649-1	CASE ASSY (H170:AEP, AUS)	

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
10	X-4942-650-1	CASE ASSY (H170:E, EA, H170K)	
11	3-356-957-01	SPRING	
△VS801	1-572-675-11	SWITCH, POWER VOLTAGE CHANGE	
ANT1	1-501-321-61	ANTENNA, TELESCOPIC (H170, H170K)	
△F801	1-532-078-00	FUSE	
△F801	1-532-203-00	FUSE (H170:E, EA, H170K)	
△F802	1-532-078-00	FUSE (H170, H170K:E, EA)	
△T101	1-450-769-11	TRANSFORMER, POWER (H170:AEP, H700)	
△T101	1-450-770-11	TRANSFORMER, POWER (H170:E, EA, AUS, H170K)	

7-2. FRONT PANEL, MAIN BOARD SECTION

- C: VOLUME board (See page 73)
- D: MIC HP board (See page 73)
- E: SW board (See page 73)




Ref. No.	Part No.	Description	Remarks
51	4-951-982-01	BUTTON (TC-E)	
52	4-951-985-01	KNOB (SLIDE)	
53	4-812-134-00	RIVET NYLON, 3.5	
54	X-4942-645-1	PANEL ASSY, FRONT (H170K)	
54	X-4942-646-1	PANEL ASSY, FRONT (H170:E, EA, AUS)	
54	X-4942-647-1	PANEL ASSY, FRONT (H170:AEP)	
54	X-4942-648-1	PANEL ASSY, FRONT (H700)	
55	1-696-146-11	WIRE (FLAT TYPE) (16 CORE)	
* 56	A-4347-469-A	DISPLAY BOARD, COMPLETE (H170:E, EA)	
* 56	A-4347-475-A	DISPLAY BOARD, COMPLETE (H170:AEP, H700)	
* 56	A-4347-483-A	DISPLAY BOARD, COMPLETE (H170K)	
* 56	A-4347-544-A	DISPLAY BOARD, COMPLETE (H170:AUS)	
57	4-928-635-01	SCREW, +BV (2.6X8) TAPPING	
58	1-690-996-11	WIRE (FLAT TYPE) (4 CORE)	
* 59	1-590-240-11	WIRE, FLAT TYPE (9 CORE)	
60	1-690-997-11	CABLE, FLAT (11 CORE)	
61	1-690-588-31	WIRE, FLAT TYPE (9 CORE)	

Ref. No.	Part No.	Description	Remarks
62	4-951-984-01	PANEL (LOADING)	
* 63	3-703-244-00	BUSHING (2104), CORD (H170:AEP, H700)	
* 63	3-703-571-11	BUSHING (S) (4516), CORD (H170:E, EA, AUS, H170K)	
△64	1-574-804-11	CORD, POWER (H700:UK)	
△64	1-574-805-11	CORD, POWER (H170:AEP, EA/H170K:EA/H700:AEP)	
△64	1-574-902-11	CORD, POWER (H170:E/H170K:E)	
△64	1-690-056-11	CORD, POWER (H170:AUS)	
* 65	A-4343-548-A	MAIN BOARD, COMPLETE (H170:E, EA)	
* 65	A-4343-553-A	MAIN BOARD, COMPLETE (H170K)	
* 65	A-4343-554-A	MAIN BOARD, COMPLETE (H170:AEP)	
* 65	A-4343-558-A	MAIN BOARD, COMPLETE (H700)	
* 65	A-4343-575-A	MAIN BOARD, COMPLETE (H170:AUS)	
66	4-925-530-01	PLATE, GROUND (H170, H170K)	
67	4-942-204-01	PLATE, GROUND	
FL1001	1-519-718-11	INDICATOR TUBE, FLUORESCENT	

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.


7-3. MD CHASSIS SECTION



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
101	3-354-960-01	SPRING (LOADING R), TORSION		111	3-354-963-01	DAMPER	
102	3-354-959-01	SPRING (LOADING L), TORSION		112	4-928-635-01	SCREW, +BV (2.6X8) TAPPING	
103	X-3362-856-1	HOLDER (R) ASSY, CASSETTE		* 113	A-4343-549-A	SUB BOARD, COMPLETE (H170:E, EA)	
104	X-3362-857-1	HOLDER (L) ASSY, CASSETTE		* 113	A-4343-550-A	SUB BOARD, COMPLETE (H170:AEP, H700)	
105	3-340-137-01	SPRING, CASSETTE RETAINER		* 113	A-4343-552-A	SUB BOARD, COMPLETE (H170K)	
106	3-354-955-01	LEVER (EJ SAFTY LEVER L)		* 113	A-4343-573-A	SUB BOARD, COMPLETE (H170:AUS)	
107	3-354-961-01	SPRING (EJ SAFTY SPRING L)		* 114	3-682-419-31	HOLDER, P. C. B	
108	3-367-720-01	RING (W), RETAINING		* 115	3-682-419-21	HOLDER, P. C. B	
109	3-367-721-01	SHAFT (FULCRUM SHAFT)		116	3-367-711-01	RETAINER, CASSETTE	
110	3-354-957-01	JOINT (LOCK LEVER)		117	3-354-962-01	SPRING (EJ SAFTY SPRING R)	
				118	3-354-956-01	LEVER (EJ SAFTY LEVER R)	

7-4. MECHANISM DECK SECTION (1)

(DECK A: TCM-190RA13A)
(DECK B: TCM-190RB22A)



Ref. No. Part No. Description

151	X-3359-408-1	LEVER (PINCH LEVER FWD) ASSY
152	3-359-455-01	SPRING, TORSION
153	3-356-713-01	WASHER
154	3-356-714-01	WASHER
155	X-3359-409-1	LEVER (PINCH LEVER REV) ASSY
157	X-3362-078-1	TABLE ASSY (B), REEL
158	3-359-424-01	GEAR (REV GEAR)
159	3-359-430-01	SPRING(CASSETTE RETAINER), LEAF
160	X-3364-554-1	FLYWHEEL (FWD) ASSY
161	X-3359-410-1	FLYWHEEL (REV) ASSY
162	3-359-417-01	BELT (FLAT), CAPSTAN
163	3-575-321-00	RETAINER, THRUST, CAPSTAN
* 164	3-359-436-01	BASE (THRUST RETAINER), FITTING
165	3-359-414-01	SCREW (+PTW 2X23)
166	3-359-450-01	PLATE, GROUND
167	1-638-983-11	PC BOARD, MOTOR FLEXIBLE

Remarks


Ref. No. Part No. Description

* 168	A-2006-399-A	MD-A BOARD (RA13A), AUDIO
* 168	A-2006-400-A	MD-B BOARD (RB22A), AUDIO
169	3-359-466-01	BELT (FR), SQUARE
* 170	1-634-841-14	LEAF SW (A) BOARD (RA13A) (DECK A)
* 170	1-634-841-14	LEAF SW (B) BOARD (RB22A) (DECK B)
171	3-343-419-01	HOLDER (S SENSOR A)
172	X-3359-404-1	TABLE ASSY, REEL
173	3-362-308-01	CAP (REEL)
174	3-356-716-01	SCREW (2X4) (B TIGHT), +P
HP101	A-2003-868-A	BASE ASSY, HEAD
HRP101	A-2003-838-A	BASE ASSY, HEAD
M101A	X-3363-501-1	MOTOR ASSY, REEL (DECK A)
M101B	X-3363-501-1	MOTOR ASSY, REEL (DECK B)
M102A	X-3359-417-1	MOTOR (CAPSTAN MOTOR) ASSY (DECK A)
M102B	X-3359-417-1	MOTOR (CAPSTAN MOTOR) ASSY (DECK B)
IC81A	8-719-710-03	IC NJL5165K-B
IC81B	8-719-710-03	IC NJL5165K-B

Remarks


7-5. MECHANISM DECK SECTION (2)

(DECK A : TCM-190RA13A)
(DECK B : TCM-190RB22A)



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
201	3-359-469-01	SPACER		210	3-359-456-01	SPRING (TRIGGER SPRING), TORSION	
* 202	3-359-425-01	SLIDER (REVERSE SLIDER)		211	X-3359-405-1	LEVER (FR ARM) ASSY	
203	3-359-426-01	LEVER (REVERSE LEVER)		212	3-359-453-01	SPRING (FR ARM), TORSION	
* 204	3-359-415-01	SLIDER (TRIGGER SLIDER)		213	3-359-419-01	GEAR (FR GEAR)	
205	3-359-448-01	GEAR (TRIGGER)		214	3-359-421-01	CLUTCH (REEL DISK)	
* 206	3-359-427-01	SLIDER (LEVERSE SLIDER)		215	3-359-418-01	PULLEY (FR PULLEY)	
207	3-359-420-01	GEAR (CAM GEAR)		216	X-3363-790-1	CHASSIS ASSY, MECHANICAL	
208	3-359-454-01	SPRING, TORSION					
209	3-359-429-01	SLIDER (BRAKE PLATE)					

7-6. CD SECTION (1)
(CDM13B-5BD4A)



Ref. No.	Part No.	Description
251	4-944-012-01	TABLE, DISC
253	1-590-530-11	WIRE, FLAT TYPE
254	A-4604-752-A	HOLDER (MG) ASSY
255	4-929-764-01	SHAFT (TABLE GUIDE)
256	4-927-620-01	GEAR (P)
257	4-927-628-01	GEAR (C)
258	4-929-724-01	PULLEY (B)
* 259	1-638-308-11	LOADING BOARD
260	4-927-649-01	BELT
261	4-944-006-01	BEARING
* 262	4-917-583-21	BRACKET, YOKE
263	X-4941-462-1	CHASSIS (MD) ASSY


Remarks

Ref. No.	Part No.	Description
264	1-690-853-11	WIRE (FLAT TYPE) (19 CORE)
265	4-933-134-01	SCREW (+PTPH M2. 6X6)
266	4-917-541-01	SPRING (B)
267	4-929-747-01	HOLDER (BU)
268	4-927-654-01	WASHER (LIMITER)
269	3-659-338-00	SPRING, COMPRESSION
270	4-929-729-01	CAM (B)
271	4-929-727-01	CAM (A)
272	X-4929-703-1	ARM ASSY, SWING
M251	A-4608-362-A	MOTOR (L) ASSY
S291	1-571-924-11	SWITCH, LEAF (LOAD OUT)
S292	1-571-924-11	SWITCH, LEAF (LOAD IN)

Remarks

7-7. CD SECTION (2)

(BU-5BD4A)



Note: The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
* 301	A-4617-937-A	BD BOARD, COMPLETE		306	4-917-567-01	GEAR (M)	
302	4-933-126-01	INSULATOR (A)		307	1-575-001-11	WIRE, FLAT TYPE (12 CORE)	
303	4-917-565-01	SHAFT, SLED		M101	X-4917-504-1	MOTOR ASSY (SLED)	
304	4-917-564-01	GEAR (P), FLATNESS		M102	X-4917-523-3	MOTOR ASSY (SPINDLE)	
Δ 305	8-848-144-11	DEVICE, OPTICAL KSS-240A		S101	1-572-085-11	SWITCH, LEAF (LIMIT IN)	



BD

SECTION 8

ELECTRICAL PARTS LIST

NOTE:

When indicating parts by reference number, please include the board name.

The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- - XX, - X mean standardized parts, so they may have some difference from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- CAPACITORS:
uF: μ F
- RESISTORS
All resistors are in ohms.
METAL: metal-film resistor
METAL OXIDE: Metal Oxide-film resistor
F: nonflammable
- COILS
uH: μ H
- SEMICONDUCTORS
In each case, u: μ , for example:
uA..., μ A..., uPA..., μ PA...,
uPB..., μ PB..., uPC..., μ PC...,
uPD..., μ PD...

- EA : Saudi Arabia
- AUS : Australian

Ref. No.	Part No.	Description	Remarks
* A-4617-936-A	BD BOARD		

< CAPACITOR >			
C101	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C102	1-163-989-11	CERAMIC CHIP 0.033uF	10% 25V
C103	1-135-155-21	TANTALUM CHIP 4.7uF	10% 16V
C104	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C105	1-126-607-11	ELECT CHIP 47uF	20% 4V
C106	1-126-607-11	ELECT CHIP 47uF	20% 4V
C107	1-126-607-11	ELECT CHIP 47uF	20% 4V
C108	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C109	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C110	1-163-989-11	CERAMIC CHIP 0.033uF	10% 25V
C111	1-164-346-11	CERAMIC CHIP 1uF	16V
C112	1-164-232-11	CERAMIC CHIP 0.01uF	50V
C113	1-164-232-11	CERAMIC CHIP 0.01uF	50V
C114	1-164-695-11	CERAMIC CHIP 0.0022uF	5% 50V
C115	1-164-695-11	CERAMIC CHIP 0.0022uF	5% 50V
C117	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C118	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C119	1-164-695-11	CERAMIC CHIP 0.0022uF	5% 50V
C120	1-163-989-11	CERAMIC CHIP 0.033uF	10% 25V
C151	1-163-019-00	CERAMIC CHIP 0.0068uF	10% 50V
C152	1-164-346-11	CERAMIC CHIP 1uF	16V
C153	1-163-135-00	CERAMIC CHIP 560PF	5% 50V
C154	1-164-695-11	CERAMIC CHIP 0.0022uF	5% 50V
C155	1-163-023-00	CERAMIC CHIP 0.015uF	5% 50V
C171	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C172	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C173	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C174	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C201	1-163-809-11	CERAMIC CHIP 0.047uF	10% 25V
C202	1-163-145-00	CERAMIC CHIP 0.0015uF	5% 50V
C203	1-164-232-11	CERAMIC CHIP 0.01uF	50V
C204	1-164-005-11	CERAMIC CHIP 0.47uF	25V
C205	1-164-346-11	CERAMIC CHIP 1uF	16V
C206	1-163-093-00	CERAMIC CHIP 10PF	5% 50V
C207	1-163-093-00	CERAMIC CHIP 10PF	5% 50V
C208	1-164-346-11	CERAMIC CHIP 1uF	16V
C209	1-164-346-11	CERAMIC CHIP 1uF	16V
C210	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C299	1-164-346-11	CERAMIC CHIP 1uF	16V
C301	1-164-346-11	CERAMIC CHIP 1uF	16V
C302	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C303	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C304	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C305	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C306	1-163-145-00	CERAMIC CHIP 0.0015uF	5% 50V
C307	1-163-145-00	CERAMIC CHIP 0.0015uF	5% 50V
C308	1-164-346-11	CERAMIC CHIP 1uF	16V
C309	1-164-346-11	CERAMIC CHIP 1uF	16V
C310	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
C311	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
C312	1-164-346-11	CERAMIC CHIP 1uF	16V
C401	1-164-232-11	CERAMIC CHIP 0.01uF	50V
< CONNECTOR >			
CN101	1-580-858-11	SOCKET, CONNECTOR (SMT) 5P	
CN102	1-580-866-11	SOCKET, CONNECTOR (SMT) 12P	
CN103	1-580-872-41	SOCKET, CONNECTOR (SMT) 19P	
< DIODE >			
D101	8-719-976-88	DIODE DTZ3.9B	
D201	8-719-988-62	DIODE 1SS355	

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
< IC >							
IC101	8-752-053-73 IC	CXA1372AQ		R214	1-239-039-11 NETWORK, RES	22K	
IC102	8-759-823-48 IC	LA6525M		R218	1-216-065-00 METAL CHIP	4.7K 5% 1/10W	
IC103	8-759-636-20 IC	M54641FP		R219	1-216-073-00 METAL CHIP	10K 5% 1/10W	
IC201	8-752-337-26 IC	CXD2500AQ		R220	1-216-001-00 METAL CHIP	10 5% 1/10W	
IC202	8-759-059-86 IC	uPD75116GF-F21-3BE		R222	1-236-427-11 NETWORK, RES	18K	
IC203	8-752-337-10 IC	CXD2554M		R223	1-216-081-00 METAL CHIP	22K 5% 1/10W	
IC301	8-759-506-63 IC	PCM67U		R224	1-216-081-00 METAL CHIP	22K 5% 1/10W	
IC302	8-759-996-43 IC	RC4558PS-T1		R225	1-216-081-00 METAL CHIP	22K 5% 1/10W	
				R226	1-216-081-00 METAL CHIP	22K 5% 1/10W	
< TRANSISTOR >				R230	1-236-413-11 NETWORK, RES	1.2K	
Q101	8-729-805-45 TRANSISTOR	2SC3395		R231	1-236-413-11 NETWORK, RES	1.2K	
Q201	8-729-602-21 TRANSISTOR	2SC4154		R232	1-216-041-00 METAL CHIP	470 5% 1/10W	
				R233	1-216-041-00 METAL CHIP	470 5% 1/10W	
< RESISTOR >				R301	1-236-413-11 NETWORK, RES	1.2K	
R101	1-216-097-00 METAL CHIP	100K 5% 1/10W		R303	1-216-055-00 METAL CHIP	1.8K 5% 1/10W	
R102	1-216-097-00 METAL CHIP	100K 5% 1/10W		R304	1-216-055-00 METAL CHIP	1.8K 5% 1/10W	
R103	1-216-091-00 METAL CHIP	56K 5% 1/10W		R305	1-216-097-00 METAL CHIP	100K 5% 1/10W	
R104	1-216-099-00 METAL CHIP	120K 5% 1/10W		R306	1-216-097-00 METAL CHIP	100K 5% 1/10W	
R105	1-216-069-00 METAL CHIP	6.8K 5% 1/10W		< VARIABLE RESISTOR >			
R106	1-216-061-00 METAL CHIP	3.3K 5% 1/10W		RV101	1-241-395-11 RES, ADJ, METAL GLAZE	10K	
R107	1-216-114-00 METAL GLAZE	510K 5% 1/10W		RV102	1-241-395-11 RES, ADJ, METAL GLAZE	10K	
R108	1-216-105-00 METAL CHIP	220K 5% 1/10W		< SWITCH >			
R109	1-216-061-00 METAL CHIP	3.3K 5% 1/10W		SW101	1-572-085-11 SWITCH, LEAF (LIMIT IN)		
R110	1-216-049-00 METAL CHIP	1K 5% 1/10W		< VIBRATOR >			
R111	1-216-049-00 METAL CHIP	1K 5% 1/10W		X201	1-579-280-11 VIBRATOR, CRYSTAL	16MHz	
R112	1-216-083-00 METAL CHIP	27K 5% 1/10W		X202	1-579-216-11 VIBRATOR, CERAMIC	4MHz	
R113	1-216-071-00 METAL CHIP	8.2K 5% 1/10W		*****			
R114	1-216-105-00 METAL CHIP	220K 5% 1/10W		*	A-4347-469-A DISPLAY BOARD, COMPLETE (H170:E, EA)		
R152	1-216-073-00 METAL CHIP	10K 5% 1/10W			*****		
R153	1-216-085-00 METAL CHIP	33K 5% 1/10W		*	A-4347-475-A DISPLAY BOARD, COMPLETE (H170:AEP, H700)		
R154	1-216-085-00 METAL CHIP	33K 5% 1/10W			*****		
R155	1-216-093-00 METAL CHIP	68K 5% 1/10W		*	A-4347-483-A DISPLAY BOARD, COMPLETE (H170K)		
R156	1-216-081-00 METAL CHIP	22K 5% 1/10W			*****		
R157	1-236-427-11 NETWORK, RES	18K		*	A-4347-544-A DISPLAY BOARD, COMPLETE (H170:AUS)		

R159	1-216-079-00 METAL CHIP	18K 5% 1/10W		< CAPACITOR >			
R160	1-216-049-00 METAL CHIP	1K 5% 1/10W		C501	1-163-117-00 CERAMIC CHIP	100PF 5% 50V	
R171	1-216-001-00 METAL CHIP	10 5% 1/10W		C502	1-163-117-00 CERAMIC CHIP	100PF 5% 50V	
R172	1-216-001-00 METAL CHIP	10 5% 1/10W		C503	1-163-125-00 CERAMIC CHIP	220PF 5% 50V	
R173	1-216-001-00 METAL CHIP	10 5% 1/10W		C504	1-163-125-00 CERAMIC CHIP	220PF 5% 50V	
R174	1-216-001-00 METAL CHIP	10 5% 1/10W		C505	1-163-031-11 CERAMIC CHIP	0.01uF 50V	
R201	1-216-061-00 METAL CHIP	3.3K 5% 1/10W		C506	1-163-031-11 CERAMIC CHIP	0.01uF 50V	
R202	1-216-073-00 METAL CHIP	10K 5% 1/10W		C507	1-163-038-00 CERAMIC CHIP	0.1uF 25V	
R203	1-216-061-00 METAL CHIP	3.3K 5% 1/10W		C508	1-163-038-00 CERAMIC CHIP	0.1uF 25V (H17 K)	
R204	1-216-073-00 METAL CHIP	10K 5% 1/10W		C511	1-126-157-11 ELECT	10uF 20% 16V	
R205	1-216-097-00 METAL CHIP	100K 5% 1/10W		C512	1-126-157-11 ELECT	10uF 20% 16V	
R208	1-216-033-00 METAL CHIP	220 5% 1/10W					
R209	1-216-081-00 METAL CHIP	22K 5% 1/10W					
R210	1-236-427-11 NETWORK, RES	18K					
R212	1-236-427-11 NETWORK, RES	18K					

DISPLAY

Ref. No.	Part No.	Description	Remarks
C1001	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1002	1-163-025-11	CERAMIC CHIP 0.001uF	50V
C1003	1-124-442-00	ELECT 330uF	20% 6.3V
C1003	1-126-924-11	ELECT 330uF	20% 10V(H170K)
C1004	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1011	1-124-584-00	ELECT 100uF	20% 10V
C1012	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1013	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C1014	1-126-157-11	ELECT 10uF	20% 16V
C1015	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1016	1-163-235-11	CERAMIC CHIP 22PF	5% 50V
C1020	1-164-222-11	CERAMIC CHIP 0.22uF	25V
C1023	1-163-229-11	CERAMIC CHIP 12PF	5% 50V
C1024	1-163-097-00	CERAMIC CHIP 15PF	5% 50V
C1025	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1026	1-126-177-11	ELECT 100uF	20% 10V
C1030	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1031	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1032	1-126-154-11	ELECT 47uF	20% 6.3V
C1033	1-126-154-11	ELECT 47uF	20% 6.3V
C1034	1-163-025-11	CERAMIC CHIP 0.001uF	50V
C1035	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1036	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1041	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1050	1-124-910-11	ELECT 47uF	20% 50V
C1051	1-124-443-00	ELECT 100uF	20% 10V
C1098	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C1099	1-163-038-00	CERAMIC CHIP 0.1uF	25V

< FILTER >

CF1001 1-579-599-21 VIBRATOR, CERAMIC

< CONNECTOR >

- * CN1001 1-569-156-11 SOCKET, CONNECTOR 10P
- * CN1002 1-569-156-11 SOCKET, CONNECTOR 10P
- * CN1003 1-569-156-11 SOCKET, CONNECTOR 10P (H170K)
- CN1003 1-695-027-11 PLUG, CONNECTOR 10P
- * CN1004 1-568-451-11 HOUSING, CONNECTOR(PC BOARD)10P
- * CN1006 1-565-980-21 HOUSING, CONNECTOR(PC BOARD) 9P

< DIODE >

D1001	8-719-820-05	DIODE 1SS181
D1002	8-719-820-05	DIODE 1SS181
D1003	8-719-820-05	DIODE 1SS181
D1004	8-719-820-05	DIODE 1SS181
D1005	8-719-820-05	DIODE 1SS181
D1007	8-719-820-05	DIODE 1SS181
D1030	8-719-021-41	DIODE U2M5.6X
D1031	8-719-021-41	DIODE U2M5.6X
D1051	8-719-026-64	DIODE SML1260S
D1052	8-719-026-64	DIODE SML1260S

Ref. No.	Part No.	Description	Remarks
D1053	8-719-026-64	DIODE SML1260S	
D1054	8-719-026-64	DIODE SML1260S	
D1055	8-719-026-64	DIODE SML1260S	
D1057	8-719-026-64	DIODE SML1260S (H170K)	
D1058	8-719-026-68	DIODE SML1960A	
D1059	8-719-026-68	DIODE SML1960A	

< INDICATOR >

FL1001 1-519-718-11 INDICATOR TUBE, FLUORESCENT

< IC >

IC106	8-759-927-29	IC SN74HC04ANS
IC501	8-759-996-43	IC RC4558PS
IC1001	8-759-059-81	IC uPD78012GC-502-AB8
IC1002	8-759-500-31	IC X24C01P
IC1003	8-759-991-11	IC XR1091DCP
IC1004	8-759-516-41	IC CD4052BCM
IC1005	8-749-923-34	IC PHOTO DIODE GPIU59XB
IC1006	8-759-512-44	IC SN755703FT
IC1007	8-759-512-44	IC SN755703FT

< JUMPER RESISTOR >

JW1001	1-216-295-00	METAL CHIP 0 5%	1/10W(H170, H700)
JW1002	1-216-295-00	METAL CHIP 0 5%	1/10W(H170, H700)
JW1004	1-216-295-00	METAL CHIP 0 5%	1/10W(H170, H700)
JW1029	1-216-295-00	METAL CHIP 0 5%	1/10W(H170, H700)
JW1050	1-216-295-00	METAL CHIP 0 5%	1/10W(H170:E, EA)

< TRANSISTOR >

Q601	8-729-141-26	TRANSISTOR 2SC3622A-LK
Q1001	8-729-900-61	TRANSISTOR DTA114ES
Q1002	8-729-900-80	TRANSISTOR DTC114ES
Q1003	8-729-900-61	TRANSISTOR DTA114ES
Q1004	8-729-805-43	TRANSISTOR 2SC3396
Q1051	8-729-620-05	TRANSISTOR 2SC2603-EF

< RESISTOR >

R501	1-216-073-00	METAL CHIP 10K 5%	1/10W
R502	1-216-073-00	METAL CHIP 10K 5%	1/10W(H170K)
R503	1-216-097-00	METAL CHIP 100K 5%	1/10W
R504	1-216-097-00	METAL CHIP 100K 5%	1/10W
R505	1-216-073-00	METAL CHIP 10K 5%	1/10W
R506	1-216-073-00	METAL CHIP 10K 5%	1/10W(H170K)
R507	1-216-073-00	METAL CHIP 10K 5%	1/10W
R508	1-216-077-00	METAL CHIP 15K 5%	1/10W
R509	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
R510	1-216-069-00	METAL CHIP 6.8K 5%	1/10W

DISPLAY

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
R511	1-216-097-00	METAL CHIP	100K 5% 1/10W	R1070	1-216-049-00	METAL CHIP	1K 5% 1/10W
R512	1-216-105-00	METAL CHIP	220K 5% 1/10W	R1071	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R513	1-216-105-00	METAL CHIP	220K 5% 1/10W	R1072	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R514	1-216-105-00	METAL CHIP	220K 5% 1/10W	R1073	1-216-049-00	METAL CHIP	1K 5% 1/10W
R515	1-216-105-00	METAL CHIP	220K 5% 1/10W	R1074	1-216-049-00	METAL CHIP	1K 5% 1/10W
R516	1-216-113-00	METAL CHIP	470K 5% 1/10W	R1075	1-216-049-00	METAL CHIP	1K 5% 1/10W
R517	1-216-113-00	METAL CHIP	470K 5% 1/10W(H170K)	R1076	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1001	1-216-089-00	METAL CHIP	47K 5% 1/10W	R1077	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1002	1-216-073-00	METAL CHIP	10K 5% 1/10W	R1078	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1003	1-216-049-00	METAL CHIP	1K 5% 1/10W	R1079	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1003	1-216-295-00	METAL CHIP	0 5% 1/10W(H170K)	R1080	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1004	1-216-097-00	METAL CHIP	100K 5% 1/10W	R1081	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1006	1-216-073-00	METAL CHIP	10K 5% 1/10W	R1082	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1016	1-216-295-00	METAL CHIP	0 5% 1/10W(H170K)	R1083	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1007	1-216-025-00	METAL CHIP	100 5% 1/10W	R1084	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1008	1-216-073-00	METAL CHIP	10K 5% 1/10W	R1085	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1010	1-216-041-00	METAL CHIP	470 5% 1/10W	R1086	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1011	1-216-045-00	METAL CHIP	680 5% 1/10W	R1087	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1012	1-216-049-00	METAL CHIP	1K 5% 1/10W	R1088	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1013	1-216-089-00	METAL CHIP	47K 5% 1/10W	R1091	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R1014	1-216-109-00	METAL CHIP	330K 5% 1/10W	R1092	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R1015	1-216-025-00	METAL CHIP	100 5% 1/10W	R1093	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R1017	1-216-041-00	METAL CHIP	470 5% 1/10W	R1094	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R1018	1-216-045-00	METAL CHIP	680 5% 1/10W	R1095	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1019	1-216-049-00	METAL CHIP	1K 5% 1/10W	R1096	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1020	1-216-053-00	METAL CHIP	1.5K 5% 1/10W	R1100	1-216-037-00	METAL CHIP	330 5% 1/10W
R1021	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	R1101	1-216-037-00	METAL CHIP	330 5% 1/10W
R1022	1-216-065-00	METAL CHIP	4.7K 5% 1/10W	R1102	1-216-037-00	METAL CHIP	330 5% 1/10W
R1023	1-216-075-00	METAL CHIP	12K 5% 1/10W	R1103	1-216-037-00	METAL CHIP	330 5% 1/10W(H170K)
R1024	1-216-041-00	METAL CHIP	470 5% 1/10W	R1115	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1025	1-216-045-00	METAL CHIP	680 5% 1/10W	R1116	1-216-049-00	METAL CHIP	1K 5% 1/10W
R1026	1-216-049-00	METAL CHIP	1K 5% 1/10W	R1130	1-216-017-00	METAL CHIP	47 5% 1/10W
R1027	1-216-053-00	METAL CHIP	1.5K 5% 1/10W	R1131	1-216-017-00	METAL CHIP	47 5% 1/10W
R1028	1-216-049-00	METAL CHIP	1K 5% 1/10W(H170K)	R1132	1-216-053-00	METAL CHIP	1.5K 5% 1/10W
R1030	1-216-113-00	METAL CHIP	470K 5% 1/10W	R1201	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R1050	1-216-041-00	METAL CHIP	470 5% 1/10W (H170:AEP, H700)	< VARIABLE RESISTOR >			
R1050	1-216-295-00	METAL CHIP	0 5% 1/10W (H170:AUS, H170K)	RV501	1-241-876-11	RES, VAR, CARBON 50K (MIC 1 LEVEL) (H170K)	
R1060	1-216-049-00	METAL CHIP	1K 5% 1/10W	RV502	1-241-876-11	RES, VAR, CARBON 50K (MIC 2 LEVEL) (H170K)	
R1061	1-216-049-00	METAL CHIP	1K 5% 1/10W	RV503	1-241-876-11	RES, VAR, CARBON 50K (ECHO LEVEL) (H170K)	
R1062	1-216-049-00	METAL CHIP	1K 5% 1/10W	< SWITCH >			
R1063	1-216-049-00	METAL CHIP	1K 5% 1/10W	S1001	1-572-184-11	SWITCH, KEYBOARD (POWER)	
R1064	1-216-049-00	METAL CHIP	1K 5% 1/10W	S1002	1-572-184-11	SWITCH, KEYBOARD (TIMER)	
R1065	1-216-065-00	METAL CHIP	4.7K 5% 1/10W	S1003	1-572-184-11	SWITCH, KEYBOARD (MPX) (H170K)	
R1066	1-216-073-00	METAL CHIP	10K 5% 1/10W	S1009	1-572-184-11	SWITCH, KEYBOARD (+)	
R1067	1-216-049-00	METAL CHIP	1K 5% 1/10W	S1010	1-572-184-11	SWITCH, KEYBOARD (BAND)	
R1068	1-216-073-00	METAL CHIP	10K 5% 1/10W				
R1069	1-216-049-00	METAL CHIP	1K 5% 1/10W				

DISPLAY
LEAF SW (A)
LEAF SW (B)
LOADING
MAIN (including POWER)

Ref. No.	Part No.	Description	Remarks
S1011	1-572-184-11	SWITCH, KEYBOARD (-)	
S1012	1-572-184-11	SWITCH, KEYBOARD (FUNCTION)	
S1013	1-572-184-11	SWITCH, KEYBOARD (KARAOKE)	
S1014	1-572-184-11	SWITCH, KEYBOARD (PRESET)	
S1015	1-572-184-11	SWITCH, KEYBOARD (EQ)	
S1016	1-572-184-11	SWITCH, KEYBOARD (TIMER REC)	
S1017	1-572-184-11	SWITCH, KEYBOARD (MEMORY/NEXT)	
S1018	1-572-184-11	SWITCH, KEYBOARD (STEREO/MONO)	
S1019	1-572-184-11	SWITCH, KEYBOARD (+)	
S1020	1-572-184-11	SWITCH, KEYBOARD (-)	
S1021	1-572-184-11	SWITCH, KEYBOARD (DBFB)	
< VIBRATOR >			
X1002	1-527-997-21	VIBRATOR, CRYSTAL 32kHz	

*	1-634-841-14	LEAF SW(A) BOARD (RA13A)	

	3-343-419-01	HOLDER (S SENSER A)	
< CONNECTOR >			
* CNP81	1-568-852-11	SOCKET, CONNECTOR 9P	
< IC >			
IC81A	8-719-710-03	IC NJL5165K-B	
< RESISTOR >			
R84	1-249-417-11	CARBON 1K 5% 1/4W	
R85	1-249-408-11	CARBON 180 5% 1/4W	
< SWITCH >			
S81	1-571-958-11	SWITCH, PUSH (1 KEY) (STOP DET)	
S82	1-571-281-21	SWITCH, LEAF (CrO2 DET)	
S86	1-571-281-21	SWITCH, LEAF (HALF DET)	

*	1-634-841-14	LEAF SW(B) BOARD (RB22A)	

	3-343-419-01	HOLDER (S SENSER A)	
< CONNECTOR >			
* CNP81	1-568-852-11	SOCKET, CONNECTOR 9P	
< IC >			
IC81B	8-719-710-03	IC NJL5165K-B	

Ref. No.	Part No.	Description	Remarks
< RESISTOR >			
R81	1-249-414-11	CARBON 560 5% 1/4W	
R82	1-247-818-11	CARBON 300 5% 1/4W	
R83	1-247-834-11	CARBON 1.3K 5% 1/4W	
R84	1-249-417-11	CARBON 1K 5% 1/4W	
R85	1-249-408-11	CARBON 180 5% 1/4W	
< SWITCH >			
S81	1-571-958-11	SWITCH, PUSH (1 KEY) (STOP DET)	
S82	1-571-281-21	SWITCH, LEAF (CrO2 DET)	
S83	1-571-281-21	SWITCH, LEAF (METAL HALF)	
S84	1-571-281-21	SWITCH, LEAF (ERASE PROOF)	
S85	1-571-281-21	SWITCH, LEAF (ERASE PROOF)	
S86	1-571-281-21	SWITCH, LEAF (HALF DET)	

*	1-638-308-11	LOADING BOARD	

< CONNECTOR >			
CN201	1-580-918-11	HOUSING, CONNECTOR 5P	
< SWITCH >			
S291	1-571-924-11	SWITCH, LEAF (LOAD OUT)	
S292	1-571-924-11	SWITCH, LEAF (LOAD IN)	

*	A-4343-548-A	MAIN BOARD, COMPLETE (H170:E, EA)	

*	A-4343-553-A	MAIN BOARD, COMPLETE (H170K)	

*	A-4343-554-A	MAIN BOARD, COMPLETE (H170:AEP)	

*	A-4343-558-A	MAIN BOARD, COMPLETE (H700)	

*	A-4343-575-A	MAIN BOARD, COMPLETE (H170:AUS)	

< CAPACITOR >			
C1	1-162-195-31	CERAMIC 4.7PF 10% 50V	(H170, H170K)
C2	1-124-907-11	ELECT 10uF 20% 50V	
C3	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C4	1-162-294-31	CERAMIC 0.001uF 10% 50V	
C5	1-101-005-00	CERAMIC 22000PF 50V	
C6	1-162-851-11	CERAMIC 0.1uF 20% 16V	(H170:E, EA, AUS, H170K)
C7	1-101-005-00	CERAMIC 22000PF 50V	
C8	1-101-005-00	CERAMIC 22000PF 50V	(H170:AEP, H700)

MAIN (including POWER)

Ref. No.	Part No.	Description	Remarks
C9	1-102-120-00	CERAMIC 0.0018uF 10% 50V (H170:AEP, H700)	
C10	1-161-374-11	CERAMIC 0.0015uF 20% 50V (H170:AEP, H700)	
C21	1-161-379-00	CERAMIC 0.01uF 20% 25V (H170:E, EA, AUS, H170K)	
C22	1-102-947-00	CERAMIC 10PF 5% 50V (H170:E, EA, AUS, H170K)	
C23	1-136-162-00	FILM 0.056uF 5% 50V (H170:E, EA, AUS, H170K)	
C24	1-101-005-00	CERAMIC 22000PF 50V (H170:E, EA, AUS, H170K)	
C51	1-164-056-11	CERAMIC 27PF 5% 50V	
C52	1-164-056-11	CERAMIC 27PF 5% 50V	
C53	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C54	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C55	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C56	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C57	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C58	1-124-907-11	ELECT 10uF 20% 50V	
C59	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C60	1-124-477-11	ELECT 47uF 20% 25V	
C61	1-124-925-11	ELECT 2.2uF 20% 100V	
C62	1-136-153-00	FILM 0.01uF 5% 50V	
C63	1-124-463-00	ELECT 0.1uF 20% 50V	
C64	1-124-902-00	ELECT 0.47uF 20% 50V (H170:AEP, H700)	
C65	1-136-157-00	FILM 0.022uF 5% 50V (H170:AEP, H700)	
C66	1-136-157-00	FILM 0.022uF 5% 50V (H170:AEP, H700)	
C81	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C82	1-124-472-11	ELECT 470uF 20% 10V	
C83	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C84	1-124-907-11	ELECT 10uF 20% 50V	
C85	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C86	1-162-282-31	CERAMIC 100PF 10% 50V	
C87	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C88	1-124-907-11	ELECT 10uF 20% 50V	
C89	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C90	1-124-477-11	ELECT 47uF 20% 25V	
C91	1-162-294-31	CERAMIC 0.001uF 10% 50V	
C92	1-162-294-31	CERAMIC 0.001uF 10% 50V	
C93	1-161-375-00	CERAMIC 0.0022uF 20% 50V	
C94	1-161-375-00	CERAMIC 0.0022uF 20% 50V	
C95	1-124-903-11	ELECT 1uF 20% 50V	
C96	1-124-903-11	ELECT 1uF 20% 50V	
C97	1-124-903-11	ELECT 1uF 20% 50V	
C98	1-124-903-11	ELECT 1uF 20% 50V	
C99	1-136-154-00	FILM 0.012uF 5% 50V	
C100	1-136-154-00	FILM 0.012uF 5% 50V	

Ref. No.	Part No.	Description	Remarks
C101	1-124-907-11	ELECT 10uF 20% 50V	
C102	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C103	1-124-463-00	ELECT 0.1uF 20% 50V	
C104	1-126-160-11	ELECT 1uF 20% 50V	
C105	1-126-160-11	ELECT 1uF 20% 50V	
C106	1-124-903-11	ELECT 1uF 20% 50V	
C108	1-162-211-31	CERAMIC 33PF 5% 50V	
C109	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C110	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C111	1-123-382-00	ELECT 3.3uF 20% 100V	
C112	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C114	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C115	1-164-159-11	CERAMIC 0.1uF 50V	
C116	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C140	1-126-926-11	ELECT 1000uF 20% 10V	
C141	1-162-282-31	CERAMIC 100PF 10% 50V	
C142	1-162-282-31	CERAMIC 100PF 10% 50V	
C200	1-102-120-00	CERAMIC 0.0018uF 10% 50V	
C201	1-162-282-31	CERAMIC 100PF 10% 50V	
C202	1-162-215-31	CERAMIC 47PF 5% 50V	
C203	1-136-172-00	FILM 0.39uF 5% 50V (H170K)	
C204	1-130-471-00	MYLAR 0.001uF 5% 50V (H170K)	
C205	1-124-927-11	ELECT 4.7uF 20% 100V	
C206	1-162-286-31	CERAMIC 220PF 10% 50V	
C207	1-124-254-00	ELECT 0.68uF 20% 50V	
C208	1-124-252-00	ELECT 0.33uF 20% 50V	
C209	1-124-252-00	ELECT 0.33uF 20% 50V	
C210	1-136-167-00	FILM 0.15uF 5% 50V	
C211	1-136-166-00	FILM 0.12uF 5% 50V	
C212	1-136-162-00	FILM 0.056uF 5% 50V	
C213	1-136-161-00	FILM 0.047uF 5% 50V	
C214	1-136-157-00	FILM 0.022uF 5% 50V	
C215	1-136-156-00	FILM 0.018uF 5% 50V	
C216	1-130-482-00	MYLAR 0.0082uF 5% 50V	
C217	1-130-481-00	MYLAR 0.0068uF 5% 50V	
C218	1-130-477-00	MYLAR 0.0033uF 5% 50V	
C219	1-136-157-00	FILM 0.022uF 5% 50V	
C220	1-126-096-11	ELECT 10uF 20% 35V	
C221	1-162-286-31	CERAMIC 220PF 10% 50V	
C222	1-162-294-31	CERAMIC 0.001uF 10% 50V (H170, H700)	
C224	1-124-252-00	ELECT 0.33uF 20% 50V	
C225	1-124-254-00	ELECT 0.68uF 20% 50V	
C227	1-164-159-11	CERAMIC 0.1uF 50V	
C228	1-124-907-11	ELECT 10uF 20% 50V	
C231	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C241	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C242	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C243	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C247	1-124-925-11	ELECT 2.2uF 20% 100V	
C248	1-164-159-11	CERAMIC 0.1uF 50V (H170K)	

MAIN (including POWER)

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
C249	1-164-159-11	CERAMIC 0.1uF 50V(H170K)		C355	1-124-907-11	ELECT 10uF 20% 50V	
C250	1-102-120-00	CERAMIC 0.0018uF 10% 50V					(H170:AEP, H700)
C251	1-162-282-31	CERAMIC 100PF 10% 50V		C356	1-124-903-11	ELECT 1uF 20% 50V	
C252	1-162-215-31	CERAMIC 47PF 5% 50V		C357	1-164-159-11	CERAMIC 0.1uF 50V	
C253	1-136-172-00	FILM 0.39uF 5% 50V(H170K)		C358	1-164-159-11	CERAMIC 0.1uF 50V	
C254	1-130-471-00	MYLAR 0.001uF 5% 50V(H170K)					(H170:AEP, H700)
C255	1-124-927-11	ELECT 4.7uF 20% 100V		C370	1-162-282-31	CERAMIC 100PF 10% 50V	
C256	1-162-286-31	CERAMIC 220PF 10% 50V					(H170:AEP, H700)
C257	1-124-254-00	ELECT 0.68uF 20% 50V		C418	1-126-916-11	ELECT 1000uF 20% 6.3V	
C258	1-124-252-00	ELECT 0.33uF 20% 50V		C419	1-126-157-11	ELECT 10uF 20% 16V	
C259	1-124-252-00	ELECT 0.33uF 20% 50V		C420	1-126-157-11	ELECT 10uF 20% 16V	
C260	1-136-167-00	FILM 0.15uF 5% 50V		C801	1-124-907-11	ELECT 10uF 20% 50V	
C261	1-136-166-00	FILM 0.12uF 5% 50V		C802	1-162-290-31	CERAMIC 470PF 10% 50V	
C262	1-136-162-00	FILM 0.056uF 5% 50V		C803	1-126-233-11	ELECT 22uF 20% 50V	
C263	1-136-161-00	FILM 0.047uF 5% 50V		C848	1-126-233-11	ELECT 22uF 20% 50V	
C264	1-136-157-00	FILM 0.022uF 5% 50V		C851	1-124-907-11	ELECT 10uF 20% 50V	
C265	1-136-156-00	FILM 0.018uF 5% 50V		C852	1-162-290-31	CERAMIC 470PF 10% 50V	
C266	1-130-482-00	MYLAR 0.0082uF 5% 50V		C853	1-126-233-11	ELECT 22uF 20% 50V	
C267	1-130-481-00	MYLAR 0.0068uF 5% 50V		C871	1-126-953-11	ELECT 2200uF 20% 35V	
C268	1-130-477-00	MYLAR 0.0033uF 5% 50V		C872	1-126-953-11	ELECT 2200uF 20% 35V	
C269	1-136-157-00	FILM 0.022uF 5% 50V		C873	1-124-120-11	ELECT 220uF 20% 25V	
C270	1-126-096-11	ELECT 10uF 20% 35V		C874	1-124-484-11	ELECT 220uF 20% 35V	
C271	1-162-286-31	CERAMIC 220PF 10% 50V		C875	1-126-233-11	ELECT 22uF 20% 50V	
C272	1-162-294-31	CERAMIC 0.001uF 10% 50V		C876	1-124-907-11	ELECT 10uF 20% 50V	
			(H170, H700)	C877	1-126-233-11	ELECT 22uF 20% 50V	
C274	1-124-252-00	ELECT 0.33uF 20% 50V		C878	1-124-910-11	ELECT 47uF 20% 50V	
C275	1-124-254-00	ELECT 0.68uF 20% 50V		C879	1-124-910-11	ELECT 47uF 20% 50V	
C277	1-164-159-11	CERAMIC 0.1uF 50V		C880	1-124-910-11	ELECT 47uF 20% 50V	
C281	1-161-379-00	CERAMIC 0.01uF 20% 25V		C883	1-162-207-31	CERAMIC 22PF 5% 50V	
C290	1-164-159-11	CERAMIC 0.1uF 50V		C884	1-162-207-31	CERAMIC 22PF 5% 50V	
C291	1-164-159-11	CERAMIC 0.1uF 50V		C891	1-164-159-11	CERAMIC 0.1uF 50V	
C292	1-164-159-11	CERAMIC 0.1uF 50V		C892	1-164-159-11	CERAMIC 0.1uF 50V	
C293	1-164-159-11	CERAMIC 0.1uF 50V		C893	1-164-159-11	CERAMIC 0.1uF 50V	
C301	1-162-282-31	CERAMIC 100PF 10% 50V		C894	1-164-159-11	CERAMIC 0.1uF 50V	
C302	1-162-282-31	CERAMIC 100PF 10% 50V		C898	1-126-233-11	ELECT 22uF 20% 50V	
C303	1-130-474-00	MYLAR 0.0018uF 5% 50V		C899	1-136-161-00	FILM 0.047uF 5% 50V	
			(H170:AEP, H700)	C901	1-124-564-11	ELECT 4700uF 20% 25V	
C304	1-130-480-00	MYLAR 0.0056uF 5% 50V		C902	1-124-927-11	ELECT 4.7uF 20% 100V	
			(H170:AEP, H700)	C903	1-124-927-11	ELECT 4.7uF 20% 100V	
C305	1-124-907-11	ELECT 10uF 20% 50V		C904	1-126-233-11	ELECT 22uF 20% 50V	
			(H170:AEP, H700)	C905	1-124-927-11	ELECT 4.7uF 20% 100V	
C306	1-124-903-11	ELECT 1uF 20% 50V		C906	1-124-927-11	ELECT 4.7uF 20% 100V	
C307	1-164-159-11	CERAMIC 0.1uF 50V		C908	1-124-907-11	ELECT 10uF 20% 50V	
C308	1-164-159-11	CERAMIC 0.1uF 50V		C909	1-124-907-11	ELECT 10uF 20% 50V	
			(H170:AEP, H700)	C910	1-124-910-11	ELECT 47uF 20% 50V	
C320	1-162-282-31	CERAMIC 100PF 10% 50V		C911	1-124-910-11	ELECT 47uF 20% 50V	
			(H170:AEP, H700)	C912	1-124-910-11	ELECT 47uF 20% 50V	
C351	1-162-282-31	CERAMIC 100PF 10% 50V		C913	1-161-379-00	CERAMIC 0.01uF 20% 25V	
C352	1-162-282-31	CERAMIC 100PF 10% 50V		C922	1-124-564-11	ELECT 4700uF 20% 25V	
C353	1-130-474-00	MYLAR 0.0018uF 5% 50V		C923	1-124-252-00	ELECT 0.33uF 20% 50V	
			(H170:AEP, H700)	C924	1-124-464-11	ELECT 0.22uF 20% 50V	
C354	1-130-480-00	MYLAR 0.0056uF 5% 50V		C951	1-124-907-11	ELECT 10uF 20% 50V	
			(H170:AEP, H700)	C952	1-126-160-11	ELECT 1uF 20% 50V	

MAIN (including POWER)

Ref. No.	Part No.	Description	Remarks
C953	1-124-903-11	ELECT 1uF 20% 50V	
C954	1-124-120-11	ELECT 220uF 20% 25V	
C999	1-101-005-00	CERAMIC 22000PF 50V	
C2002	1-124-907-11	ELECT 10uF 20% 50V	
C2052	1-124-907-11	ELECT 10uF 20% 50V	
C9001	1-124-907-11	ELECT 10uF 20% 50V	
C9002	1-124-034-51	ELECT 33uF 20% 16V	

< CIRCUIT BREAKER >

CB801	1-532-564-00	BREAKER, CIRCUIT 2.2A	
CB851	1-532-564-00	BREAKER, CIRCUIT 2.2A	

< FILTER >

CF1	1-567-389-11	FILTER, CERAMIC	
CF81	1-567-389-11	FILTER, CERAMIC	

< CONNECTOR >

* CN201	1-569-155-11	PLUG, CONNECTOR 10P	
* CN202	1-569-155-11	PLUG, CONNECTOR 10P	
CN203	1-695-026-11	SOCKET, CONNECTOR 10P	
* CN204	1-568-828-11	SOCKET, CONNECTOR 9P	
* CN205	1-566-973-21	PIN, CONNECTOR (PC BOARD) 8P	
* CN206	1-566-973-21	PIN, CONNECTOR (PC BOARD) 8P	
* CN207	1-573-085-11	CONNECTOR, FPC (NON ZIF) 19P	
* CN401	1-568-852-11	SOCKET, CONNECTOR 9P	
* CN402	1-568-455-11	PIN, CONNECTOR (PC BOARD) 10P	
* CN403	1-568-847-11	SOCKET, CONNECTOR 4P	
* CN404	1-695-070-11	CONNECTOR, FFC/FPC 11P	
* CN801	1-562-573-11	SOCKET, CONNECTOR 8P	
* CN802	1-564-510-11	PLUG, CONNECTOR 7P	
* CN803	1-564-509-11	PLUG, CONNECTOR 6P	
* CN804	1-695-069-11	CONNECTOR, FFC/FPC 11P	
* CN901	1-564-510-11	PLUG, CONNECTOR 7P	
* CN902	1-564-509-11	PLUG, CONNECTOR 6P	

< TRIMMER >

CT21	1-141-227-00	CAP, TRIMMER 20PF (H170:E, EA, AUS, H170K)	
CT22	1-141-227-00	CAP, TRIMMER 20PF (H170:E, EA, AUS, H170K)	

< DIODE >

D21	8-719-976-30	DIODE KV1560N (H170:E, EA, AUS, H170K)	
D81	8-719-987-63	DIODE 1N4148M	
D202	8-719-987-63	DIODE 1N4148M	
D205	8-719-933-33	DIODE HZS6A1L (H170K)	
D206	8-719-933-33	DIODE HZS6A1L	
D207	8-719-933-33	DIODE HZS6A1L (H170K)	

Ref. No.	Part No.	Description	Remarks
D208	8-719-987-63	DIODE 1N4148M	
D401	8-719-987-63	DIODE 1N4148M	
D801	8-719-987-63	DIODE 1N4148M	
D901	8-719-200-82	DIODE 11ES2	
D902	8-719-200-82	DIODE 11ES2	
D904	8-719-933-41	DIODE HZS6C3L	
D905	8-719-200-82	DIODE 11ES2	
D906	8-719-200-82	DIODE 11ES2	
D907	8-719-011-22	DIODE UZ-36BSB	
D909	8-719-001-15	DIODE UZL-9M2	
D910	8-719-987-63	DIODE 1N4148M	
D914	8-719-987-63	DIODE 1N4148M	
D915	8-719-987-63	DIODE 1N4148M	
D916	8-719-987-63	DIODE 1N4148M	
D921	8-719-987-63	DIODE 1N4148M	
D923	8-719-200-82	DIODE 11ES2	
D924	8-719-200-82	DIODE 11ES2	

< CONNECTOR >

* DIP801	1-562-327-00	SOCKET, CONNECTOR 3P	
* DIP802	1-562-327-00	SOCKET, CONNECTOR 3P	
* DIP803	1-562-327-00	SOCKET, CONNECTOR 3P	
* DIP804	1-562-327-00	SOCKET, CONNECTOR 3P	

< FRONTEND >

FE1	1-465-673-11	FRONTEND (2 BAND)	
FE2	1-236-462-11	ENCAPSULATED COMPONENT (H170:AEP, H700)	
FE2	1-236-777-11	ENCAPSULATED COMPONENT (H170:E, EA, AUS, H170K)	
FE3	1-236-463-11	ENCAPSULATED COMPONENT (H170:AEP, H700)	

< IC >

IC51	8-759-820-91	IC LC7218	
IC81	8-759-821-45	IC LA1851N	
IC201	8-759-603-14	IC M5229P	
IC231	8-759-000-49	IC MC14066BCP	
IC232	8-759-634-51	IC M5218AF	
IC234	8-759-822-26	IC LC7522K	
IC236	8-759-000-49	IC MC14066BCP(H170K)	
IC251	8-759-603-14	IC M5229P	
IC301	8-759-634-51	IC M5218AF (H170:AEP, H700)	
IC302	8-759-000-48	IC MC14052BCP	
IC406	8-759-820-62	IC LB1639	
IC801	8-749-920-13	IC STK-4132MK2	
IC901	8-759-602-66	IC M5230L-A	
IC902	8-759-821-93	IC LA5601	
IC9001	8-759-520-90	IC PST572E	

MAIN (including POWER)

Ref. No. Part No. Description

< IFT >

IFT81 1-404-713-11 TRANSFORMER, IF
IFT82 1-404-807-11 TRANSFORMER, DISCRIMINATOR

< JACK >

J301 1-569-181-11 JACK, PIN 2P (VIDEO/AUX)

< COIL >

L1 1-408-425-00 INDUCTOR 220uH (H170:AEP, H700)
L81 1-408-399-00 INDUCTOR 1.5uH
L83 1-410-489-11 INDUCTOR 390uH

< FILTER >

LPF81 1-235-164-00 FILTER, LOW PASS
LPF82 1-235-164-00 FILTER, LOW PASS

< TRANSISTOR >

Q1 8-729-620-19 TRANSISTOR 2SC2724-CD
Q4 8-729-900-61 TRANSISTOR DTA114ES
Q5 8-729-900-80 TRANSISTOR DTC114ES
Q7 8-729-119-76 TRANSISTOR 2SA1175-HFE
Q8 8-729-119-76 TRANSISTOR 2SA1175-HFE

Q9 8-729-900-80 TRANSISTOR DTC114ES
Q10 8-729-900-74 TRANSISTOR DTC143TS (H170:AEP, H700)
Q10 8-729-900-80 TRANSISTOR DTC114ES
(H170:E, EA, AUS, H170K)
Q11 8-729-620-05 TRANSISTOR 2SC2603-EF
(H170:E, EA, AUS, H170K)
Q51 8-729-202-67 TRANSISTOR 2SK246-GR3
Q52 8-729-201-83 TRANSISTOR 2SC3112-A
Q53 8-729-202-67 TRANSISTOR 2SK246-GR3 (H170:AEP, H700)
Q54 8-729-201-83 TRANSISTOR 2SC3112 (H170:AEP, H700)
Q101 8-729-620-05 TRANSISTOR 2SC2603-EF

Q102 8-729-620-05 TRANSISTOR 2SC2603-EF
Q103 8-729-900-80 TRANSISTOR DTC114ES
Q201 8-729-202-67 TRANSISTOR 2SK246-GR3
Q202 8-729-141-26 TRANSISTOR 2SC3622A-LK
Q231 8-729-900-63 TRANSISTOR DTA124ES (H170K)

Q232 8-729-900-63 TRANSISTOR DTA124ES
Q233 8-729-119-76 TRANSISTOR 2SA1175-HFE
Q234 8-729-900-63 TRANSISTOR DTA124ES
Q235 8-729-900-63 TRANSISTOR DTA124ES (H170K)
Q236 8-729-900-80 TRANSISTOR DTC114ES (H170K)

Q237 8-729-620-05 TRANSISTOR 2SC2603-EF
Q251 8-729-202-67 TRANSISTOR 2SK246-GR3
Q252 8-729-141-26 TRANSISTOR 2SC3622A-LK
Q301 8-729-900-61 TRANSISTOR DTA114ES
Q302 8-729-900-61 TRANSISTOR DTA114ES

Remarks

Ref. No. Part No. Description

Remarks

Q901 8-729-620-05 TRANSISTOR 2SC2603-EF
Q903 8-729-209-15 TRANSISTOR 2SD2012
Q904 8-729-141-83 TRANSISTOR 2SB1094-LK
Q905 8-729-620-05 TRANSISTOR 2SC2603-EF
Q906 8-729-209-15 TRANSISTOR 2SD2012

Q907 8-729-209-15 TRANSISTOR 2SD2012
Q908 8-729-209-15 TRANSISTOR 2SD2012
Q911 8-729-900-80 TRANSISTOR DTC114ES
Q999 8-729-900-61 TRANSISTOR DTA114ES
Q8001 8-729-900-89 TRANSISTOR DTC144ES

Q9001 8-729-900-80 TRANSISTOR DTC114ES
Q9002 8-729-900-80 TRANSISTOR DTC114ES
Q9003 8-729-620-05 TRANSISTOR 2SC2603-EF

< RESISTOR >

R1 1-249-411-11 CARBON 330 5% 1/4W
R2 1-249-411-11 CARBON 330 5% 1/4W
R3 1-247-891-00 CARBON 330K 5% 1/4W
R4 1-249-411-11 CARBON 330 5% 1/4W
R7 1-249-405-11 CARBON 100 5% 1/4W

R8 1-249-441-11 CARBON 100K 5% 1/4W
R9 1-249-437-11 CARBON 47K 5% 1/4W
R10 1-249-429-11 CARBON 10K 5% 1/4W
R11 1-249-421-11 CARBON 2.2K 5% 1/4W
R12 1-249-421-11 CARBON 2.2K 5% 1/4W

R13 1-249-433-11 CARBON 22K 5% 1/4W
(H170:AEP, H700)
R14 1-249-432-11 CARBON 18K 5% 1/4W
(H170:AEP, H700)
R15 1-247-903-00 CARBON 1M 5% 1/4W
(H170:AEP, H700)

R20 1-249-425-11 CARBON 4.7K 5% 1/4W
R21 1-249-437-11 CARBON 47K 5% 1/4W
(H170:E, EA, AUS, H170K)
R31 1-249-429-11 CARBON 10K 5% 1/4W
R32 1-249-429-11 CARBON 10K 5% 1/4W
R39 1-247-903-00 CARBON 1M 5% 1/4W
(H170:E, EA, AUS, H170K)
R41 1-249-429-11 CARBON 10K 5% 1/4W
R48 1-249-429-11 CARBON 10K 5% 1/4W
(H170:E, EA, AUS, H170K)
R49 1-249-437-11 CARBON 47K 5% 1/4W
(H170:E, EA, AUS, H170K)

R50 1-249-417-11 CARBON 1K 5% 1/4W
R51 1-249-417-11 CARBON 1K 5% 1/4W
R52 1-249-417-11 CARBON 1K 5% 1/4W
R53 1-249-417-11 CARBON 1K 5% 1/4W
R54 1-249-417-11 CARBON 1K 5% 1/4W



R55 1-249-425-11 CARBON 4.7K 5% 1/4W
R56 1-249-405-11 CARBON 100 5% 1/4W
R57 1-249-401-11 CARBON 47 5% 1/4W
R58 1-249-423-11 CARBON 3.3K 5% 1/4W
R59 1-249-414-11 CARBON 560 5% 1/4W

MAIN (including POWER)

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
R60	1-249-417-11	CARBON	1K 5% 1/4W	R203	1-249-429-11	CARBON	10K 5% 1/4W
R61	1-249-410-11	CARBON	270 5% 1/4W	R204	1-249-429-11	CARBON	10K 5% 1/4W (H170K)
R62	1-249-425-11	CARBON	4. 7K 5% 1/4W	R205	1-247-903-00	CARBON	1M 5% 1/4W (H170K)
R63	1-249-421-11	CARBON	2. 2K 5% 1/4W	R206	1-249-427-11	CARBON	6. 8K 5% 1/4W
R64	1-249-425-11	CARBON	4. 7K 5% 1/4W	R209	1-247-903-00	CARBON	1M 5% 1/4W
R65	1-249-425-11	CARBON	4. 7K 5% 1/4W	R210	1-247-903-00	CARBON	1M 5% 1/4W
R66	1-249-405-11	CARBON	100 5% 1/4W	R211	1-247-903-00	CARBON	1M 5% 1/4W
R67	1-249-423-11	CARBON	3. 3K 5% 1/4W (H170:AEP, H700)	R212	1-247-903-00	CARBON	1M 5% 1/4W
R68	1-249-414-11	CARBON	560 5% 1/4W (H170:AEP, H700)	R213	1-247-903-00	CARBON	1M 5% 1/4W
R69	1-249-417-11	CARBON	1K 5% 1/4W (H170:AEP, H700)	R214	1-247-903-00	CARBON	1M 5% 1/4W
R70	1-249-410-11	CARBON	270 5% 1/4W (H170:AEP, H700)	R215	1-249-423-11	CARBON	3. 3K 5% 1/4W
R71	1-249-433-11	CARBON	22K 5% 1/4W (H170:AEP, H700)	R216	1-247-903-00	CARBON	1M 5% 1/4W
R72	1-249-421-11	CARBON	2. 2K 5% 1/4W (H170:AEP, H700)	R217	1-249-427-11	CARBON	6. 8K 5% 1/4W
R73	1-249-425-11	CARBON	4. 7K 5% 1/4W (H170:AEP, H700)	R221	1-249-441-11	CARBON	100K 5% 1/4W
R74	1-249-425-11	CARBON	4. 7K 5% 1/4W (H170:AEP, H700)	R222	1-249-441-11	CARBON	100K 5% 1/4W
R81	1-249-433-11	CARBON	22K 5% 1/4W	R227	1-247-887-00	CARBON	220K 5% 1/4W
R82	1-249-417-11	CARBON	1K 5% 1/4W	R228	1-247-887-00	CARBON	220K 5% 1/4W
R83	1-249-399-11	CARBON	33 5% 1/4W	R233	1-249-441-11	CARBON	100K 5% 1/4W
R84	1-249-429-11	CARBON	10K 5% 1/4W	R235	1-249-441-11	CARBON	100K 5% 1/4W
R85	1-249-429-11	CARBON	10K 5% 1/4W	R236	1-249-417-11	CARBON	1K 5% 1/4W
R86	1-249-437-11	CARBON	47K 5% 1/4W	R237	1-247-862-11	CARBON	20K 5% 1/4W
R87	1-249-409-11	CARBON	220 5% 1/4W	R240	1-249-433-11	CARBON	22K 5% 1/4W (H170K)
R88	1-249-429-11	CARBON	10K 5% 1/4W	R241	1-249-433-11	CARBON	22K 5% 1/4W
R89	1-249-429-11	CARBON	10K 5% 1/4W	R242	1-249-417-11	CARBON	1K 5% 1/4W
R90	1-249-421-11	CARBON	2. 2K 5% 1/4W	R243	1-249-417-11	CARBON	1K 5% 1/4W
R91	1-249-421-11	CARBON	2. 2K 5% 1/4W	R244	1-247-816-11	CARBON	240 5% 1/4W
R92	1-247-891-00	CARBON	330K 5% 1/4W	R245	1-249-433-11	CARBON	22K 5% 1/4W
R93	1-247-891-00	CARBON	330K 5% 1/4W	R246	1-247-903-00	CARBON	1M 5% 1/4W
R94	1-249-420-11	CARBON	1. 8K 5% 1/4W	R247	1-249-432-11	CARBON	18K 5% 1/4W
R95	1-249-420-11	CARBON	1. 8K 5% 1/4W	R248	1-249-437-11	CARBON	47K 5% 1/4W
R96	1-249-425-11	CARBON	4. 7K 5% 1/4W	R249	1-249-433-11	CARBON	22K 5% 1/4W (H170K)
R97	1-249-425-11	CARBON	4. 7K 5% 1/4W	R250	1-247-887-00	CARBON	220K 5% 1/4W
R98	1-249-404-00	CARBON	82 5% 1/4W	R251	1-249-429-11	CARBON	10K 5% 1/4W
R99	1-249-417-11	CARBON	1K 5% 1/4W	R252	1-247-862-11	CARBON	20K 5% 1/4W
R100	1-247-848-11	CARBON	5. 1K 5% 1/4W	R253	1-249-429-11	CARBON	10K 5% 1/4W
R102	1-249-430-11	CARBON	12K 5% 1/4W	R254	1-249-429-11	CARBON	10K 5% 1/4W (H170K)
R103	1-249-428-11	CARBON	8. 2K 5% 1/4W	R255	1-247-903-00	CARBON	1M 5% 1/4W (H170K)
R104	1-249-435-11	CARBON	33K 5% 1/4W	R256	1-249-427-11	CARBON	6. 8K 5% 1/4W
R108	1-249-417-11	CARBON	1K 5% 1/4W	R259	1-247-903-00	CARBON	1M 5% 1/4W
R142	1-249-417-11	CARBON	1K 5% 1/4W	R260	1-247-903-00	CARBON	1M 5% 1/4W
R143	1-249-431-11	CARBON	15K 5% 1/4W	R261	1-247-903-00	CARBON	1M 5% 1/4W
R144	1-249-393-11	CARBON	10 5% 1/4W	R262	1-247-903-00	CARBON	1M 5% 1/4W
R200	1-247-887-00	CARBON	220K 5% 1/4W	R263	1-247-903-00	CARBON	1M 5% 1/4W
R201	1-249-429-11	CARBON	10K 5% 1/4W	R264	1-247-903-00	CARBON	1M 5% 1/4W
R202	1-247-862-11	CARBON	20K 5% 1/4W	R265	1-249-423-11	CARBON	3. 3K 5% 1/4W
				R266	1-247-903-00	CARBON	1M 5% 1/4W
				R267	1-249-427-11	CARBON	6. 8K 5% 1/4W
				R271	1-249-441-11	CARBON	100K 5% 1/4W
				R272	1-249-441-11	CARBON	100K 5% 1/4W
				R277	1-247-887-00	CARBON	220K 5% 1/4W

MAIN (including POWER)

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
R278	1-247-887-00	CARBON	220K 5% 1/4W	R875	1-249-421-11	CARBON	2.2K 5% 1/4W
R283	1-249-441-11	CARBON	100K 5% 1/4W	R876	1-249-421-11	CARBON	2.2K 5% 1/4W
R285	1-249-441-11	CARBON	100K 5% 1/4W	△R877	1-212-881-11	FUSIBLE	100 5% 1/4W F
R287	1-247-862-11	CARBON	20K 5% 1/4W	R878	1-249-417-11	CARBON	1K 5% 1/4W
R290	1-249-437-11	CARBON	47K 5% 1/4W	R879	1-249-417-11	CARBON	1K 5% 1/4W
R294	1-249-442-11	CARBON	510 5% 1/4W	△R880	1-212-881-11	FUSIBLE	100 5% 1/4W F
R295	1-249-441-11	CARBON	100K 5% 1/4W (H170K)	R881	1-249-421-11	CARBON	2.2K 5% 1/4W
R296	1-249-441-11	CARBON	100K 5% 1/4W (H170K)	R882	1-249-421-11	CARBON	2.2K 5% 1/4W
R297	1-249-433-11	CARBON	22K 5% 1/4W	△R883	1-212-881-11	FUSIBLE	100 5% 1/4W F
R298	1-249-441-11	CARBON	100K 5% 1/4W	△R889	1-212-849-00	FUSIBLE	4.7 5% 1/4W F
R299	1-249-433-11	CARBON	22K 5% 1/4W (H170K)	R891	1-249-389-11	CARBON	4.7 5% 1/4W
R301	1-249-417-11	CARBON	1K 5% 1/4W	R892	1-249-389-11	CARBON	4.7 5% 1/4W
R302	1-249-437-11	CARBON	47K 5% 1/4W	△R900	1-212-934-00	FUSIBLE	1 5% 1/2W F
R303	1-249-437-11	CARBON	47K 5% 1/4W (H170:AEP, H700)	△R901	1-212-950-00	FUSIBLE	4.7 5% 1/2W F
R304	1-247-897-11	CARBON	560K 5% 1/4W (H170:AEP, H700)	△R902	1-219-108-11	FUSIBLE	1.5 5% 1W F
R305	1-249-417-11	CARBON	1K 5% 1/4W (H170:AEP, H700)	R903	1-247-903-00	CARBON	1M 5% 1/4W
R306	1-249-417-11	CARBON	1K 5% 1/4W	R904	1-249-405-11	CARBON	100 5% 1/4W
R307	1-249-437-11	CARBON	47K 5% 1/4W	R905	1-249-432-11	CARBON	18K 5% 1/4W
R308	1-249-417-11	CARBON	1K 5% 1/4W	R906	1-247-842-11	CARBON	3K 5% 1/4W
R309	1-249-417-11	CARBON	1K 5% 1/4W	R907	1-249-431-11	CARBON	15K 5% 1/4W
R310	1-249-417-11	CARBON	1K 5% 1/4W	R908	1-247-854-11	CARBON	9.1K 5% 1/4W
R340	1-249-433-11	CARBON	22K 5% 1/4W	△R909	1-219-153-11	FUSIBLE	10 5% 1/4W F
R341	1-249-433-11	CARBON	22K 5% 1/4W	R910	1-249-417-11	CARBON	1K 5% 1/4W
R351	1-249-417-11	CARBON	1K 5% 1/4W	R911	1-249-417-11	CARBON	1K 5% 1/4W
R352	1-249-437-11	CARBON	47K 5% 1/4W	△R913	1-212-942-00	FUSIBLE	2.2 5% 1/2W F
R353	1-249-437-11	CARBON	47K 5% 1/4W (H170:AEP, H700)	R914	1-249-423-11	CARBON	3.3K 5% 1/4W
R354	1-247-897-11	CARBON	560K 5% 1/4W (H170:AEP, H700)	R921	1-249-429-11	CARBON	10K 5% 1/4W
R355	1-249-417-11	CARBON	1K 5% 1/4W (H170:AEP, H700)	R922	1-249-441-11	CARBON	100K 5% 1/4W
R356	1-249-417-11	CARBON	1K 5% 1/4W	R923	1-249-429-11	CARBON	10K 5% 1/4W
R357	1-249-437-11	CARBON	47K 5% 1/4W	△R924	1-217-637-00	FUSIBLE	1 5% 1/4W F
R358	1-249-417-11	CARBON	1K 5% 1/4W	R927	1-249-417-11	CARBON	1K 5% 1/4W
R359	1-249-417-11	CARBON	1K 5% 1/4W	R928	1-249-417-11	CARBON	1K 5% 1/4W
R360	1-249-417-11	CARBON	1K 5% 1/4W	R952	1-247-903-00	CARBON	1M 5% 1/4W
R407	1-247-887-00	CARBON	220K 5% 1/4W	R953	1-247-903-00	CARBON	1M 5% 1/4W
R457	1-247-887-00	CARBON	220K 5% 1/4W	R954	1-247-903-00	CARBON	1M 5% 1/4W
R486	1-249-413-11	CARBON	470 5% 1/4W	R955	1-249-429-11	CARBON	10K 5% 1/4W
R801	1-249-417-11	CARBON	1K 5% 1/4W	△R999	9-910-999-33	FUSIBLE	0.22 5% 1/4W F
R802	1-249-438-11	CARBON	56K 5% 1/4W	R2001	1-249-441-11	CARBON	100K 5% 1/4W (H170, H700)
R803	1-249-413-11	CARBON	470 5% 1/4W	R2002	1-249-421-11	CARBON	2.2K 5% 1/4W
R804	1-249-438-11	CARBON	56K 5% 1/4W	R2003	1-249-433-11	CARBON	22K 5% 1/4W
R851	1-249-417-11	CARBON	1K 5% 1/4W	R2004	1-249-433-11	CARBON	22K 5% 1/4W
R852	1-249-438-11	CARBON	56K 5% 1/4W	R2052	1-249-421-11	CARBON	2.2K 5% 1/4W
R853	1-249-413-11	CARBON	470 5% 1/4W	R8001	1-249-417-11	CARBON	1K 5% 1/4W
R854	1-249-438-11	CARBON	56K 5% 1/4W	R9001	1-249-429-11	CARBON	10K 5% 1/4W
R871	1-249-429-11	CARBON	10K 5% 1/4W	R9002	1-249-429-11	CARBON	10K 5% 1/4W
R872	1-249-437-11	CARBON	47K 5% 1/4W	R9003	1-249-429-11	CARBON	10K 5% 1/4W
R873	1-249-429-11	CARBON	10K 5% 1/4W	R9004	1-249-429-11	CARBON	10K 5% 1/4W
R874	1-247-883-00	CARBON	150K 5% 1/4W				

Note: The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

MAIN (including POWER)

MD-A

MD-B

Ref. No. Part No. Description Remarks

< VARIABLE RESISTOR >

RV81 1-238-601-11 RES, ADJ, CARBON 22K
RV82 1-238-601-11 RES, ADJ, CARBON 22K
RV406 1-241-877-11 RES, VAR, CARBON 100K X2(VOLUME)

< COIL >

T1 1-402-424-11 COIL (ANT, SW3) (H170:E, EA, AUS, H170K)
T2 1-406-346-11 COIL (OSC, SW3) (H170:E, EA, AUS, H170K)

< TERMINAL >

* TB1 1-537-138-31 TERMINAL BOARD (ANT) (H170:AEP, H700)
TB1 1-537-238-21 TERMINAL BOARD (H170:E, EA, AUS, H170K)
* TB2 4-925-530-01 PLATE, GROUND (H170, H170K)
* TB3 4-942-204-01 PLATE, GROUND
TM301 1-537-238-11 TERMINAL BOARD (SPEAKER)

< TEST PIN >

* TP81 1-568-449-11 HOUSING, CONNECTOR(PC BOARD)3P

< VIBRATOR >

X51 1-577-126-11 VIBRATOR, CRYSTAL 7.2MHz
X81 1-577-075-11 OSCILLATOR, CERAMIC 456kHz

* A-2006-399-A MD-A BOARD (RA13A)

< CAPACITOR >

C11 1-163-131-00 CERAMIC CHIP 390PF 5% 50V
C12 1-136-157-00 FILM 0.022uF 5% 50V
C13 1-124-234-00 ELECT 22uF 20% 16V
C18 1-163-117-00 CERAMIC CHIP 100PF 5% 50V
C21 1-163-131-00 CERAMIC CHIP 390PF 5% 50V

C22 1-136-157-00 FILM 0.022uF 5% 50V
C23 1-124-234-00 ELECT 22uF 20% 16V
C28 1-163-117-00 CERAMIC CHIP 100PF 5% 50V
C31 1-124-234-00 ELECT 22uF 20% 16V
C32 1-124-234-00 ELECT 22uF 20% 16V

C71 1-124-499-11 ELECT, NONPOLAR R 1uF 20% 50V

< JACK >

* CNJ31 1-580-782-11 CONNECTOR, BOARD TO BOARD
* CNJ72 1-580-411-11 SOCKET, CONNECTOR 4P

< CONNECTOR >

* CNP32 1-580-772-11 PIN, CONNECTOR (PC BOARD) 4P
* CNP71 1-564-719-11 PIN, CONNECTOR (SMALL TYPE) 3P

Ref. No. Part No. Description Remarks

< IC >

IC31A 8-759-106-02 IC uPC4570G2

< JUMPER RESISTOR >

JW1 1-216-295-00 METAL CHIP 0 5% 1/10W
JW51 1-216-296-00 METAL CHIP 0 5% 1/8W
JW52 1-216-296-00 METAL CHIP 0 5% 1/8W
JW53 1-216-296-00 METAL CHIP 0 5% 1/8W
JW54 1-216-296-00 METAL CHIP 0 5% 1/8W

< TRANSISTOR >

Q71A 8-729-602-36 TRANSISTOR 2SA1602

< RESISTOR >

R11 1-216-099-00 METAL CHIP 120K 5% 1/10W
R12 1-216-025-00 METAL CHIP 100 5% 1/10W
R13 1-216-100-00 METAL GLAZE 130K 5% 1/10W
R14 1-216-067-00 METAL CHIP 5.6K 5% 1/10W
R21 1-216-099-00 METAL CHIP 120K 5% 1/10W

R22 1-216-025-00 METAL CHIP 100 5% 1/10W
R23 1-216-100-00 METAL GLAZE 130K 5% 1/10W
R24 1-216-067-00 METAL CHIP 5.6K 5% 1/10W
R31 1-216-033-00 METAL CHIP 220 5% 1/10W
R32 1-216-033-00 METAL CHIP 220 5% 1/10W

R71 1-216-082-00 METAL GLAZE 24K 5% 1/10W
R72 1-216-081-00 METAL CHIP 22K 5% 1/10W
R73 1-216-089-00 METAL CHIP 47K 5% 1/10W
R74 1-216-089-00 METAL CHIP 47K 5% 1/10W

< VARIABLE RESISTOR >

RV11A 1-238-012-11 RES, ADJ, CARBON 1K
RV21A 1-238-012-11 RES, ADJ, CARBON 1K
RV71A 1-238-016-11 RES, ADJ, CARBON 10K
RV72A 1-238-016-11 RES, ADJ, CARBON 10K

A-2006-400-A MD-B BOARD (RB22A)

< CAPACITOR >

C11 1-163-131-00 CERAMIC CHIP 390PF 5% 50V
C12 1-136-157-00 FILM 0.022uF 5% 50V
C13 1-124-234-00 ELECT 22uF 20% 16V
C14 1-136-273-91 FILM 75PF 5% 630V
C15 1-164-080-11 CERAMIC 390PF 10% 50V

C17 1-163-103-00 CERAMIC CHIP 27PF 5% 50V
C18 1-163-117-00 CERAMIC CHIP 100PF 5% 50V
C21 1-163-131-00 CERAMIC CHIP 390PF 5% 50V
C22 1-136-157-00 FILM 0.022uF 5% 50V
C23 1-124-234-00 ELECT 22uF 20% 16V

MD-B

Ref. No.	Part No.	Description			
C24	1-136-273-91	FILM	75PF	5%	630V
C25	1-164-080-11	CERAMIC	390PF	10%	50V
C27	1-163-103-00	CERAMIC CHIP	27PF	5%	50V
C28	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C31	1-124-234-00	ELECT	22uF	20%	16V

C32	1-124-234-00	ELECT	22uF	20%	16V
C33	1-124-234-00	ELECT	22uF	20%	16V
C51	1-163-019-00	CERAMIC CHIP	0.0068uF	10%	50V
C52	1-163-019-00	CERAMIC CHIP	0.0068uF	10%	50V
C53	1-163-022-00	CERAMIC CHIP	0.012uF	10%	50V

C54	1-136-559-11	FILM	0.0047uF	5%	630V
C56	1-164-505-11	CERAMIC CHIP	2.2uF		16V
C57	1-164-346-11	CERAMIC CHIP	1uF		16V
C58	1-163-024-00	CERAMIC CHIP	0.018uF	10%	50V
C71	1-124-499-11	ELECT, NONPOLAR	1uF	20%	50V

< JACK >

* CNJ31	1-580-782-11	CONNECTOR, BOARD TO BOARD
* CNJ33	1-580-782-11	CONNECTOR, BOARD TO BOARD
* CNJ72	1-580-411-11	SOCKET, CONNECTOR 4P

< CONNECTOR >

* CNP32	1-580-781-11	PIN, CONNECTOR (PC BOARD) 7P
* CNP71	1-564-719-11	PIN, CONNECTOR (SMALL TYPE) 3P

< DIODE >

D31	8-719-016-74	DIODE	1SS352
-----	--------------	-------	--------

< IC >

IC31B	8-759-106-02	IC	uPC4570G2
-------	--------------	----	-----------

< JUMPER RESISTOR >

JW1	1-216-296-00	METAL CHIP	0	5%	1/8W
JW2	1-216-295-00	METAL CHIP	0	5%	1/10W
JW3	1-216-295-00	METAL CHIP	0	5%	1/10W
JW4	1-216-295-00	METAL CHIP	0	5%	1/10W
JW5	1-216-295-00	METAL CHIP	0	5%	1/10W
JW6	1-216-295-00	METAL CHIP	0	5%	1/10W
JW7	1-216-295-00	METAL CHIP	0	5%	1/10W
JW52	1-216-296-00	METAL CHIP	0	5%	1/8W
JW53	1-216-296-00	METAL CHIP	0	5%	1/8W
JW54	1-216-296-00	METAL CHIP	0	5%	1/8W
JW55	1-216-296-00	METAL CHIP	0	5%	1/8W
JW56	1-216-296-00	METAL CHIP	0	5%	1/8W
JW57	1-216-296-00	METAL CHIP	0	5%	1/8W
JW58	1-216-296-00	METAL CHIP	0	5%	1/8W
JW59	1-216-296-00	METAL CHIP	0	5%	1/8W
JW60	1-216-296-00	METAL CHIP	0	5%	1/8W
JW61	1-216-296-00	METAL CHIP	0	5%	1/8W

Remarks

Ref. No. Part No. Description

< COIL >

L11	1-410-780-11	INDUCTOR	27mH
L21	1-410-780-11	INDUCTOR	27mH

< TRANSISTOR >

Q51	8-729-808-01	TRANSISTOR	2SD1622-S
Q52	8-729-808-01	TRANSISTOR	2SD1622-S
Q53	8-729-808-01	TRANSISTOR	2SD1622-S
Q71B	8-729-802-36	TRANSISTOR	2SA1602

< RESISTOR >

R11	1-216-099-00	METAL CHIP	120K	5%	1/10W
R12	1-216-025-00	METAL CHIP	100	5%	1/10W
R13	1-216-100-00	METAL GLAZE	130K	5%	1/10W
R14	1-216-067-00	METAL CHIP	5.6K	5%	1/10W
R15	1-249-430-11	CARBON	12K	5%	1/4W
R21	1-216-099-00	METAL CHIP	120K	5%	1/10W
R22	1-216-025-00	METAL CHIP	100	5%	1/10W
R23	1-216-100-00	METAL GLAZE	130K	5%	1/10W
R24	1-216-067-00	METAL CHIP	5.6K	5%	1/10W
R25	1-249-430-11	CARBON	12K	5%	1/4W
R31	1-216-033-00	METAL CHIP	220	5%	1/10W
R32	1-216-033-00	METAL CHIP	220	5%	1/10W
R41	1-249-393-11	CARBON	10	5%	1/4W
R42	1-249-393-11	CARBON	10	5%	1/4W
R51	1-216-075-00	METAL CHIP	12K	5%	1/10W
R52	1-216-075-00	METAL CHIP	12K	5%	1/10W
R53	1-216-073-00	METAL CHIP	10K	5%	1/10W
R54	1-216-309-00	METAL CHIP	5.6	5%	1/10W
R55	1-216-309-00	METAL CHIP	5.6	5%	1/10W
R56	1-216-298-00	METAL CHIP	2.2	5%	1/10W
R71	1-216-082-00	METAL GLAZE	24K	5%	1/10W
R72	1-216-081-00	METAL CHIP	22K	5%	1/10W
R73	1-216-089-00	METAL CHIP	47K	5%	1/10W
R74	1-216-089-00	METAL CHIP	47K	5%	1/10W

< VARIABLE RESISTOR >

RV11B	1-238-012-11	RES, ADJ, CARBON	1K
RV12	1-238-551-11	RES, ADJ, CARBON	220K
RV21B	1-238-012-11	RES, ADJ, CARBON	1K
RV22	1-238-551-11	RES, ADJ, CARBON	220K
RV71B	1-238-016-11	RES, ADJ, CARBON	10K
RV72B	1-238-016-11	RES, ADJ, CARBON	10K

< RELAY >

RY31	1-515-726-11	RELAY
------	--------------	-------

< TRANSFORMER >

T51	1-406-419-11	COIL, BIAS OSCILLATION
-----	--------------	------------------------

SUB (including POWER TRANSFORMER/VOLUME/MIC HP/SW)

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
*	A-4343-549-A	SUB BOARD, COMPLETE (H170:E, EA) *****		C426	1-124-478-11	ELECT 100uF 20% 25V	
*	A-4343-550-A	SUB BOARD, COMPLETE (H170:AEP, H700) *****		C427	1-124-478-11	ELECT 100uF 20% 25V	
*	A-4343-552-A	SUB BOARD, COMPLETE (H170K) *****		C428	1-163-141-00	CERAMIC CHIP 0.001uF 5% 50V	
*	A-4343-573-A	SUB BOARD, COMPLETE (H170:AUS) *****		C429	1-126-926-11	ELECT 1000uF 20% 10V	
*	1-705-409-11	SUB COMBINED BOARD		C603	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V(H170K)	
< CAPACITOR >				C604	1-126-101-11	ELECT 100uF 20% 16V(H170K)	
C201	1-163-986-00	CERAMIC CHIP 0.027uF 10% 25V		C605	1-126-101-11	ELECT 100uF 20% 16V(H170K)	
C202	1-163-133-00	CERAMIC CHIP 470PF 5% 50V		C606	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V(H170K)	
C203	1-124-254-00	ELECT 0.68uF 20% 50V		C607	1-124-589-11	ELECT 47uF 20% 16V(H170K)	
C204	1-163-133-00	CERAMIC CHIP 470PF 5% 50V		C608	1-163-017-00	CERAMIC CHIP 0.0047uF 5% 50V(H170K)	
C205	1-124-257-00	ELECT 2.2uF 20% 50V		C609	1-124-611-00	ELECT 1uF 20% 50V(H170K)	
C206	1-163-117-00	CERAMIC CHIP 100PF 5% 50V		C610	1-163-018-00	CERAMIC CHIP 0.0056uF 5% 50V(H170K)	
C207	1-126-157-11	ELECT 10uF 20% 16V		C611	1-124-903-11	ELECT 1uF 20% 50V(H170K)	
C208	1-164-005-11	CERAMIC CHIP 0.47uF 25V		C612	1-164-232-11	CERAMIC CHIP 0.01uF 50V(H170K)	
C209	1-124-257-00	ELECT 2.2uF 20% 50V		C613	1-163-010-11	CERAMIC CHIP 0.0012uF 10% 50V(H170K)	
C301	1-163-986-00	CERAMIC CHIP 0.027uF 10% 25V		C614	1-124-903-11	ELECT 1uF 20% 50V(H170K)	
C302	1-163-133-00	CERAMIC CHIP 470PF 5% 50V		C615	1-163-018-00	CERAMIC CHIP 0.0056uF 5% 50V(H170K)	
C303	1-124-254-00	ELECT 0.68uF 20% 50V		C617	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V(H170K)	
C304	1-163-133-00	CERAMIC CHIP 470PF 5% 50V		C618	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V(H170K)	
C305	1-124-257-00	ELECT 2.2uF 20% 50V		C619	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V(H170K)	
C306	1-163-117-00	CERAMIC CHIP 100PF 5% 50V		C620	1-164-232-11	CERAMIC CHIP 0.01uF 50V(H170K)	
C307	1-126-157-11	ELECT 10uF 20% 16V		C621	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V(H170K)	
C308	1-164-005-11	CERAMIC CHIP 0.47uF 25V		C622	1-164-232-11	CERAMIC CHIP 0.01uF 50V(H170K)	
C309	1-124-257-00	ELECT 2.2uF 20% 50V		C623	1-163-117-00	CERAMIC CHIP 100PF 5% 50V	
C401	1-126-933-11	ELECT 100uF 20% 16V		C624	1-124-903-11	ELECT 1uF 20% 50V	
C402	1-163-038-00	CERAMIC CHIP 0.1uF 25V		C625	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V	
C403	1-163-038-00	CERAMIC CHIP 0.1uF 25V		C626	1-124-903-11	ELECT 1uF 20% 50V	
C404	1-124-443-00	ELECT 100uF 20% 10V		C627	1-163-117-00	CERAMIC CHIP 100PF 5% 50V(H170K)	
C405	1-124-443-00	ELECT 100uF 20% 10V		C628	1-124-903-11	ELECT 1uF 20% 50V(H170K)	
C407	1-124-257-00	ELECT 2.2uF 20% 50V		C629	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V(H170K)	
C408	1-163-117-00	CERAMIC CHIP 100PF 5% 50V		C630	1-124-903-11	ELECT 1uF 20% 50V(H170K)	
C409	1-164-222-11	CERAMIC CHIP 0.22uF 25V		C631	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C410	1-164-222-11	CERAMIC CHIP 0.22uF 25V		C632	1-163-117-00	CERAMIC CHIP 100PF 5% 50V	
C411	1-163-141-00	CERAMIC CHIP 0.001uF 5% 50V		C633	1-163-005-11	CERAMIC CHIP 470PF 10% 50V	
C412	1-124-903-11	ELECT 1uF 20% 50V		C636	1-126-157-11	ELECT 10uF 20% 16V	
C413	1-124-443-00	ELECT 100uF 20% 10V		C637	1-163-117-00	CERAMIC CHIP 100PF 5% 50V	
C414	1-124-443-00	ELECT 100uF 20% 10V		C638	1-126-101-11	ELECT 100uF 20% 16V	
C415	1-163-038-00	CERAMIC CHIP 0.1uF 25V		C639	1-126-157-11	ELECT 10uF 20% 16V	
C416	1-163-038-00	CERAMIC CHIP 0.1uF 25V		C640	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C417	1-124-482-11	ELECT 33uF 20% 35V		C641	1-164-232-11	CERAMIC CHIP 0.01uF 50V(H170K)	
C419	1-126-926-11	ELECT 1000uF 20% 10V		C681	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C420	1-163-038-00	CERAMIC CHIP 0.1uF 25V		C682	1-163-117-00	CERAMIC CHIP 100PF 5% 50V	
C421	1-163-117-00	CERAMIC CHIP 100PF 5% 50V		C683	1-163-005-11	CERAMIC CHIP 470PF 10% 50V	
C422	1-163-117-00	CERAMIC CHIP 100PF 5% 50V		C686	1-126-157-11	ELECT 10uF 20% 16V	
C424	1-163-133-00	CERAMIC CHIP 470PF 5% 50V		C687	1-163-117-00	CERAMIC CHIP 100PF 5% 50V	
C425	1-163-133-00	CERAMIC CHIP 470PF 5% 50V		C689	1-126-157-11	ELECT 10uF 20% 16V	
				C691	1-124-604-00	ELECT 330uF 20% 10V	
				C692	1-124-604-00	ELECT 330uF 20% 10V	
				C4001	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
				C4002	1-164-232-11	CERAMIC CHIP 0.01uF 50V	

SUB (including POWER TRANSFORMER/VOLUME/MIC HP/SW)

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
C4003	1-164-005-11	CERAMIC CHIP 0.47uF	25V	IC404	8-759-916-25	IC SN74HC32AN	
< CONNECTOR >				IC405	8-759-520-90	IC PST572E	
CN402	1-573-101-11	SOCKET, CONNECTOR 9P		IC601	8-759-636-22	IC M50197FP (H170K)	
CN403	1-580-783-11	CONNECTOR, BOARD TO BOARD		IC602	8-759-636-55	IC M5218AFP	
CN404	1-573-101-11	SOCKET, CONNECTOR 9P		< JACK >			
CN405	1-580-783-11	CONNECTOR, BOARD TO BOARD		J601	1-562-837-21	JACK (HEADPHONES)	
CN406	1-580-783-11	CONNECTOR, BOARD TO BOARD		J602	1-562-837-21	JACK (MIC1)	
* CN407	1-566-970-11	HOUSING, CONNECTOR(PC BOARD)8P		J603	1-562-837-21	JACK (MIC2) (H170K)	
* CN408	1-566-970-11	HOUSING, CONNECTOR(PC BOARD)8P		< COIL >			
CN410	1-695-068-11	CONNECTOR, FFC/FPC 15P		L403	1-410-482-31	INDUCTOR 100uH	
* CN601	1-568-454-11	PIN, CONNECTOR (PC BOARD) 9P		L404	1-410-482-31	INDUCTOR 100uH	
* CN602	1-573-100-11	SOCKET, CONNECTOR 4P		< TRANSISTOR >			
* CN851	1-564-321-00	PIN, CONNECTOR 2P		Q201	8-729-900-80	TRANSISTOR DTC114ES	
* CN852	1-569-508-11	PIN, CONNECTOR 8P		Q202	8-729-620-05	TRANSISTOR 2SC2603-EF	
* CN1501	1-691-894-11	CONNECTOR, FFC/FPC 15P		Q301	8-729-900-80	TRANSISTOR DTC114ES	
< DIODE >				Q302	8-729-620-05	TRANSISTOR 2SC2603-EF	
D401	8-719-210-33	DIODE EC10DS2		Q401	8-729-804-41	TRANSISTOR 2SB1122-S	
D403	8-719-801-78	DIODE 1SS184		Q402	8-729-804-41	TRANSISTOR 2SB1122-S	
D404	8-719-021-41	DIODE UZM5.6X		Q403	8-729-900-61	TRANSISTOR DTA114ES	
D405	8-719-021-77	DIODE UZM8.2Z		Q404	8-729-900-80	TRANSISTOR DTC114ES	
D407	8-719-801-78	DIODE 1SS184		Q405	8-729-900-61	TRANSISTOR DTA114ES	
D410	8-719-801-78	DIODE 1SS184		Q406	8-729-900-61	TRANSISTOR DTA114ES	
D411	8-719-801-78	DIODE 1SS184		Q407	8-729-900-61	TRANSISTOR DTA114ES	
D412	8-719-801-78	DIODE 1SS184		Q408	8-729-900-80	TRANSISTOR DTC114ES	
D414	8-719-210-33	DIODE EC10DS2		Q409	8-729-900-65	TRANSISTOR DTA114ES	
D416	8-719-801-78	DIODE 1SS184		Q410	8-729-900-65	TRANSISTOR DTA114ES	
D601	8-719-303-65	DIODE SEL4510-D (H170K)		Q411	8-729-900-80	TRANSISTOR DTC114ES	
D602	8-719-303-65	DIODE SEL4510-D (H170K)		Q412	8-729-900-61	TRANSISTOR DTA114ES	
D810	8-719-312-09	DIODE RBA-402		Q413	8-729-900-80	TRANSISTOR DTC114ES	
D1501	8-719-026-66	DIODE SML1460E		Q414	8-729-900-80	TRANSISTOR DTC114ES	
D1502	8-719-026-66	DIODE SML1460E		Q415	8-729-900-61	TRANSISTOR DTA114ES	
D1503	8-719-026-64	DIODE SML1260S		Q602	8-729-620-05	TRANSISTOR 2SC2603-EF	
D1504	8-719-026-64	DIODE SML1260S		Q603	8-729-620-05	TRANSISTOR 2SC2603-EF (H170K)	
D1506	8-719-026-64	DIODE SML1260S		< RESISTOR >			
D1507	8-719-026-66	DIODE SML1460E		R201	1-216-089-00	METAL CHIP 47K 5% 1/10W	
D1508	8-719-026-66	DIODE SML1460E		R202	1-216-089-00	METAL CHIP 47K 5% 1/10W	
D1509	8-719-026-68	DIODE SML1960A		R203	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
D4001	8-719-801-78	DIODE 1SS184		R204	1-216-063-00	METAL CHIP 3.9K 5% 1/10W	
< IC >				R205	1-216-105-00	METAL CHIP 220K 5% 1/10W	
IC201	8-759-516-43	IC CD4053BCM		R206	1-216-025-00	METAL CHIP 100 5% 1/10W	
IC202	8-752-050-13	IC CXA1101M		R207	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
IC203	8-759-996-43	IC RC4558PS		R208	1-216-105-00	METAL CHIP 220K 5% 1/10W	
IC204	8-759-516-47	IC CD4066BCM		R209	1-216-097-00	METAL CHIP 100K 5% 1/10W	
IC205	8-752-055-60	IC CXA1578M		R210	1-216-066-00	METAL CHIP 5.1K 5% 1/10W	
IC401	8-759-061-36	IC M50964-302					
IC402	8-759-207-05	IC TA7272P					
IC403	8-759-996-43	IC RC4558PS					

SUB (including POWER TRANSFORMER/VOLUME/MIC HP/SW)

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
R211	1-216-025-00	METAL CHIP	100 5% 1/10W	R431	1-216-080-00	METAL CHIP	20K 5% 1/10W
R212	1-216-057-00	METAL CHIP	2. 2K 5% 1/10W	R432	1-216-090-00	METAL CHIP	51K 5% 1/10W
R213	1-216-081-00	METAL CHIP	22K 5% 1/10W	R433	1-216-025-00	METAL CHIP	100 5% 1/10W
R214	1-216-089-00	METAL CHIP	47K 5% 1/10W	R434	1-216-121-00	METAL CHIP	1M 5% 1/10W
R215	1-216-065-00	METAL CHIP	4. 7K 5% 1/10W	R435	1-216-073-00	METAL CHIP	10K 5% 1/10W
R301	1-216-089-00	METAL CHIP	47K 5% 1/10W	R436	1-216-065-00	METAL CHIP	4. 7K 5% 1/10W
R302	1-216-089-00	METAL CHIP	47K 5% 1/10W	R437	1-216-073-00	METAL CHIP	10K 5% 1/10W
R303	1-216-057-00	METAL CHIP	2. 2K 5% 1/10W	R438	1-216-073-00	METAL CHIP	10K 5% 1/10W
R304	1-216-063-00	METAL CHIP	3. 9K 5% 1/10W	R440	1-216-057-00	METAL CHIP	2. 2K 5% 1/10W
R305	1-216-105-00	METAL CHIP	220K 5% 1/10W	R441	1-216-041-00	METAL CHIP	470 5% 1/10W
R306	1-216-025-00	METAL CHIP	100 5% 1/10W	R444	1-216-073-00	METAL CHIP	10K 5% 1/10W
R307	1-216-057-00	METAL CHIP	2. 2K 5% 1/10W	R445	1-216-073-00	METAL CHIP	10K 5% 1/10W
R308	1-216-105-00	METAL CHIP	220K 5% 1/10W	R446	1-216-097-00	METAL CHIP	100K 5% 1/10W
R309	1-216-097-00	METAL CHIP	100K 5% 1/10W	R447	1-216-065-00	METAL CHIP	4. 7K 5% 1/10W
R310	1-216-066-00	METAL CHIP	5. 1K 5% 1/10W	R448	1-216-089-00	METAL CHIP	47K 5% 1/10W
R311	1-216-025-00	METAL CHIP	100 5% 1/10W	R449	1-216-113-00	METAL CHIP	470K 5% 1/10W
R312	1-216-057-00	METAL CHIP	2. 2K 5% 1/10W	R450	1-216-057-00	METAL CHIP	2. 2K 5% 1/10W
R313	1-216-081-00	METAL CHIP	22K 5% 1/10W	R451	1-216-097-00	METAL CHIP	100K 5% 1/10W
R314	1-216-089-00	METAL CHIP	47K 5% 1/10W	R452	1-216-097-00	METAL CHIP	100K 5% 1/10W
R315	1-216-065-00	METAL CHIP	4. 7K 5% 1/10W	R453	1-216-065-00	METAL CHIP	4. 7K 5% 1/10W
R401	1-216-037-00	METAL CHIP	330 5% 1/10W	R454	1-216-097-00	METAL CHIP	100K 5% 1/10W
R402	1-216-037-00	METAL CHIP	330 5% 1/10W	R455	1-216-089-00	METAL CHIP	47K 5% 1/10W
R403	1-216-037-00	METAL CHIP	330 5% 1/10W	R456	1-216-089-00	METAL CHIP	47K 5% 1/10W
R404	1-216-057-00	METAL CHIP	2. 2K 5% 1/10W	R457	1-216-089-00	METAL CHIP	47K 5% 1/10W
R405	1-216-057-00	METAL CHIP	2. 2K 5% 1/10W	R458	1-216-088-00	METAL CHIP	43K 5% 1/10W
R406	1-216-113-00	METAL CHIP	470K 5% 1/10W	R459	1-216-089-00	METAL CHIP	47K 5% 1/10W
R407	1-216-113-00	METAL CHIP	470K 5% 1/10W	R460	1-216-065-00	METAL CHIP	4. 7K 5% 1/10W
R408	1-216-073-00	METAL CHIP	10K 5% 1/10W	R461	1-216-081-00	METAL CHIP	22K 5% 1/10W
R409	1-216-073-00	METAL CHIP	10K 5% 1/10W	R462	1-216-082-00	METAL GLAZE	24K 5% 1/10W
R410	1-216-045-00	METAL CHIP	680 5% 1/10W	R463	1-216-073-00	METAL CHIP	10K 5% 1/10W
R411	1-216-037-00	METAL CHIP	330 5% 1/10W	R464	1-216-073-00	METAL CHIP	10K 5% 1/10W
R412	1-216-073-00	METAL CHIP	10K 5% 1/10W	R466	1-216-025-00	METAL CHIP	100 5% 1/10W
R413	1-216-045-00	METAL CHIP	680 5% 1/10W	R467	1-216-025-00	METAL CHIP	100 5% 1/10W
R414	1-216-073-00	METAL CHIP	10K 5% 1/10W	R470	1-216-073-00	METAL CHIP	10K 5% 1/10W
R415	1-216-083-00	METAL CHIP	27K 5% 1/10W	R471	1-216-073-00	METAL CHIP	10K 5% 1/10W
R416	1-216-073-00	METAL CHIP	10K 5% 1/10W	R472	1-216-073-00	METAL CHIP	10K 5% 1/10W
R417	1-216-083-00	METAL CHIP	27K 5% 1/10W	R473	1-216-073-00	METAL CHIP	10K 5% 1/10W
R418	1-216-085-00	METAL CHIP	33K 5% 1/10W	R474	1-216-073-00	METAL CHIP	10K 5% 1/10W
R419	1-216-084-00	METAL CHIP	30K 5% 1/10W	R475	1-216-065-00	METAL CHIP	4. 7K 5% 1/10W
R420	1-216-089-00	METAL CHIP	47K 5% 1/10W	R601	1-216-073-00	METAL CHIP	10K 5% 1/10W(H170K)
R421	1-216-065-00	METAL CHIP	4. 7K 5% 1/10W	R602	1-216-077-00	METAL CHIP	15K 5% 1/10W(H170K)
R422	1-216-090-00	METAL CHIP	51K 5% 1/10W	R603	1-216-077-00	METAL CHIP	15K 5% 1/10W(H170K)
R423	1-216-080-00	METAL CHIP	20K 5% 1/10W	R604	1-216-083-00	METAL CHIP	27K 5% 1/10W(H170K)
R424	1-216-090-00	METAL CHIP	51K 5% 1/10W	R605	1-216-060-00	METAL GLAZE	3K 5% 1/10W(H170K)
R425	1-216-025-00	METAL CHIP	100 5% 1/10W	R606	1-216-059-00	METAL CHIP	2. 7K 5% 1/10W(H170K)
R426	1-216-065-00	METAL CHIP	4. 7K 5% 1/10W	R607	1-216-077-00	METAL CHIP	15K 5% 1/10W(H170K)
R427	1-216-085-00	METAL CHIP	33K 5% 1/10W	R608	1-216-077-00	METAL CHIP	15K 5% 1/10W(H170K)
R428	1-216-089-00	METAL CHIP	47K 5% 1/10W	R609	1-216-073-00	METAL CHIP	10K 5% 1/10W(H170K)
R429	1-216-090-00	METAL CHIP	51K 5% 1/10W	R610	1-216-070-00	METAL CHIP	7. 5K 5% 1/10W(H170K)
R430	1-216-084-00	METAL CHIP	30K 5% 1/10W	R611	1-216-094-00	METAL GLAZE	75K 5% 1/10W(H170K)

SUB (including POWER TRANSFORMER/VOLUME/MIC HP/SW)

Ref. No.	Part No.	Description	Remarks
R612	1-216-070-00	METAL CHIP 7.5K 5% 1/10W(H170K)	
R613	1-216-094-00	METAL GLAZE 75K 5% 1/10W(H170K)	
R616	1-216-045-00	METAL CHIP 680 5% 1/10W	
R617	1-216-121-00	METAL CHIP 1M 5% 1/10W	
R618	1-216-060-00	METAL GLAZE 3K 5% 1/10W	
R619	1-216-025-00	METAL CHIP 100 5% 1/10W	
R620	1-216-045-00	METAL CHIP 680 5% 1/10W(H170K)	
R621	1-216-121-00	METAL CHIP 1M 5% 1/10W(H170K)	
R622	1-216-060-00	METAL GLAZE 3K 5% 1/10W(H170K)	
R623	1-216-025-00	METAL CHIP 100 5% 1/10W(H170K)	
R624	1-216-121-00	METAL CHIP 1M 5% 1/10W(H170K)	
R626	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R627	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R628	1-216-063-00	METAL CHIP 3.9K 5% 1/10W	
R629	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R630	1-216-017-00	METAL CHIP 47 5% 1/10W	
R632	1-216-097-00	METAL CHIP 100K 5% 1/10W	
R633	1-216-097-00	METAL CHIP 100K 5% 1/10W(H170K)	
R634	1-216-035-00	METAL CHIP 270 5% 1/10W	
R635	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R636	1-216-089-00	METAL CHIP 47K 5% 1/10W(H170K)	
R676	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R677	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R678	1-216-063-00	METAL CHIP 3.9K 5% 1/10W	
R679	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R687	1-216-105-00	METAL CHIP 220K 5% 1/10W	
R688	1-216-017-00	METAL CHIP 47 5% 1/10W	
△R831	1-219-119-11	FUSIBLE 0.1 5% 1/4W F	
△R881	1-219-119-11	FUSIBLE 0.1 5% 1/4W F	
R1028	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R1501	1-216-041-00	METAL CHIP 470 5% 1/10W	
R1502	1-216-045-00	METAL CHIP 680 5% 1/10W	
R1503	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R1504	1-216-053-00	METAL CHIP 1.5K 5% 1/10W	
R1505	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R1506	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R1507	1-216-075-00	METAL CHIP 12K 5% 1/10W	
R1508	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R1509	1-216-075-00	METAL CHIP 12K 5% 1/10W	
R1510	1-216-029-00	METAL CHIP 150 5% 1/10W	
R1511	1-216-033-00	METAL CHIP 220 5% 1/10W	
R1512	1-216-037-00	METAL CHIP 330 5% 1/10W	
R1513	1-216-041-00	METAL CHIP 470 5% 1/10W	
R1514	1-216-045-00	METAL CHIP 680 5% 1/10W	
R1515	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R1517	1-216-075-00	METAL CHIP 12K 5% 1/10W	
R1518	1-216-067-00	METAL CHIP 5.6K 5% 1/10W	
R1519	1-216-029-00	METAL CHIP 150 5% 1/10W	
R1520	1-216-033-00	METAL CHIP 220 5% 1/10W	
R1521	1-216-037-00	METAL CHIP 330 5% 1/10W	

Ref. No.	Part No.	Description	Remarks
R1522	1-216-041-00	METAL CHIP 470 5% 1/10W	
R1523	1-216-045-00	METAL CHIP 680 5% 1/10W	
R1524	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R1525	1-216-067-00	METAL CHIP 5.6K 5% 1/10W	
R1526	1-216-029-00	METAL CHIP 150 5% 1/10W	
R1527	1-216-029-00	METAL CHIP 150 5% 1/10W	
R2001	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R4000	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R4001	1-216-298-00	METAL CHIP 2.2 5% 1/10W	
R4002	1-216-298-00	METAL CHIP 2.2 5% 1/10W	
R4003	1-216-298-00	METAL CHIP 2.2 5% 1/10W	
R4004	1-216-298-00	METAL CHIP 2.2 5% 1/10W	
R4005	1-216-298-00	METAL CHIP 2.2 5% 1/10W	
R4006	1-216-298-00	METAL CHIP 2.2 5% 1/10W	
R4007	1-216-298-00	METAL CHIP 2.2 5% 1/10W	
R4008	1-216-298-00	METAL CHIP 2.2 5% 1/10W	
△R4009	1-212-849-00	FUSIBLE 4.7 5% 1/4W F	
△R4010	1-212-849-00	FUSIBLE 4.7 5% 1/4W F	
R4099	1-249-390-11	CARBON 5.6 5% 1/6W	
R4421	1-216-049-00	METAL CHIP 1K 5% 1/10W	
< VARIABLE RESISTOR >			
RV201	1-241-136-11	RES, ADJ, CARBON 10K	
RV301	1-241-136-11	RES, ADJ, CARBON 10K	
< SWITCH >			
S1022	1-572-184-11	SWITCH, KEYBOARD (CONTINUE)	
S1501	1-572-184-11	SWITCH, KEYBOARD (▲)	
S1502	1-572-184-11	SWITCH, KEYBOARD (▶▶▶)	
S1503	1-572-184-11	SWITCH, KEYBOARD (■)	
S1504	1-572-184-11	SWITCH, KEYBOARD (◀)	
S1505	1-572-184-11	SWITCH, KEYBOARD (◀◀)	
S1506	1-572-184-11	SWITCH, KEYBOARD (REPEAT)	
S1507	1-572-184-11	SWITCH, KEYBOARD (PROGRAM)	
S1508	1-572-184-11	SWITCH, KEYBOARD (SHUFFLE)	
S1509	1-572-184-11	SWITCH, KEYBOARD (EDIT/TIME/FADE)	
S1510	1-572-184-11	SWITCH, KEYBOARD (CHECK)	
S1511	1-572-184-11	SWITCH, KEYBOARD (■)	
S1512	1-572-184-11	SWITCH, KEYBOARD (PAUSE)	
S1513	1-572-184-11	SWITCH, KEYBOARD (▷)	
S1514	1-572-184-11	SWITCH, KEYBOARD (<)	
S1516	1-572-184-11	SWITCH, KEYBOARD (◀◀)	
S1517	1-572-184-11	SWITCH, KEYBOARD (▶▶)	
S1518	1-572-184-11	SWITCH, KEYBOARD (■)	
S1519	1-572-184-11	SWITCH, KEYBOARD (▷)	
S1520	1-572-184-11	SWITCH, KEYBOARD (<)	
S1521	1-572-184-11	SWITCH, KEYBOARD (◀◀)	
S1522	1-572-184-11	SWITCH, KEYBOARD (▶▶)	
S1523	1-572-184-11	SWITCH, KEYBOARD (REC)	
S1524	1-572-184-11	SWITCH, KEYBOARD (HIGH SPEED)	
S1525	1-572-184-11	SWITCH, KEYBOARD (CD SYNC)	

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

SUB (including POWER TRANSFORMER/VOLUME/MIC HP/SW)

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
△S126	1-570-837-11	SWITCH, SLIDE (DIRECTION MODE)		ACCESSORIES & PACKING MATERIALS			
S1527	1-570-849-11	SWITCH, SLIDE (DOLBY NR)		*****			
△VS801	1-572-675-11	SWITCH, POWER VOLTAGE CHANGE		1-501-369-11	ANTENNA (H700:UK)		
		(H170:E, EA, H170K)		1-501-374-11	ANTENNA, LOOP (H700:UK)		
< TEST PIN >				1-693-057-11	COMMANDER, STANDARD (RM-S150)		
* TP101	1-564-517-11	PLUG, CONNECTOR 2P		3-701-630-00	BAG, POLYETHYLENE (H700:UK)		
* TP201	1-564-518-11	PLUG, CONNECTOR 3P		3-755-073-11	MANUAL, INSTRUCTION (ENGLISH, FRENCH, SPANISH, CHINESE, DUTCH) (H700:UK)		
* TP401	1-564-518-11	PLUG, CONNECTOR 3P		* 4-941-548-01	LABEL, CLASS 1 (H170, H170K/H700:AEP)		
< VIBRATOR >				* 4-951-410-01	INDIVIDUAL CARTON (H700:UK)		
X401	1-567-819-11	VIBRATOR, CERAMIC 4MHz		* 4-951-934-01	CUSHION, UPPER		
X601	1-567-819-11	VIBRATOR, CERAMIC 4MHz (H170K)		* 4-951-935-01	CUSHION, LOWER		
*****				4-952-050-01	LABEL, MODEL NUMBER (AE) (H700:AEP)		
MISCELLANEOUS				4-952-381-01	LABEL, MODEL NUMBER (AU) (H170:AUS)		
*****				*****			
△T101	1-450-769-11	TRANSFORMER, POWER (H170:AEP, H700)		*****			
△T101	1-450-770-11	TRANSFORMER, POWER (H170:E, EA, AUS, H170K)		HARDWARE LIST			
55	1-696-146-11	WIRE (FLAT TYPE) (16 CORE)		*****			
58	1-690-996-11	WIRE (FLAT TYPE) (4 CORE)		#1	7-682-547-04	SCREW +BVTT 3X6 (S)	
* 59	1-590-240-11	WIRE, FLAT TYPE (9 CORE)		#2	7-685-649-79	SCREW +BVTP 3X14 TYPE2 IT-3	
60	1-690-997-11	CABLE, FLAT (11 CORE)		#3	7-685-647-79	SCREW +BVTP 3X10 TYPE2 N-S	
61	1-690-588-31	WIRE, FLAT TYPE (9 CORE)		#4	7-682-549-09	SCREW +BVTT 3X10 (S) (H170, H170K)	
△64	1-574-804-11	CORD, POWER (H700:UK)		#5	7-621-255-15	SCREW +PTT 2X3 (S)	
△64	1-574-805-11	CORD, POWER (H170:AEP, EA/H170K:EA/H700)		#6	7-621-770-67	SCREW +PTT 2.6X6 (S)	
△64	1-574-902-11	CORD, POWER (H170:E/H170K:E)		#7	7-627-556-08	SCREW +P 2.6X2.8	
△64	1-690-056-11	CORD, POWER (H170:AUS)		#8	7-621-775-00	SCREW +B 2.6X3	
167	1-638-983-11	PC BOARD, MOTOR FLEXIBLE		#9	7-685-234-19	SCREW +KTP 2.6X8 TYPE2NON-SLIT	
253	1-590-530-11	WIRE, FLAT TYPE		#10	7-685-646-79	SCREW +BVTP 3X8 TYPE2 N-S	
264	1-690-853-11	WIRE (FLAT TYPE) (19 CORE)		#11	7-624-105-04	STOP RING 2.3, TYPE -E	
△305	8-848-144-11	DEVICE, OPTICAL KSS-240A		#12	7-621-775-10	SCREW +B 2.6X4	
307	1-575-001-11	WIRE, FLAT TYPE (12 CORE)		#13	7-685-134-19	SCREW +BTP 2.6X8 TYPE2 N-S	
ANT1	1-501-321-61	ANTENNA, TELESCOPIC (H170, H170K)		#14	7-685-136-19	SCREW +P 2.6X12 TYPE2 NON-SLIT (H170, H70K)	
△F801	1-532-078-00	FUSE (1A) (H700, H170:AEP, AUS)					
△F801	1-532-203-00	FUSE (2A) (H170:E, EA, H170K)					
△F802	1-532-078-00	FUSE (1A) (H170, H170K:E, EA)					
HP101	A-2003-868-A	BASE ASSY, HEAD					
HRP101	A-2003-838-A	BASE ASSY, HEAD					
M101	X-4917-504-1	MOTOR ASSY (SLED)					
M101A	X-3363-501-1	MOTOR ASSY, REEL (DECK A)					
M101B	X-3363-501-1	MOTOR ASSY, REEL (DECK B)					
M102	X-4917-523-3	MOTOR ASSY (SPINDLE)					
M102A	X-3359-417-1	MOTOR (CAPSTAN MOTOR) ASSY (DECK A)					
M102B	X-3359-417-1	MOTOR (CAPSTAN MOTOR) ASSY (DECK B)					
M251	A-4608-362-A	MOTOR (L) ASSY					

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

SS-H150/H170/H700

SERVICE MANUAL

*AEP Model
UK Model*

*E Model
Australian Model*
SS-H150/H170





Photo:SS-H150

- SS-H150 is the speaker system in FH-B150.
- SS-H170 is the speaker system in FH-B170/B170K.
- SS-H700 is the speaker system in MHC-500/700.

SPECIFICATIONS

Speaker system 3 way system
Speaker units
Woofer: 13 cm dia., cone type
Tweeter: 5 cm dia., cone type
Super tweeter: 2 cm dia., dome type
Enclosure Bass reflex
Frequency range 60 Hz — 20 kHz
Sensitivity 88 dB/w/m
Rated impedance 6 ohms
Dimensions Approx. 195 x 285 x 230 mm
(7 5/8 x 11 1/4 x 9 inches)
Weight Approx. 3.0 kg (6 lb 10 oz)
net per speaker

WIRING DIAGRAM



SPEAKER SYSTEM
SONY®




3. EXPLODED VIEW AND PARTS LIST

NOTE:

- - XX, - X mean standardized parts, so they may have some differences from the original one.
- Color Indication of Appearance Parts
Example :
KNOB, BALANCE (WHITE)...(RED)
Parts color Cabinet's color
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.

— L-CH —



Ref. No.	Part No.	Description
1	X-4942-258-1	PANEL (R) ASSY, FRONT
	X-4942-259-1	PANEL (L) ASSY, FRONT
	X-4942-611-1	PANEL (R) ASSY, FRONT (H170/H700)
	X-4942-612-1	PANEL (L) ASSY, FRONT (H170/H700)
2	7-621-849-10	SCREW +P 3X12 TYPE4
3	4-874-614-11	SCREW (4) (3.5X14), TAPPING
4	9-911-844-XX	PACKING
5	7-685-646-79	SCREW +BVTP 3X8 TYPE2 SLIT
6	X-4942-260-1	CABINET ASSY, SPEAKER (H700: AEP, UK)
	X-4942-357-1	CABINET ASSY, SPEAKER (H150, H170)
	X-4942-803-1	CABINET ASSY, SPEAKER (H700: Germany)
7	1-575-610-11	CORD, CONNECTION (H700)
8	1-537-332-11	TERMINAL BOARD (H700)
9	1-574-792-11	CORD, SPEAKER (H150, H170)
10	4-870-003-00	CLIPPER, CORD (H150, H170)

Remarks

Ref. No.	Part No.	Description
11	4-874-614-61	SCREW +BVTP 3.5X16 (H150, H170)
12	4-929-656-01	PANEL, SIDE (H150)
13	4-950-752-01	PANEL (L), SIDE (H170)
13	4-950-753-01	PANEL (R), SIDE (H170)
SP1	1-544-237-11	SPEAKER (13CM)
SP2	1-544-236-11	SPEAKER (5CM)
SP3	1-544-293-11	SPEAKER (2CM)

ACCESSORIES & PACKING MATERIALS

- 4-920-151-01 SHEET, PROTECTION
- 4-951-731-01 BOARD, BAFFLE

Sony Corporation
Audio Group

English
92C1669-1
Printed in Japan
© 1992.3

Published by Customer Relations and Service Group

HCD-H170/H170K/H700

SONY SERVICE MANUAL

AEP Model
HCD-H170/HCD-H700

UK Model
HCD-H700

E Model
HCD-H170/HCD-H170K

Australian Model
East European Model
Canadian Model
HCD-H170

SUPPLEMENT-1

File this supplement with the Service Manual.

Subject: EXPLODED VIEWS/ELECTRICAL PARTS LIST Addition

1. The parts number for the following printed wiring boards are registered as independent parts. The original parts numbers for these wiring boards are changed accordingly.

NOTE:

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- EA : Saudi Arabia model
- AUS : Australian model
- EE : East European model
- G : Germany model
- IT : Italian model
- CND : Canadian model

 : Changed PART


SECTION 7 EXPLODED VIEWS

Page 71.

7-1. CASE, POWER SECTION

- ▲ A : POWER board (See page 72)
- B : POWER TRANSFORMER board (See page 73)

delete




Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
* 12	A-4347-485-A	POWER BOARD, COMPLETE (H170:E/EA, H170K model)			A-4347-494-A	POWER BOARD, COMPLETE (H170:G/IT model)	
	A-4347-493-A	POWER BOARD, COMPLETE (H170:AEP/EE, H700 model)			A-4347-543-A	POWER BOARD, COMPLETE (H170:AUS model)	
					A-4356-343-A	POWER BOARD, COMPLETE (H170:CND model)	
				* 13	1-643-352-11	POWER TRANSFORMER BOARD	

7-2. FRONT PANEL, MAIN BOARD SECTION

● C: VOLUME board (See page 73)

● D: MIC HP board (See page 73)


● E: SW board (See page 73)



Ref. No.	Part No.	Description	Remarks
* 65	A-4347-468-A	MAIN BOARD, COMPLATE (H170:E/EA/AUS model)	
* 65	A-4347-484-A	MAIN BOARD, COMPLATE (H170K model)	
* 65	A-4347-487-A	MAIN BOARD, COMPLATE (H170:AEP model)	
* 65	A-4347-488-A	MAIN BOARD, COMPLATE (H170:G/IT model)	
* 65	A-4347-489-A	MAIN BOARD, COMPLATE (H170:EE model)	
* 65	A-4347-492-A	MAIN BOARD, COMPLATE (H700:AEP/UK model)	
* 65	A-4356-342-A	MAIN BOARD, COMPLATE (H170:CND model)	

Ref. No.	Part No.	Description	Remarks
* 69	A-4347-467-A	MIC HP BOARD, COMPLATE (H170:CND/AEP/E/EA/EE/AUS, H700 model)	
* 69	A-4347-478-A	MIC HP BOARD, COMPLATE (H170:G/IT model)	
* 69	A-4347-482-A	MIC HP BOARD, COMPLATE (H170K model)	
* 70	1-643-349-12	VOLUME BOARD	
* 71	A-4347-470-A	SW BOARD, COMPLATE (H170:G/IT model)	
* 71	A-4347-471-A	SW BOARD, COMPLATE (EXCEPT H170:G/IT model)	

7-3. MD CHASSIS SECTION



Ref. No.	Part No.	Description	Remarks
* 113	A-4347-472-A	SUB BOARD, COMPLETE (H170:AEP/E/EA/EE/AUS, H170K, H700 model)	
* 113	A-4347-476-A	SUB BOARD, COMPLETE (H170:G/IT model)	
* 113	A-4356-345-A	SUB BOARD, COMPLETE (H170:CND model)	

SECTION 8

ELECTRICAL PARTS LIST

Ref. No.	Part No.	Description	Remarks
----------	----------	-------------	---------

•For the list of individual parts constituting the MAIN BOARD,
See the parts list "MAIN BOARD COMPLETE" in the Service
Manual.

MAIN BOARD, COMPLETE

- * A-4347-468-A (H170:E/EA/AUS model)
- * A-4347-487-A (H170:AEP model)
- * A-4347-488-A (H170:G/IT model)
- * A-4347-489-A (H170:EE model)
- * A-4356-342-A (H170:CND model)
- * A-4347-484-A (H170K model)
- * A-4347-492-A (H700:AEP/UK model)

POWER BOARD, COMPLETE

- * A-4347-485-A (H170:E/EA, H170K model)
- * A-4347-493-A (H170:AEP/EE, H700 model)
- * A-4347-494-A (H170:G/IT model)
- * A-4347-543-A (H170:AUS model)
- * A-4356-343-A (H170:CND model)

•For the list of individual parts constituting the SUB BOARD,
See the parts list "SUB BOARD COMPLETE" in the Service
Manual.

MIC HP BOARD, COMPLETE

- * A-4347-467-A (H170:CND/AEP/E/EA/EE/AUS, H700 model)
- * A-4347-478-A (H170:G/IT model)
- * A-4347-482-A (H170K model)

- Items marked "*" are not stocked
since they are seldom required for
routine service. Some delay should
be anticipated when ordering these
items.

Ref. No.	Part No.	Description	Remarks
----------	----------	-------------	---------

SW BOARD, COMPLETE

- * A-4347-470-A (H170:G/IT model)
- * A-4347-471-A (EXCEPT H170:G/IT model)

VOLUME BOARD

- * 1-643-349-12

SUB BOARD, COMPLETE

- * A-4347-472-A (H170:AEP/E/EA/EE/AUS, H170K, H700 model)
- * A-4347-476-A (H170:G/IT model)
- * A-4356-345-A (H170:CND model)

POWER TRANSFORMER BOARD

- * 1-643-352-11

Note :

- CND : Canadian model
- G : Germany model
- IT : Italian model
- EA : Saudi Arabia model
- EE : East European model
- AUS : Australian model

Sony Corporation
Audio Group

9-957-082-81

English
93D1674-1
Printed in Japan
© 1993.4
Published by Audio Corporate Planning Group

FH-B170/B177/B170K, MHC-700

SERVICE MANUAL

AEP Model

E Model

FH-B170/B170K

East European Model

Australian Model

FH-B170

These systems are composed of following models.
As for the service manual, it is issued for each component model, then, please refer to it.

COMPONENT MODEL NAME FOR THESE SYSTEM

	FH-B170	FH-B177	FH-B170K	MHC-700
TUNER, DECK, CD, AMPLIFIER	HCD-H170		HCD-H170K	HCD-H700
SPEAKER SYSTEM	SS-H170	SS-H177	SS-H170	SS-H700

PARTS LIST

● Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

EE : East European Model
EA : Saudi Arabia Model
G : Germany Model

IT : Italian Model
AUS : Australian

Part No.	Description	Remarks
1-501-369-11	ANTENNA (MHC-700)	
1-501-374-11	ANTENNA, LOOP (except FH-B170)	
1-569-007-11	ADAPTOR CONVERSION 2P (E, EA)	
1-575-495-11	CORD, SPEAKER (MHC-700)	
3-755-073-11	MANUAL, INSTRUCTION (AEP, North European, AUS) (English, F, E, RC, NL)	
3-755-073-41	MANUAL, INSTRUCTION (AEP, North European, G, IT) (D, S, P, I)	
3-755-073-51	MANUAL, INSTRUCTION (EE) (English, D, SU, PL)	
3-755-073-71	MANUAL, INSTRUCTION (E, EA) (English, F, E, RC, NL)	

Part No.	Description	Remarks
*4-951-405-01	INDIVIDUAL, CARTON (FH-B170; except AUS)	
*4-951-407-01	INDIVIDUAL, CARTON (AUS)	
*4-951-408-01	INDIVIDUAL, CARTON (G, IT, EE)	
*4-951-409-01	INDIVIDUAL, CARTON (AEP, North European)	
*4-951-411-01	INDIVIDUAL, CARTON (FH-B170K)	

Note	F : FRENCH	RC : CHINESE
	D : GERMAN	NL : DUTCH (HOLLAND)
	I : ITALIAN	S : SWEDISH
	P : PORTUGUESE	SU : RUSSIAN
	E : SPANISH	PL : POLAND

COMPACT HI-DENSITY
COMPONENT SYSTEM
SONY®



9-957-147-11

Sony Corporation
Audio Group

English
92C1863-1
Printed in Japan
© 1992.3
Published by Customer Relations and Service Group